

T 515

M72

Copy 1



THE  
KEY TO SUCCESS,  
OR THE  
DRESSMAKER'S GUIDE,

*By Mrs C. F. Moll*

Principal of the Defiance Sewing School.

PRICE \$1.50.

329321

DEFIANCE, OHIO.

Entered according to Act of Congress, in the Year 1882,  
By MRS C F MOLL,  
In the Office of the Librarian of Congress, at Washington.

WHITE & MAINS, PRS., DEFIANCE, OHIO.

## PREFACE.

Having long noticed the failures that so many of our young girls make, even when they are said to have learned the art of Dressmaking, the author determined to find out the cause and if possible to invent a remedy. The conclusion reached was that their failures was due, first, to poor guides, and second in their not having any definite rules for drafting. The first is easily remedied, as there are many guides to choose from. The second the author has endeavored to correct by issuing this little book; giving it in as compact form as possible and using such language that all may be able to readily understand. With this explanation we send it forth on its mission, that mission to help those who are struggling to be successful in the art of Dress-making.

MRS. C. F. MOLL,  
Defiance, Ohio.

# LESSONS.

---

## LESSON I.

Suggestion on the positions of the person while being measured. Also, the proper manner of placing the tape line at the different points of the form:

1. The lady should stand in her natural position, erect with her arms down.

2. The person taking the measure should stand on the right of the one being measured and should hold the end of the tape-line in her left hand, never pressing too hard but at the same time being sure that the end of the line is on the cords and joints as it should be.

3. In order to obtain a good fit it is necessary that the measures called for in this guide, in connection with these I shall give are taken as accurately as possible.

**LESSON 2.****Manner and Order of Taking the Measure.****Length of Waist at Side.**

Number 1. Place the end of tape on the back cord of the arm and measure down to the hip as long as the dress can be worn.

**Length at Center of Back.**

Number 2. From the last joint of the back bone, at the neck, down even with the length of the waist at the side.

**Length of Back to Upper Neck.**

Number 3. From the cord at the side of the neck, as high as you desire the dress to be, down to the waist line at center of back.

**Hight of Shoulders in the Back.**

Number 4. From the shoulder joint to the waist line at center of back.

**Length of Shoulders.**

Number 5. From the cord of the neck, at the side, as high as you desire the dress to be, down as long as fashion requires. Notice should be taken whether the shoulder is hollow, medium or full. Hollow is a sloping shoulder. A full shoulder is thick and square. Medium between hollow and full.

**Across the Shoulders.**

Number 6. From the joint of the shoulder across the back to the opposite side.

**Across the Back.**

Number 7. From the back cord of the arm straight across to the opposite side.

**Bust Measure.**

Number 8. Place the end of the tape-line at the center of the back, between the shoulder blades, passing the tape-line under the arms and over the center of the breast. This measure should be taken loose.

**Length up Center of Front.**

9. From the hollow of the neck down as long as it is natural for the dress to be worn, or even with the length of waist at the side.

**Length of Front to Upper Neck.**

Number 10. From the cords at the side of the neck, as high as you wish the dress to be, down to the waist line at center of front.

**Height of Shoulders in the Front.**

Number 11. From the waist line at center of front to the shoulder joint.

**Chest Measure.**

Number 12. From the cord of the arm in front across to the opposite side.

**Belt Measure.**

Number 13. The tape line should be drawn tight so as to allow for being taken over the dress.

**Dart Measure.**

Number 14. Place a pin in the front and back four inches above the waist line and measure all around the form, drawing the tape-line as tight as the lady desires the dress to be.

**Neck Measure.**

Number 15. This measure should never be taken over the dress or a collar, but the tape-line should pass around the neck and just meet over the end of the fore-finger which should be placed between the tape-line and front of neck. This measure should be taken close.

**Arm Size.**

Number 16. This measure is taken around the upper part of the arm, where the sleeve is sewed into the dress. For a large sized arm this measure should be taken closer than for a medium or a small sized arm, as it gives a better proportion to the dress when finished.

**Sleeve Measure.**

Number 17. First, from the cord of the arm in front to the joint of wrist. Second, around the largest part of the hand as tight as the lady desires the sleeve to be. Third, from the cord at side of neck, as in taking length of shoulders, over the shoulder joint and elbow down to the outside joint of the wrist. Fourth, from the elbow to joint of wrist; this measure is taken only when the sleeve to be drafted is gathered at the elbow. Fifth, the arm being bent, measure around the elbow; this measure, which is taken only for drafting tight sleeves, should be taken as much looser than is necessary for the bending of the arm as is desired by the lady.



**Hip Measure.**

Number 18. From a joint four inches below the length of waist, under the arm, across to the opposite side. Great care should be used in taking this measure and the rule should be followed accurately, and endeavor to keep the tape-line at all points four inches below the waist line.

**Form Measure.**

Number 19. Around the form, four inches below the waist line.

**Length of Skirt.**

Number 20. From the waist line as long as the lady desires the dress to be. Measure at each side, left and right, as some persons stand with one hip higher than the other. Measure also, down the center of back and ascertain how wide the lady desires the skirt to be at the bottom.

**Length of Elastic for Skirt.**

Number 21. Take the measure around the form, four inches above one-half the length of skirt. Observe if hoops or bustle are to be worn.

**For Drapery, Elastic in Basque, Polonaise or Overdress.**

Measure around the form nine inches below the waist line.

**MEASURES FOR PRACTICE.****BACK OF WAIST,**

1. Length of waist at side,  $8\frac{1}{2}$  inches.
2. Length of waist up center of back, 16 inches.
3. Length of back to upper neck,  $16\frac{1}{2}$  inches.

4. Height of shoulder in the back, 15 inches.
5. Length of shoulder,  $5\frac{1}{2}$  inches.
6. Width of shoulder,  $13\frac{1}{2}$  inches.
7. Across the Back,  $12\frac{1}{2}$  inches.
8. Bust measure, 36 inches.

## FRONT OF WAIST.

1. Length of waist at side,  $8\frac{1}{2}$  inches.
5. Length of shoulder,  $5\frac{1}{2}$  inches.
8. Bust measure, 36 inches.
9. Length up center of front, 13 inches.
10. Length of front to upper neck,  $16\frac{1}{2}$  inches.
11. Height of shoulder in front, 16 inches.
12. Chest measure, 13 inches.
13. Belt Measure, 24 inches.
14. Dart Measure, 27 inches.
15. Neck measure, 12 inches,
16. Arm size, 16 inches.

## SLEEVE

17. Sleeve measure: 1st, 18 inches. 2d, 9 inches. 3d,  $28\frac{1}{2}$  inches. 4th, 11 inches. 5th, 14 inches
18. Hip measure, 25 inches.
19. Form measure, 40 inches.

## SKIRT.

20. Length of skirt: 1st, 40 inches; 2d, 40 inches; 3d, 41 inches; 4th,  $40\frac{1}{2}$  inches. Width at bottom  $2\frac{1}{2}$  yards.
21. Width for elastic in skirts, 45 inches.
22. For Drapery elastic, 43 inches.

**LESSON 3.****To Draft the Back of a Tight Waist without Side Forms.****THE BACK.**

The back must be drafted first.

First dot in the perforation along No. 2, opposite the figure or perforation denoting the length of No. 1. Place the end of the tape-line on this point and measure up the length of No. 2. From the first point made measure up the length of No. 3 to form the upper neck. From the same first point measure up the length of No. 4, less two inches. Measure one-half the length of No. 6, straight across to the hem-line, to the upper part of No. 4. This is to prove if the length of shoulder be long enough in proportion to the width of shoulder. Measure straight across from the hem-line even with No. 7, plus one-half of an inch for seams. Dot at No. 8 in the perforation whose number corresponds to the measure No. 8. Dot under the bust measure in the scale of P, the length of No. 1.

**TO OUTLINE,**

Draw a line from the first dot made at center of back, up to the dot denoting the length of measure No. 2. To slope the back measure in one-half inch from the first dot and connect this point by a line with the center of the length of No. 2.

Make all lines with a straight rule unless otherwise directed.

To outline the back of neck draw a line from the upper dot No. 2 to No. 3 with the neck of guide,

To outline the shoulder draw a line from No. 3 to No. 4, with the shoulder edge of guide.

To outline the back arm size, draw a line from No. 4 to No. 8, and touching No. 7, with edge of back arm size of guide.

To outline the under arm seam, place the arm point of guide on the arm point of goods, and the under arm line resting on the point No. 1 and connect the two points by a line drawn along the edge of guide.

To outline the waist-line, connect with a straight rule the point denoting the length of No. 1, to the first dot made

If the back is sloped, the same that you slope off from the back should be added to the waist-line at the side.

## LESSON 4.

### **To Draft a Back with the English Side Form.**

To Draft a Back with the English Side Form, proceed in the same manner as for plain back until No. 7 is reached.

From the center of back measure across to the bust measure in the scale of P. Subtract one inch from this length and one-half of the remainder will be the width of the center of back at waist line.

After pointing off this measure at the waist line, (first sloping the back) place the pointed end of the side form rule at No. 7, rest the curved edge on the waist line before pointed off, and draw a line along the curved edge, thus forming the center of back.

To draft the side form dot at No. 7, No. 8 and No. 1. Outline the arm size and under arm seam as in plain waist. Outline the waist line measure straight across one inch more than the center of back. To outline the back of side form, draw a line over the curved edge of side form the point of which is resting on No. 7, and the curved edge on waist line.

## LESSON 5,

### To Draft a Back with the French Side Form.

To Draft a Back with French Side Form: Draft the center of back the same as for English, pointing off at the shoulder where it is desired that the line should be. Point off at the waist line the same as for the English side form. Connect with a straight line, or if it is desired that it should be slightly curved, place the pointed end of the dart rule at the shoulder and the side towards the back, resting on the waist line, draw along the back edge

To draft the side form, first form the shoulder part by dotting at upper neck and height of shoulder, and measure down from the neck point as far as is the center back. dot at No. 7, No. 8 and No. 1, outline the arm size and length of waist under the arm; point off the waist line the same as for the center back.

**LESSON 6.****Draft Front of Plain Tight Waist.**

To Draft the Front of a Plain tight Waist Fitted with Two Bust Darts: First dot in the preforation along No. 9, opposite the figures on preforation denoting the length of No. 1.

Place the tape line on this point and measure up the length of No. 9, or length up center of front; then the length of No. 10, the length to upper neck; and still from the same point, the length of No. 11, one height of the shoulder, plus two inches. From the upper part of No. 10 measure the length of No. 5, plus one half inch for seams; and outline with the shoulder edge of guide. If the shoulder be hollow, medium or full, place the end of tape line at the point above the word hollow, medium or full, and let the guide rest on the upper point of No. 11.

Measure straight across from the inside of the hem line to No. 12 on the front arm size cord, one half of No. 12 plus one half inch for seams.

Dot at the preforation or number denoting the length of No. 8 or bust measure.

To find the position of the darts dot in the preforation having the number denoting the length of No. 8.

Dot the length of No. 1 even with the bust measure.

To draw the waist line, place the bottom of the front edge of guide on the lower point of No. 9 and the side resting on the lower point of No. 1 and connect by a line drawn along the lower edge of guide, still in the same position draw a line along the edge of center of front.

To outline the neck draw with the neck of guide a curved line from No. 9 to No. 10. If the neck does not measure enough hollow it out; if too large reduce the size. First measure the back with the tape line at the edge of the neck, then measure the front

To outline arm size place the point of A of the arm size of guide on No. 12; the the upper part resting on the lower length of No. 5; connect these two points by drawing along the edge of guide, then keeping the point A on No. 12, let the lower part of the arm size of guide rest on the end of No. 8; connect as in the upper part.

Place the arm point of guide even with the arm point of goods and the edge resting on the point denoting length of No. 1; thus forming the under arm seam. To find the arm size, measure first the back arm size, then the front; if too small lower from A to the arm point until the required size.

To find the height of the darts measure with a straight rule two inches down from the lowest part of arm size and from this point draw a line straight across to the hem line. Lower the back dart even with this line and the front dart in the same proportion,

To find the width of the darts at the waist line subtract No. 13 from No. 8 and the remainder will be the number of inches for

darts. As but one half of the garment is drafted (the other being cut by the part drafted) divide this remainder by two. Measure one and a half inches in from the hem line on the waist line; from this dot measure the width of the front dart, which must be one-half inch less in width than the back dart, from this measure on three fourth to one inch for the distance between the darts and then measure the width of the back dart.

To draft the darts for tapering waist, place the pointed end of dart rule at the height of darts and draw along the outside edge to point for width of darts at the waist line. For full forms place the top of dart rule two inches above the top of dart.

If the measure No. 8 is full and No. 13 and No. 14 are small use sloping darts.

To ascertain if the darts are sloped correctly measure the back and front, four inches above the waist line, and compare with the measure of the person; if too small slope the darts until the waist measures the requisite number of inches; if too large the darts are sloped too much.

Before cutting out measure all parts to prove if it be correct. In drafting a plain waist without a skirt use no underarm dart unless called for by the pattern.

To draft an under arm dart for plain waist:

Rule first. Take one eighth of the difference between No. 8 and No. 13 for the width of each of the under arm darts at the waist line. Measure in from the top and bottom of the underarm seam according to the following rule:



With a belt measure of from eighteen to twenty-six inches, measure two inches; with a belt measure from twenty-six up measure in one-sixteenth of an inch more for every inch above twenty-six. From the last dot made on the waist line measure the width of the underarm dart, outline the dart with underarm seam of guide.

Second Rule. Add to the underarm seam one inch for seams of the underarm dart. Draft the darts first and place the under arm dart in from the under arm seam as in the first rule.

Remember to take the added fullness from the new underarm seam of the under arm dart.

There will be nothing but half inch seams as the fullness that there is in the bust darts has already been taken out.

## LESSON 7.

### To Draft the Front of Loose Waist.

To Draft the Front of Loose Waist, draft as for tight waists with the following exceptions:

Add to No. 8 No. 12 and No. 5 from one half to one inch for looseness and let the darts for fullness at the waist line.

**LESSON 8.****To Draft the Back of Loose Waist.**

To Draft the Back of Loose Waist, draft as for tight waist with the following exceptions:

Add from one-half to one inch to the width across the back, across the shoulder and the bust measure.

Also add to the waist line at the under arm seam from three to six inches for gathers.

**LESSON 9.****To Draft Yoke Waist, Gathered Body.**

To Draft Yoke Waist, Gathered Body, draft the upper part the same as for tight waist, and point off the yoke with straight or curved rule according to the style desired.

To draft the lower body, dot at the arm size and at the lower part of yoke. At this point extend the body from three to six inches out in a straight line. Sometimes more than six inches may be added.

From the arm size at A and from the bust measure dot, measure out the same distance as above and dot; thus forming the remainder of the arm size. The front and back are drafted by the same rule.

**LESSON 10.****Yoke Waist with Pleated Body,**

To Draft Yoke Waist with Pleated Body, draft the yoke the same as for yoke with gathered body.

Fold the pleats as the style requires and draft the body below the yoke, as for loose waist.

## LESSON 11.

### Plain Waist Open in the Back.

For Plain Waists Open in the Back: In drafting the front place the lap part of the guide even with the fold of the goods and draft as for tight waist.

In drafting the back allow one half inch for laps and draft as for tight waist. Allow one half inch seams all around, except at the under arm seam which should be one inch.

## LESSON 12.

### Half Fitting Waists.

To Draft Half Fitting Waist: Draft as for loose waist and leave but one dart for looseness at waist line. Place the top of the dart to be drafted, half way between the two dots for position of darts.

Place the front edge of dart, two inches in from the hem line on the waist line. If it is desired that the dress should be tight, a dart, equal in width to two-thirds of the width of the two darts may be drafted

For back of half fitting waist, draft as for back of loose waist with the exception of adding one-half inch to the waist line for fullness.

**LESSON 13.****To Draft Diagonal Waists.**

In drafting the front, fold the lining as for the front of waist open in the back; draft the same. After drafting, fold or crease, as fashion requires.

In waists with the diagonal from the left shoulder to first dart at the right side, baist the darts in both sides of the lining before making the diagonal line. After cutting out add one-half inch to each side for laps and piece with flat seams.

In drafting for a dress in which no lining is to be used, draft first on paper as the out side must not be pieced for the laps.

**LESSON 14.****To Draft Plaited Waists of Any Kind.**

First fold the plaits and baist them to position; draft as for the style desired, and be sure in cutting the reversed side that the sides match.

**LESSON 15.****To Draft Double Breasted Waists.**

Slip the guide in as far from the edge as it is desired that the fold should be, and draft the style desired.

---

**LESSON 16.****To Draft the Surplus Waist,**

Draft as for a doubled breasted waist, and draw a line from the upper neck to the front edge at waist line; this being the surplus line. In cutting out no seam is allowed along its length.

**LESSON 17.****To Draft Low Neck Waists,**

Draft for high neck and cut out the neck, shaped by curved or straight rule, as style may require.

**LESSON 18.****To Draft a Plain Tight Basque,**

First find the length of the skirt of basque, in proportion for the form drafted for, as follows:

Find the length up center of front on the cut from which the style is taken, then the length up center of front of the person to be fitted. If the first length is two inches, the second fourteen, by dividing fourteen by two the number seven will be obtained. The

quotient thus obtained serves as the means of finding the length of skirt of basque. If the length of skirt of basque on cut is one inch the length of basque skirt for lady will be seven times one inch, or seven inches long. The quotient, as in this case seven, being always used as the multiplier. After finding the length of front, side and back proceed to draft. Always commence with the center of back.

For the center of back in any garment with waist and skirt combined a one inch slope must be added to the skirt, at center of back, for the first nine inches in length, and one inch for every six below this number. As it was found by the example above, that the length of skirt should be seven inches, the slope in that case would be seven-ninths of an inch. After finding the slope necessary for the center of the back below the waist line, place the back of the guide in so far from the edge of the goods as the slope requires and draft as required by the style desired. After the center of back above the waist line is drafted, place a straight rule with the end resting on the back edge of waist line, and draw a line nine inches long, straight down; from the edge of this line measure out one inch and connect with the back end of waist line. Below this add one inch for slope of gores for every six in length. Next subtract the hip measure from the form measure, and the remainder will be the width of the back, four inches below the waist line. As the side form at the waist line is one inch wider than the center of the back so it must be one inch wider four inches below the waist line.

For example: If the hip measure is twenty-five and the form measure thirty-nine, the difference or width of the back will be fourteen, and one-half of fourteen which is seven will be the width of one-half of the back. As the side form must be one inch wider than the center back, subtract one inch from seven; and

one-half of the remainder six, will be three, the width of the center back. As the center of the back is three inches wide and the side form must be one inch wider, the side form will be four inches. On a line four inches below the waist line measure across from the center seam of the back, the width of the center back four inches below the waist line and connect this point with the side end of the waist line. From the last point, four inches below the waist line, measure down the length require and extend out one inch for every six in length. Allow one-half inch for seams.

In drafting the side form, draft the part above the waist line as for tight waist. Place the pointed end of the dart rule at the under arm seam at waist line and let the dart rule point rest perpendicular, as this line needs only the slope at top, which the dart rule gives, the remainder of the line being straight. At four inches below the waist line, measure straight across from the under arm seam, the width required for the side back, four inches below the waist line, connect this point with the back end of waist line and add one inch, for slope of gore, for every six inches in length. Thus is the back drafted.

In drafting the front, draft as for tight waists but leave the under arm dart until the hip measure has been drafted. Next measure on the hem line the length of the basque below the waist line. Measure on the waist line the distance the center of the first dart is in from the hem line, and from twelve inches down measure in the same distance and dot. Connect the sides of the dart with dots placed one-half inch on each side of the one denoting the length of dart. Never make darts more than fifteen or less than twelve inches on the slope will not be correct.

The back dart is drafted in the same manner. If the form be full curve the darts from the waist line, to give more room over the abdomen. From the hem line, four inches below the waist line, measure straight across one-half of the hip measure, plus the width of the front darts four inches below the waist line and the width of the under arm dart at the waist line. From the length of waist under the arm draw a line perpendicular to the waist line. If the distance between the last line and the end of the hip measure line is greater than two inches add the excess to the under arm seam and take out by means of the under arm dart the fullness, or largeness caused thereby. Place the dart rule point at the under arm seam at waistline, let the out side rest on the hip measure dot, and connect by a line drawn along its edge. Below the four inches add one inch, for slope of gore, for every six inches in length.

In drafting the under arm dart, if the belt measure is from eighteen to twenty-six inches, place the under arm dart in two inches from the under arm seam, and one-fourth of an inch farther in for every four inches more than twenty-six. Place the top of under arm dart as far in from the under arm seam as at the bottom of dart. Draw sides of under arm dart with the under arm seam of guide.

To extend the under arm dart into the skirt, draw a line from the center of the dart at waist line perpendicular to the waist line and the length required for basque. Place dots one-half inch on each side of this length and connect these to the sides of the dart by straight rule. Prove all parts before cutting; add one inch seam under the arm and one-half inch seam every place else.



---

**LESSON 19.****To Draft Half Fitting Basques.**

In drafting the back, find the slope of gore at center of back; draft the body as for half fitting waist, and add one inch for looseness to the whole of the back four inches below the waist line. For the front draft the body the same as for half fitting waist, and add one inch to half of the hip measure.

**LESSON 20.****To Draft Double Breasted Basques.**

Place the guide in as far as style may require; draft the darts tight or half fitting as the pattern calls for, and extend the darts into the skirt as for a plain basque.

**LESSON 21.****To Draft Diagonal Basques.**

Draft above the waist as for diagonal waist and extend the darts into the skirt as for plain basque.

**LESSON 22.****To Draft Plain Basques with Plaits in the Skirt.**

Find how wide the plait is to be at the center of the back, and how far from the waist line, and place the guide as far in from the fold of the goods as the gore and plaits require. This is for plaits without a seam in the back; if a seam is used the guide must be placed in as far as the plaits, gore and seam require. If made without a seam, the surplus width of the plaits at the top will be folded under by the plaits. After the guide is placed in proper position, draft as for plain basque and mark the plaits afterward. If plaits are desired at the side form, draft as for plain basque adding box or side plaits as may be desired.

**LESSON 23.****To Draft Draped Basques,**

Draft as for polonaise and use the short darts if draped high on the hips. There are often exceptions made as to the under arm dart in polonaise and draped basques, for where the drapery commences four inches from the waist line, the under arm dart may be from four to seven inches long, while the front darts may be from nine to twelve inches in length.

**LESSON 24.****Misses' and Childrens' Basques,**

Draft as for ladies' basques with the following exceptions: Run the darts from seven to twelve inches in length. Use but one front dart, and place it one and a half inch in from the hem line, at waist line. In finding the darts for misses' and childrens' it is best to have a loose bust measure. Never make a snug fitting waist for a growing child. To find the darts, subtract the belt from the bust measure; If the remainder is more than two inches, take one-fourth of it for the two under arm darts and divide the remainder of the fullness between the two front darts placing one on each side.

**LESSON 25.****To Draft Vest Fronts,**

Draft as for front of tight basque. Point off at the shoulder at the upper neck, as style may require. Draw a line from this point to the top of front dart, prolong the line along the front side of dart, and below the waist line point off the vest as the style of pattern may require. In cut-away coats and sacques, let the vest extend to the under arm dart or seam. Draft the front of cut-away coats or sacques as for half or two-thirds fitting basque and shape the front edge as the style of pattern may require. Slope the edge with the dart and side form rule.

**LESSON 26.****To Enlarge from Fashion Plate,**

Divide the length of the skirt to be drafted by the length of the skirt on the fashion plate; the quotient received then, used as a multiplier will enable the drafter to get the correct proportions to all trimmings and so forth; that is, multiply the breadth or length of trimming as they measure on the plate, by the quotient received, and the result will be the length or breadth, that the trimming should be drafted. Example: If the skirt on the plate measures five inches and the skirt to be drafted measures forty inches, divide forty by five, and the quotient eight will be the number by which to multiply to find the correct proportions of trimmings. If the drapery on the fashion plate is three inches long in the front in the draped position, then three multiplied by eight equals twenty-four the length of the drapery to be when draped. Thus this rule may be applied in all cases. When the full pattern is not on the plate but only a part, as for basque, divide the length up center of front of the person to be drafted for by the same measure on the pattern and use the result or quotient as directed above.

**LESSON 27.****Drapery Rule.**

Add two inches for an average plait, and more or less as the plait is desired. For gathers, find the length the gathers are to be when finished and multiply the length by two. All fullness for drapery should be measured straight down from the finished length. Thus if the finished length of gathers is eight inches, and sixteen would be taken up in the gathers.

**LESSON 28.****How to Determine How Much Goods are Required for Trim-  
mings &c,**

Select the pattern and take the lady's measure. Divide the width of the skirt by the width of goods and the quotient will give some idea as to the number of widths will be necessary. At the present time one width is generally used for the front; one for both sides and two for the back. Multiply the necessary number of breadths by the length of skirt and divide the result by thirty-six, the number of inches in a yard, and the result will be the number of yards required for the skirt. For plaiting and so forth, multiply the depth of the plaiting by the number of widths required. Treble plaitings of all kinds, and fine plaiting, require three times around the skirt. For over dresses find the finished length, add the drapery, multiply by the number of breadths of goods and divide by thirty-six. For basques, sacques and so forth, observe if one or two widths are required for the back or front or sleeve. Take the length of the front to the upper neck, add the longest length of the skirt part in front length of the back to upper neck, the longest length of skirt in the back and the length for sleeves.

For polonaise find the waist and sleeves as for basques and the drapery as for over dresses. For gathered ruffles find the depth and multiply by once and a half round the skirt. For shirred ruffles caught into plaits, multiply the depth by the number of breadths required to go around the skirt twice. In puffed

skirts add from one-half to two-thirds to the length. For bias bands, find the depth of the band and add one-half inch for every inch. For example: If a band four inches wide is desired, six inches of goods will have to be bought.

## LESSON 29.

### Rules for Darts in Polonaise.

Draft as for basques with the following exceptions: Extend the darts below the waist from seven to twelve inches and draw from the point to both sides. Draft the under arm dart the same as for basques, but make it three inches shorter than the front darts and draft to a point. Darts in ladies' basque must not be drafted less than twelve inches below the waist line. If the basque is less than twelve inches in length, draft the darts the full length (twelve inches) and then cut off the basque the desired length. For childrens' polonaise extend the darts into the skirt from four to nine inches.

### RULES FOR DARTS IN SKIRTS.

From eighteen to twenty-six inch belt measure, use one inch for each dart and add one-fourth inch for every four inches, add to belt measure. Place one dart in the center of each side of the front and extend all darts four inches in length. To place the dart in the side, measure on the side width from the front one inch more than half of the front width at the top, and place the dart half way between the front edge and this dot. For darts in over dresses follow the same rule.

**LESSON 30,****To Draft the Back of Polonaise.**

If there is to be a box plait at the center of the back, place the model and draft as for basque with box plaits. If the side form is to be gored to the center of the back without seams in the skirt, measure on the center of back as far down as it is desired that the seam should extend into the skirt. From this point measure straight across one inch more than the width of the center of the back. From this point measure straight up to waist line and curve with dart rule as for the basque. From the last point measure towards the back the width of side form at waist line. There place the dot for length of waist even with the bust measure at the under arm, and draft the side form. If a box plait should be desired at the side form, after drafting the center of the back find how far it is desired that the plait be from the waist line, and measure straight across from the back the width of the plait. To draft the side form follow the direction given above.

**LESSON 31.****To Draft the Back of Polonaise with Side Form, without Seams in the Skirt.**

In drafting the back, allow at the center from four to eight inches for box plait, and slope from the waist line to the box plait

from three to five inches. Draft according to rule in lesson 30. In drafting the side, measure the width required, allow for plaits at from three to five inches below the waist line. Fold the fullness underneath in single plaits.

### LESSON 32.

#### **To Draft Polonaise with Side Form and Front Joined.**

Draft the front as for plain waist but leave the under arm dart until the hip measure has been drafted. Extend the darts into the skirt from seven to twelve inches and draft to a point. Draft the hip measure the same as for plain basque. Draft the under arm dart the same as for plain basque, extend into the skirt three inches shorter than the front darts, but draft to a point the same as the front darts. After drafting the front reverse the guide and draft the side form and make the waist line of side even with waistline of front, Extend the under arm seam into the skirt in a dart not longer than the under arm dart. Shape the skirt as style may require.

### LESSON 33.

#### **Princes Polonaise.**

Back: Draft the center of back as for plain basque and slope the center back seam into the skirt as long as the pattern requires. To draft the side measure out from the extent of the slope at side of back one inch more than the width of the back at the same point.



From this point measure up the length to the waist line and slope with the dart rule. Place the length of the waist (on the guide) on this point and draft the side form. Draft the front as for a plain basque, and the darts according to the rule for darts in polonaise.

### LESSON 34.

#### Rule for Gathers.

In belt measures from eighteen to twenty-six, subtract four inches for belt measure; from twenty-six on, one inch for every four above twenty-six.

### LESSON 35.

#### To Draft a Four Gored Skirt.

Subtract the gathers from the belt measure, take one-half the remainder, subtract one and take one-half of this remainder for the width of one-half of the front at the top; to this add the dart and seam. Place the fold of the goods towards you and the bulk of goods at the right side. Measure straight across (at the top of goods) from the fold, the width of the front plus the dart and the seam. Measure down on the fold from one-half to one inch and curve with a curved rule the line connecting this point with the dot denoting the width at top. Measure along the fold of the goods the length required for the skirt plus one inch for seams and from this point measure out the width of the skirt at the top plus the width of gore. For average skirts of from thirty-six to forty inches in length use two inches for slope of gore; from nine to twenty-

six inches, one inch; and from twenty to thirty-six inches, one and a half inch. connect the last point to the point denoting the width at top. Draft the dart as for dart rule,

To draft the side gore, subtract the gathers from the form measure, take one half of the remainder: subtract the width of the front four inches down from the top and add for slope the same as for the front.

To draft the back subtract from one-half the desired width of skirt, the width of the side at the bottom plus one-half of the width of the whole front at the bottom and the remainder will be one-half the width of the back. Place a casing in the skirt for the elastic, four inches higher than one-half of the length of the skirt, and draft the casing one and a half inches wide.

## LESSON 36.

### To Draft Six Gored Skirts.

To draft the front, subtract the gathers as for four gored skirt and take one-sixth of the remainder for one-half of the width of the front at the top. Draft the rest of the front as for four gored skirt. To draft the two side gores, subtract the gathers from the form, measure from one-half of this, subtract one-half of the width of the front four inches down. One-half of the remainder will be the width of each of the two side widths at the top. Draft

as for front and place a dart in the center of each front side gore. To find the width of the back, subtract from the width of the skirt, the sum of the widths of the sides and front at bottom.

It is advisable to use a six gored skirt when the width at the bottom is more than two and a half yards.

## LESSON 37.

### Rule for Over Dresses.

Subtract the gathers from the form measure and take one-half of the remainder for the front, four inches below the belt. Measure from two to three inches down the center of front and curve to the side for the top. Place the darts as the rule for darts in over dresses requires. Draft the back width by the drapery rule. If it should have a diagonal front or panner sides, divide the front by the drapery rule.

## LESSON 38.

### Train Skirts.

Draft the front and sides as for four gored skirts and use a train gore and a straight or a fan back width as the style may require. To draft a train gore measure straight across the top from three to five inches, make the length at front equal to the length of side gore. Measure down from the top two-thirds of the length and add from one to three inches for slope of gore. Spring the gore out

from this point the length required for the train. The longer the train the straighter out the line will be from the gore. Form the bottom with the curved edge of the skirt rule and draft the spring with the same rule. The back width is curved with the curved edge of the skirt rule. The square train gore is drafted the same as for round train, with the exception that the length required to lay on the floor is added to the front side. For an adjustable train draft on paper and cut off at the length at which it is desired that the train should be buttoned on to the skirt.

## LESSON 39,

### Dolmans.

As there are so many varied styles and it would be impossible to give all, only the standard style will be given.

Take the measure as for any out side wrap, with the following measures added: From the front cord of the arm passing loosely over the arm to the center of the back between the shoulder blades. With the hand resting at the waist line in front, measure from the out side joint at wrist, over the elbow to the center of back at waist line. The back is drafted as style requires, but usually the English side forms are used so at any time it may be made into a sacque by putting in sacque sleeves. If only a dolman should be desired, cut the back at the shoulder from one to one and a half inches short and slope to the side form. Add when drafting, from one to one and a half inches to the waist line and to the width of the back four inches below the waist line for fullness.

The side form is drafted from the shoulder, the top being the width which is taken from the shoulder at center of back. The side form at the waist line is often the same width as the center of back. The front is drafted loose but an under arm dart is always used to do away with too much fullness. The side form may be drafted in the same piece with the front and the under arm seam extended into the skirt in a dart. To draft the side and front in one, reverse the guide to draft the side form.

To draft the sleeve, draft first on paper the top of a sleeve to fit the form. Spring a gore from the elbow to the wrist from three to six inches. Draft the width of the back according to the measure taken across the back. Subtract this from the measure taken from the cord of the arm to the center of the back and measure from the front the remainder, or the required width. Measure down from the top of the arm, down even with the waist line. To find the measure, measure the height of the shoulder from the waist line, first subtracting the measure of the center of the back at the waist line, from the measure required. Shape at the back to fit the curves of the center of the back, and shape the bottom of sleeve with curved or straight rule according to the drapery rule.

## LESSON 40.

### Lady's and Child's Chemise,

Placing the fold of the cloth towards you, draft the waist without laps. To draft the yoke measure three inches down from the neck on the fold of the goods; measure from two to three inches up from the shoulder point; curve to form the upper part of yoke, and

point off the lower part as the pattern may require. The body of the chemise is drafted by placing the yoke on the fold of the cloth and extend the line out from the yoke from three to six inches for gathers. Set the sleeve in the body for a distance of two-thirds the length of the waist under the arm. Set in plain the length of gusset; slope the skirt by adding for gore, one inch for every six in length.

For puffed sleeves draft a piece of cloth two inches wider than the sleeves are to be when finished and from seven to nine inches longer than the measure of the arm size. Slope the ends to form the gusset and curve the upper part from one to two inches. Make the band from one to two inches less than the arm size.

## LESSON 41.

### Chemise Drawers.

Take the measure as for waist with the following additions: The length down the side from the waist line to the ankle bone, the length required when finished, and the measure around the leg just below the knee. To draft, place the front edge of the front part of guide, in from three to five inches from the edge of the cloth and draft as for half fitting waist.

From the front of waist line, draft a perpendicular line extending downward one-third the length down the side, plus three inches. From this point measure out from three to five inches to the edge of the goods and connect these two points by a straight rule. If open in the back take the lap from the front and add to the back.

Join the side form or back so the front by reversing the guide and placing it so the waist line will be on a line with the waist line of the front, letting the slope for the side form be but one inch towards the front and running the under arm seam into a dart equal in length to the under arm dart.

Draft the center of back separate and with the skirt four inches in length, if the garment is to be open in front; if open in the back the center of back and side forms should have a skirt length as for basque. From a point three inches below the front end of the waist line, measure straight down one-third the length down the side. From this point draw a line parallel with the waist line, equal in length to one-half the form measure plus from three to five inches for fullness. This is called the seat line. Connect the seat line by a perpendicular line to the waist line. Measure four inches down on the line connecting the seat line and the waist line, (or if open in the back, measure as far down on the line connecting the seat line and waist line as you wish the plaket opening to be). From this point measure out twice the width of the center of the back at the length required. From three inches above this point draw a line to the seat line and another to the point for length of skirt or opening, thus causing a sloping line for the top of this fullness, which is taken up in gathers to fit the back.

#### TO DRAFT THE LOWER PART.

If for garter panties, measure from the length at the side, one-half of the garter measure, plus from three to eight inches for gathers. Connect the lower part to the seat line by placing the curved edge to the skirt rule at the seat line and draft to the bottom points. If you desire them shorter, cut off above the line drafted at bottom but always draft to the ankle bone so that the point for seat

line may be found. Draft the neck as for chemise. Use one or two darts according to the desire of looseness, and extend them into the skirt as for polonaise.

## LESSON 42.

### Ladies' and Childrens' Drawers.

Take the following measures: Around the waist, form measure, length of the waist line down to the ankle bone and around the garter. To draft, measure straight across the top of the goods, one-fourth of the belt measure, plus from three to six inches for fullness and dot. Measure three inches down on the fold for slope of top and connect with the side at top. Measure down from the three inch dot, the length required for the side to the ankle bone and dot. From the last dot, measure straight across one-half the garter measure, plus from three to eight inches and dot. Measure from a point three inches below the three inch dot made at the top of the fold, two-thirds the length down the side to find the basis of the seat. From this point, measure straight across one-half of the form measure plus from three to eight inches for fullness. This is called the seat line. Connect the seat and waist line by a straight rule, and the seat line and bottom by placing the curved edge of the skirt rule on the seat line the straight or narrow end resting on the garter measure.

## LESSON 43.

### Night Dresses and Wrappers.

Draft as for loose or half fitting basque, with or without yoke and add for gore one inch for every six in length.



**LESSON 44.****Gents' and Boys' Long Pants.**

The following measures used; Belt measure, form measure, the length down the side to the heel, around the the instep as loose as style may require. To draft the front part, measure in one inch from the edge and slope down four inches for pocket gore. From this one inch point measure one-fourth the waist measure across to a point one inch below the top of goods. Measure down the side the length of the side to the heel, To draft the basis of the seat, measure down the side from a point three inches below the waist line, one-third the length down the side to the heel. From this point measure straight across one-fourth of the waist line plus two or three inches and draw a line. This is called the seat line. To draft the fly, draw a line parallel to the side measure from the back end of waist line, to the one-fourth of the form measure on the seat line. From a point on this line as far above the seat line as that line extends beyond the point where the last drawn line meets it, draw a line curved downwards to the end of seat line. To get the width at the bottom, subtract from two to three inches from the width as the back must be from two to three inches wider than the front. Take one-half the remainder for the bottom of front. Curve out from one-fourth to one-half inch at the center and slope towards the sides so as to fit over the instep. To draft the inside line place the curved edge of the skirt rule on the seat line and the small end resting on the bottom.

**BACK PART.**

Measure from two to three inches down from the top on the edge of goods to form the slope. Take one-fourth of the belt measure add from two to three inches for the width across the top.

Place the dart in the center of piece drafted and extend it to a point four inches below the waist line. To find the basis of the seat draft as for front. To find the width of the seat, take one-half of the form measure, subtract the width of the front four inches below the waist line and add from three to five inches for fullness. Outline the same as the front, the bottom being from two to three inches wider than the front and curved downwards. The waist band should be one and a half inches wide at the front and two and a half at the back. The back seam is left open from two to three inches for straps and turned in or sloped off on each side. The waist band being cut the actual size, the sloping in the back allows for laps. Draft the pockets from eight to twelve inches in length and from seven to nine in width.

### LESSON 45.

#### Boys' Short Pants.

Draft as for long pants with the following exceptions. As the width at the bottom will be too wide when cut off at the required length, measure from a point, on the inside seam, denoting the required length; across one-half the width they should be.

### LESSON 46.

#### Gents' and Boy's Drawers.

Measure as for long pants, and in drafting place the fold of goods toward you. Measure down three inches and draft as for back of pants, except at the bottom. Let the front and back each be equal to one-half the width around the ankle; this forms the back. Turn the goods over and draft the front as for front of pants.

## LESSON 47.

## Sack Shirts.--Back.

Neck measure one-half inch less than collar worn. All other measures are taken as for ladies' waists.

Draft as for the front of plain waist without darts, only the front of guide is used in drafting shirts. Make a dot two inches above the front neck dot; shape the back neck by the neck of the guide held in a reverse position, that is with the right side or face of the guide down. Draw a line from this dot to the upper neck dot. Dot two inches from the edge of the goods on the curve of the back neck. Make a dot three-fourths of an inch below the shoulder; dot three-fourths of an inch below the three-fourths inch dot at the arm-size; dot two inches below the two inch dot at the back of neck curve. Draw a line connecting these two dots, thus forming the yoke seam. Fold the goods over on the last drawn line, so that the shoulder edge of the yoke will meet at the line drawn from the two inch dot on the curve of the neck to the three-fourths inch dot below the end of the shoulder. This forms the yoke seam. The back arm-size is shaped with the side form rule. Measure down one inch from the arm point on the under arm line. Place the under edge of the side rule at this dot and resting on the end of the shoulder line. The front and back of the skirt is drafted the same. The curve and length of the skirt are obtained by the skirt rule, the corners being rounded by the side form rule.

For a separate yoke with a full body in the back, draft as for sack shirt with the following exceptions: Extend the shoulder part of the body at the end of the yoke from three to five inches. From

a new arm-size by adding at the arm point the same number of inches as has been added to the yoke. The fullness must be gathered in the yoke.

For front draft, as for front of plain waist without laps and make the waist line equal to one-fourth of the belt measure; draw the under arm seam to this point. Measure one and a half inches down from the neck dot. Draw a line from this dot to a dot one and a half inch from the length of the shoulder on the arm-size, the yoke being folded over the curve for front neck is shaped by the neck of the guide being placed in such a position as to unite and form a continuous line with the curve of the yoke at the back neck. To reshape the front arm-size cut off one inch from the arm point and shape with the side form rule. Shape the under arm seam with the curved edge of dart rule by placing the pointed edge of the rule at the arm point and the bottom edge resting on the waist line in such a position as to take out the extra fullness caused by the darts. The front and back skirts are drafted the same.

## LESSON 48.

### Gent's Dressing Gown.

Measure the same as for loose basque. Draft as for loose basque, using but the under arm dart and extending it into the skirt as for polonaise. Draft the skirt but from one to three inches wider at the bottom than four inches below the waist line. From one inch below the upper neck on the length of shoulder slope the front to a point eight inches below the neck. This line should be cut off for a rolling collar; if for a revere collar fold back even with these lines. The collar should be curved to fit the neck and joined in the back by a sloping seam.

The back is usually cut on the fold of the goods; if a seam is preferred in the back, use only one inch for slope of gore for the entire length and at the front side of the back below the four inches add only from one to three inches for slope of gore the entire length.

## LESSON 49.

### Coat Sleeve.

Draft a plain sleeve as far from the edge of the cloth as the hollow of the arm size or chest measure dot is from the under arm seam, and measure from the inside of the sleeve the same distance out, top and bottom and draw a line. This will be the under seam of the sleeve. Add to the out side edge, at top one inch, at bottom one-half inch and one-half inch seams all around. For the under part, draft first a plain sleeve with the sleeve guide, and curving out by reversing the curve of guide. Subtract from the inside edge as much as has been added to the top and the same at the out side edge. Add one-half inch seams all around. In putting the sleeve into the arm size place the under seam to the seam of the under arm dart. First sew the out side of the sleeve in and then hem the lining over to cover the seams.

**FINIS.**

# INDEX.

PAGE.

- 10. Back, with the English Side Form.
- 11. Back, with the French Side Form.
- 23. Basque, Diagonal.
- 23. Basque, Double Breasted.
- 24. Basque, Draped
- 23. Basque, Half Fitting.
- 25. Basque, Misses' and Childrens'
- 10. Basque, Plain Tight.
- 24. Basque, Plain with Plaits in the Skirt.
- 25. Basque, Vest Front
- 35. Chemise, Ladies and Children's.
- 43. Coat Sleeve.
- 34. Dolmans.
- 36. Drawers, Chemise.
- 40. Drawers, Gent's and Boy's.
- 35. Drawers, Ladies' and Childrens'
- 42. Dressing Gown for Gentlemen.
- 26. Fashion Plate to Enlarge from.
- 27. Goods, how to determine how much is required for Trimmings, &c.
- 4. Measure, Manner and Order of Taking.
- 33. Overdresses.
- 40. Pants, Boy's Short Pants.
- 30. Pants, Gent's and Boy's Long Pants.
- 29. Polonaise, Back.
- 29. Polonaise, Back with Side Forms and without seams in the Skirt.
- 30. Polonaise, Princes.
- 28. Polonaise, Rule for Darts.
- 30. Polonaise, with Side Form and Front joined.
- 26. Rule, Drapery.
- 31. Rule, Gathers.
- 41. Sack Shirts.
- 31. Skirt, Four Gored.
- 32. Skirt, Six Gored.
- 33. Skirt, Train.
- 16. Waist, Back.
- 18. Waist, Diagonal.
- 18. Waist, Double Breasted.
- 15. Waist, Front of Loose Waist.
- 12. Waist, Front of Plain Tight
- 17. Waist, Half Fitting.
- 19. Waist, Low Neck.
- 17. Waist, Plain, open in the Back.
- 18. Waist, Plaited.
- 19. Waist, Surplus.
- 9. Waist, Tight. Back without Side Forms.
- 16. Waist, Yoke, Gathered Body.
- 16. Waist, Yoke, Pleated Body.



LIBRARY OF CONGRESS



0 014 062 702 1