

**10" TABLESAW BLADES**

See the best in our test *See page 62*

Better Homes and Gardens

# WOOD<sup>®</sup>

THE WORLD'S LEADING WOODWORKING MAGAZINE

ISSUE 121 FEBRUARY 2000

*Make this heirloom*

## ROCKING CHAIR

*Our jigs guarantee your success*

*See page 53*

## More Great Projects!

- Mission nesting tables
- Portable cold frame
- Bandsawn keepsake box
- Drill-press angle jig

Display until February 1

U.S.A. \$5.95



02>

<http://www.woodmagazine.com>

Better Homes and Gardens®  
**WOOD**

THE WORLD'S LEADING WOODWORKING MAGAZINE

**CONTENTS**



Page 62



Page 50

**37 Forests for the future**

Learn how foresters grow bigger and better trees, as well as how to size a tree for board feet yield.

**41 Crafted in Carolina**

When someone buys a Philip Greene canoe, he does so to own a boat...as well as a work of art.

**62 10" saw blades**

Get the lowdown on price and performance as we put 37 multipurpose models to the test.

**68 From blocks to bandsawn boxes**

Let pro Jerry Patrasso teach you the simple steps for making four clever containers.

**76 The signs of the times**

These carved, painted figures advertised products and businesses in our not-too-distant past.

**46 Nesting knockouts**

Build a trio of Mission oak tables that fit within each other and add to your home's decor.

**50 Portable plant protection**

This spring, protect young plants with this easy-to-store folding cold frame.

**53 Rocker of the ages**

Make an heirloom chair for generations to enjoy using our jigs and free mail-order patterns.

**60 A drill-press jig with all the angles**

Use this handy shop project with our rocking chair plans or for any compound-drilling tasks.

**74 A keepsake box worth keeping**

Provide a handsome home for jewelry or other small valuables with this bandsawn beauty.



Page 53



Page 46



Page 74

**SHORT-SUBJECT FEATURES**

**4** The Editor's Angle

**6** Talking Back

**10** How To Scoop A Chair Seat

**16** How To Remove Heat And Water Marks

**18** Hot Off The Internet

**22** Ask WOOD

**24** Tips From Your Shop (And Ours)

**80** Products That Perform

**102** Wood Anecdote: Black Willow

**104** Finishing Touches

# My First Experience as a Chairmaker

It doesn't happen often. But I was mesmerized immediately by that charming child's rocking chair I spotted at Remember When Antiques, a dimly lit shop on Bay Street in Savannah, Georgia, more than two years ago. And I knew that we just had to do something with it. That something is on the cover of this issue.

The road leading to what now is a full-sized rocking chair has been a long, winding one. But I think you'll agree that we've created something beautiful here. And you can, too.

For better or worse, in my zeal, I volunteered to build the chair. And to make absolutely sure this project came out just right, I engaged the assistance of Jim Downing, *WOOD* magazine's Senior Design Editor. As it turned out, determining the angle at which to drill all of the spindle



**You wouldn't think a guy like me could fit into the child's rocker we used as the inspiration for our rocker design, would you? Guess what? I didn't even get stuck.**

holes was the most challenging part of the project. It took three full-sized models to finally settle on the perfect angles.

With that out of the way, we needed a sure-fire way to drill the holes accurately. To do this, Jim came up with the perfect solution: an angle-drilling jig for your drill press. You will find it explained on page 60. Finding good-quality walnut

was difficult, too. I'll bet I looked through 300 or more boards to find the ones I wanted to use. We've lined up a source if you have trouble finding what you need. And for those of you who don't have a lathe, or just don't feel like turning the 13 spindles needed, we've provided a mail-order source for those parts as well.

Now that we've completed this wonderful-looking project, Jim and I think it was well worth the time and effort everyone put in on it. And do you know the best part? I can honestly say that if you work carefully, you won't have any trouble constructing this beauty.

By the way, I'd like to see a snapshot of your handiwork after you get done with your rocker. If you share that with me, I'll send you a brass plate bearing the inscription "A custom-built *WOOD* magazine Family-Heirloom project" as a reward for your dedication. That will be free of charge, of course. Send your snapshot to I Built a Rocker, *WOOD* magazine, 1716 Locust, GA310, Des Moines, IA 50309-3023.

Happy building! 🪵

*Larry Clayton*



Jim Downing verifies the hole angles for the seat-back spindles and back splats. With this project, angles are everything.

Better Homes and Gardens®

# WOOD®

THE WORLD'S LEADING WOODWORKING MAGAZINE

FEBRUARY 2000 • Vol. 17, No. 1 • Issue No. 121

Editor **LARRY CLAYTON**

Managing Editor **JIM HARROLD**

Assistant Managing Editor/Products **BILL KRIER**

Senior Editor/Features **PETER J. STEPHANO**

Senior Editor/Special-Interest **LARRY JOHNSTON**

General-Interest Editor **DAVE CAMPBELL**

Senior Design Editor **JAMES R. DOWNING**

Assistant Design Editor/Project Builder **JAN HALE SVEC**

Shop Manager/Project Designer **CHARLES I. HEDLUND**

Senior Associate Art Director **PERRY A. MCFARLIN**

Assistant Art Director **CHERYL A. CIBULA**

Production/Office Manager **MARGARET CLOSNER**

Administrative Assistant **SHERYL MUNYON**

Art Business Office Secretary **BARBARA HELPS**

Reader-Contact Specialist **BEN VON RUDEN**

Contributing Editors **KIM DOWNING, DAVE HENDERSON,**

**LORNA JOHNSON, ROXANNE LEMOINE,**

**BOB MCFARLIN, CARSON ODE**

©Copyright Meredith Corporation 2000  
All rights reserved. Printed in the U.S.A.

*Better Homes and Gardens® WOOD®* magazine (ISSN-0743-894X) is published nine times a year in January, February, March, April, June, August, October, November, and December by Meredith Corporation, 1716 Locust St., Des Moines, IA 50309-3023. Periodicals postage paid at Des Moines, Iowa, and additional mailing offices. *Better Homes and Gardens* trademark registered in Canada and Australia. Marca Registrada en México. **ONE-YEAR SUBSCRIPTION PRICES:** U.S. and its possessions, \$27; Canada, \$39; other countries, \$47. Canada Post Publications Mail Sales Product Agreement No. 1369350. Canadian BN 12348 2887RT. **CANADIAN RETURN ADDRESS:** *Better Homes and Gardens WOOD* magazine, 2744 Edna Street, Windsor, Ontario, N8Y 1V2. **POSTMASTER:** Send address changes to *Better Homes and Gardens WOOD* magazine, P.O. Box 37439, Boone, IA 50037-0439.

**CUSTOMER SERVICE 800/374-9663:** Use this number for subscription services, changes of address, billing questions, questions for our editorial staff, questions about how to reach an advertiser, or to place an advertisement in our magazine. **To order back issues 800/346-9663. Subscription mailing address:** *Better Homes and Gardens WOOD* magazine, P.O. Box 37439, Boone, IA 50037-0439. Please enclose your address label from a recent issue. **Editorial mailing address:** The Editor, *WOOD* magazine, 1716 Locust Street, GA310, Des Moines, IA 50309-3023. Reprints are \$5 per article.

**MPA**


Better Homes and Gardens®

## WOOD Online®

at <http://www.woodmagazine.com>

A good, solid workbench is essential to maximum enjoyment of your time in the shop. Whether you're setting up your first shop or wanting to add more benchtop space to your existing one, you can't beat our Workhorse Workbench. Download the plans from **WOOD ONLINE** today for only \$5.95. It's plan DP-00065 in the downloadable plans section of project plans.





## SOLID 3" x 3" SQUARES

Available in (3) Lengths  
17" • 22" • 30"

Surfaced Hit or Miss  
to 2 15/16" Square

Kiln Dried to 6-8%

### FREE CATALOGUE



Adams Wood Products™ L.T.D., L.P.  
974 Forest Drive Morristown, TN 37814  
Factory/Office 5436 Jeffery Lane, Dept. M42  
Phone 423-587-2942 • Fax 423-586-2188  
www.adamswoodproducts.com

Circle No. 1002


## TALKING BACK

### Neat, clean holes with sharpened brass tubing

In issue #116's "ASK WOOD," a reader wanted tips on drilling holes in model aircraft built of balsa wood. For my decoy carvings that need eye holes, I simply buy a short length of brass tubing in the appropriate diameter at a hobby store. Then, I fasten it

to a dowel handle with a brass pin and sharpen the protruding end—the cutting edge—with emery cloth. Thin-wall tubing sharpened to a razor edge like this will cut neat eye holes with no crushed fibers. But, remember to rotate the cutter as you push it in.

—W. H. Brown, Niagara-on-the-lake, Ont.



### For long-lasting brushes, oil them up

Regarding the advice about keeping your natural-bristle brushes soft, as mentioned in issue #117's "ASK WOOD," I have been a sign painter for the better part of 50 years, and learned long ago how to preserve my \$25 to \$50 brushes after use with oil-based paint or finish.

I rinse off excess paint, shake out excess thinner, then swish the brush in lard oil or a heavy mineral oil. With my fingers, I smooth out the bristles, and store the brush in a brush box or drawer. Before I use the brush again, I rinse it out with paint thinner.


—Jack Ekker, Marysville, Utah

### Don't plug in turned-on tools

In "Where Safety Begins" in issue #115, the author states that you can check to see if you have magnetic switches by turning on woodworking machines, unplugging them, then plugging them back in. But you should never unplug a machine when it's running. And you should never plug in any electrical tool or appliance while its switch is on. Doing so may cause an electrical arc that can be potentially lethal, unless the machine really does have a magnetic switch.

—Steve Aga, Colorado Springs, Colo.

Thanks for making your point, Steve. "Where Safety Begins" is written by safety expert Mike Gililand,



who basically agrees with you. However, the part of the article you mention was from a woodworking professional's contribution to the WOOD ONLINE® discussion group, and was not included in Mike's original copy. It should have been checked out. 🍀

### We would like to hear from you

We welcome your comments, criticisms, suggestions, and yes, even compliments. We'll publish letters of the greatest benefit to our readers. Write to: Talking Back, WOOD Magazine, 1716 Locust St., GA310, Des Moines, IA 50309-3023

Better Homes and Gardens®

**WOOD** Advertising & Marketing

THE WORLD'S LEADING WOODWORKING MAGAZINE

Publisher WILLIAM R. REED

Associate Publisher MARK HAGEN

Ancillary Sales and Internet Manager MARLEN KEMMET

Advertising Services Manager PAT HENDERSHOTT

Chicago Advertising Office: 333 N. Michigan Ave., Suite 1101, Chicago, IL 60601 Phone: 312/853-2890 FAX: 312/580-7906

Advertising Managers JAMES N. FORD, WILL MURPHY

Direct Response Advertising CAROLYN DAKIS

Marketing Specialist GERALDIE LEGASPI

Sales Assistant MARGARET TRAVIS

Des Moines Advertising Office: 1716 Locust St., GA204, Des Moines, IA 50309-3023 Phone: 515/284-3575 FAX: 515/284-3343

Senior Salesperson RICH RAINFORTH

Direct Response Advertising NATASHA KUCHERENKO

Administrative Assistant KRISTI HASEK

Classified Advertising: Phone: 800/424-3090 FAX: 312/464-0512

Publishing Director JERRY WARD

Circulation Director LIZ BREDESON

Associate Circulation Director KATHI PRIEN

Business Manager JANET DONNELLY

Senior Product Manager RICK GROW

#### MEREDITH PUBLISHING GROUP

CHRISTOPHER M. LITTLE, President

ELLEN de LATHOUDER, Creative Services;

BRUCE HESTON, Manufacturing; KARLA JEFFRIES, Controller;

JERRY KAPLAN, Group Sales; BOB MATE, Integrated Marketing;

BILL MURPHY, Strategic Marketing; HAL ORINGER, Consumer

Marketing; DEAN PIETERS, Operations; MAX RUNCIMAN,

Finance; THOMAS L. SLAUGHTER, Licensing and New Media



WILLIAM T. KERR, President and Chief Executive Officer

E. T. MEREDITH III, Chairman of the Executive Committee



# Here's The Scoop On ROUTING A CHAIR SEAT

This router jig makes scooped seats simple

A seat scooped out of a solid plank, a defining feature of the Windsor chair, first appeared more than 250 years ago. Hollowing out the seat then was a job for an adze and inshave. You can still form a seat that way today—and many chairmakers do.

But when we built the rocking chair on *page 53*, we decided to take a modern approach by routing the seat. Here's how to build and use our jig, shown in the photo at *right*, to make a scooped-out seat for your rocker—or any other chair constructed in the Windsor manner.



## Build a simple router jig to start

Refer to the Seat Routing Jig drawing, *below right*, and the Guide Rail Full-Size Pattern in the *WOOD PATTERNS®* insert. Then cut the parts for the routing jig to size.

Temporarily laminate blanks for the two guide rails (A) with double-faced tape, and apply the Full-Size Guide Rail Pattern to the stack. Bandsaw the curve, taking care to make a smooth, continuous arc. Sand the curved edge, and separate the parts.

Assemble the jig, referring to the Seat Routing Jig drawing. First join the two guide rails (A) with the spacers (B). Then fasten the sides (C) to the clamping wings (D). Finally, attach the C/D assemblies to the A/B assembly. On the top edge of one side, draw an arrow pointing toward the end of the guide rail that curves up to a point. (You can see the arrow on the jig in the photo *above right*.) Coat the curved edges with wax.

Mount a 1/4x6x6" auxiliary base on your router, and install a 3/4" straight bit. (We opted for one with a 1/2" shank to stand up to the heavy cutting.) Adjust the bit to extend 1 1/32" below the base.



*Continued on page 14*

Continued from page 10

## ROUTING A CHAIR SEAT

Clamp the jig to a piece of scrap-wood (we used a 2' length of 2x8), with the arrow pointing to your right. Then, place the router at the left end of the jig, turn it on, and make a full pass in the direction of the arrow. Turn off the router, and lift it from the jig. The bit will cut a ramp in the spacer block at the left end of the jig. You'll use this sloped slot to align the jig when shaping the seat.

### Now, rout the scoop-out

Photocopy the Full-Size Seat Pattern, found in the chair patterns package. (See page 53 for information on ordering the chair plans.) Trace the outline for the scooped-out area onto a piece of 1/4"-thick plywood or hardboard that's the same size as your seat blank. At the front of the seat, trace along the outward-flaring dotted lines rather than the solid line. Draw a centerline from front to back. Set the plywood aside for later use. If you haven't already adhered the pattern to the top of the seat blank, do so now, using spray adhesive.

Clamp the seat blank to your workbench. Place the jig on the blank, aligning the corners of the jig's exit ramp along the solid pattern line on the right side of the seat. (The photo bottom left shows the alignment

points at a later stage of the routing.) Slide the jig straight toward the front edge of the blank so about 2/3 of the ramp's width lies over the blank, and clamp it in place. Be sure the clamps won't interfere with router movement in the guide rails.

Then place the router at the end of the jig that's toward the center of the seat. Turn it on, and slide it along the curve in the guide rails. As you exit the cut, turn off the router; then lift it from the jig. Don't lift the router out of the jig before turning it off, and don't try to go back through the cut in the other direction.


Unclamp the jig, and move it to make the next cut. Again, align the corners of the exit ramp with the pattern line, and position the jig so you'll be cutting with about two-thirds of the bit's width. Start the router, make another pass as before, and shut off the router after the bit exits the work. Periodically recheck the router-bit protrusion distance and ensure that the collet is tight.

Continue moving the jig around the blank counterclockwise, always moving the router in the direction of the arrow, as shown in the *opening photo*. We made 74 passes when we routed our chair's seat.


### Sand the seat for smooth sitting

Now, cut two sanding templates from the sheet material you traced the pattern onto earlier. To make template 1, bandsaw along the seat-recess outline, making a smooth, flowing curve. For template 2, saw the cut-out piece into two parts just to one side of the line. Save the part with the line on it to use as template 2.

Attach template 1 to the seat blank, ensuring that the opening coincides with the edge of the area to be routed. (We fastened the template in position with screws driven into waste areas.) Then, with a random-orbit sander and 100-grit abrasive, sand from the lowest point in the seat to the edge. Fair the flared front edge into the seat. Bring the sanding disc right up to the



Sand the routed hollow with a random-orbit sander. Bring the disc right up to the plywood template, which is fastened to the blank with screws or brads driven into waste areas around the outside.



Clamp the centerline template in place, and sand right up to its edge. Flip the template, and clamp it into the other side of the seat to complete the ridge.

template, as shown in the *top photo*. Do not sand down the peaked area at the center front of the seat. Repeat sanding with 120- and 150-grit paper.

After sanding to the edge all around, clamp template 2 in position, as shown in the photo *above*. Sand from the low point to the straight edge of the template to establish the center ridge at the front of the seat, using progressively finer grits as you did with the edge. Flip the template, move it to the other side of the seat, and sand the other side of the ridge.

Remove the templates, and complete the seat as explained in the main rocking chair article. ♣

Photographs: Hetherington Photography  
Illustration: Roxanne LeMoine; Lorna Johnson



As you move the jig around the seat, align both corners of the exit ramp along the pattern line, as indicated by the arrows. Place the jig so you cut with about two-thirds of the bit's width.

# Anyone care for a Ring Remover?

Water and heat rings on tabletops and other surfaces rank high on the list of common finish faults. Here are some tricks that just might make them go away.



Take your pick of tricks for clearing up white marks, such as the blemishes at the front of the serving tray.

"There are no guarantees when it comes to removing water and heat rings," according to furniture repair and finishing ace Jim Kull. "Some methods for getting rid of white marks are potentially damaging to the finish," Jim says. "And ultimately, all efforts may fail, leaving stripping and refinishing—or living with the marks—as your only options."

But if you're game, it might pay to try some of these tricks before you resort to refinishing.

## Let's see what you have there

Start by assessing the damage. "A simple repair may be possible for finish discoloration, damage that doesn't penetrate the wood," Jim says.

### The mark itself will tell you a lot

- ✓ A white mark signifies damage to the finish only.
- ✓ A darker mark denotes damage that's gone through to the wood.

### Check the surface, too

- ✓ An unmarred surface over the mark generally indicates damage caused by moisture.
- ✓ A slight indentation over the area usually points to heat damage.

### Play it cool with heat marks

"Often your only solution for heat marks is to strip and refinish the surface," Jim says. Even so, you may be able to clear heat marks in shellac or lacquer finishes. Here's how to determine whether the finish you're dealing with is lacquer or shellac.

- ✓ Dab a little denatured alcohol on the finish in a hidden spot. If the finish softens, it's shellac.
- ✓ If it doesn't soften, try the same thing with lacquer thinner. If the finish softens now, it is lacquer.

✓ If neither has an effect, you're contending with some other finish.

### Shellac or lacquer tricks

Clean the area thoroughly with paint thinner. Then, wash it with a mild soap, such as Murphy's Oil Soap. Wipe it down again with paint thinner, and let it dry.

Wet the finish directly over the mark with alcohol (for a shellac finish) or lacquer thinner (for a lacquer finish). "It's best to spray it on," Jim says, "but you could brush on a wet coat and leave it. Don't rub it." The solvent dissolves the finish, which will then reflow as it dries, maybe erasing the mark. "This may not work," Jim cautions, "but it's worth the effort."

### Try buffing for other finishes

"Buffing is my least favorite approach; it rarely works for me," Jim warns. "And you can easily polish right through a thin finish." If you buff, apply a fine-grit automotive polishing compound with a high-speed buffer and a lamb's wool pad.

### Now let's dive into water marks

Jim reports mixed results with commercial white-ring removers. The Jasco ring-remover cloth shown below (from Restoration Hardware,



Rubbing with this chemically treated cloth minimizes the white mark.

800/816-0901) renders most rings less visible. An almond stick works in many cases, too. With either, the rings may reappear after time.

### Go for the grease

An easy fix to try is to smear mayonnaise, petroleum jelly, or shortening on the mark. (Jim likes mayo on his furniture because it's easier to clean up.) Slather it on generously, and leave it overnight. The idea is to let oil seep in to clear the mark.

"If that didn't quite do the trick, try again," Jim counsels. "If another application doesn't get it all, you need to try something else."

### Beyond sandwich spread

That something else would be wiping gently with denatured alcohol. "But be careful," Jim cautions. "Alcohol will dissolve shellac, mess up a lacquer finish, and damage some water-base finishes."

For this procedure, fold cheesecloth or cotton fabric into a pad, and dampen it with alcohol. It should be thoroughly damp, but not wet.

"Then," Jim explains, "gently, gently, gently wipe the pad over the ring area. Swing your arm, brushing the pad across the mark much like an airplane landing and taking off, with the landing being very soft. Don't rub," he says. "A slight haze should appear; this is the alcohol evaporating and, we hope, taking the subsurface moisture with it."

If that doesn't happen, you could try the same tactic again, but using lacquer thinner. "This technique, which is best left to pros, could totally destroy the finish," Jim warns. But by this point, you may have become resigned to refinishing, anyhow. ♣

Written by Larry Johnston with Jim Kull  
Photographs: Hetherington Photography

## WOODWORKERS TO THE RESCUE

Comments, answers, and ideas from our **WOOD ONLINE®** discussion groups

**Note:** If you would like more information on the woodworking-related subjects featured here, visit our **WOOD ONLINE** discussion groups at [www.woodmagazine.com](http://www.woodmagazine.com).

We have edited all entries in the interest of brevity and clarity while preserving the message. In addition, we have included our response to some questions.

### Looking for advice on fastening composite materials

*Does anyone out there have an opinion on what glues and screws work best with medium-density fiberboard (MDF)? I know that it wants to split out with tapered screws, but I understand that there are several thread designs available that might do the trick.*

—Roy Freeman, Seward, Alaska

● I have had good fortune with screws from McFeely's (800/443-7937) made for composite materials like MDF, particleboard, and the like.

—Rick Van Schoick, West Chester, Pa.

● I have been a cabinet builder for 17 years and have used MDF for the last 10. The material will work fine with yellow glue and nails. A dado joint is better than dowels or biscuits in MDF.

—Darrell Strickland, England, Ark.

● Roy, we posed your question to Jim Ray of McFeely's, and he confirmed that his company sells a line of screws (with part nos. ending in "FXT") that work well with composite materials, such as MDF and particleboard. These screws have auger tips, which help the screw evacuate material, and nibs on the underside of their bugle heads that carve out some countersink material. They also have wide (coarse) threads for distributing the fastener load.

Still, Jim cautions that even with these screws you should pre-drill and countersink any fasteners placed near the edge of composite materials. Otherwise, the wood particles simply will crumble around the fastener.


—WOOD® Magazine



### How much pressure should I put on pipe clamps?

*Do 4'-long pipe clamps normally bend, or did I simply tighten them too much?*

—GAH (full name & address unknown)



● Temporary bowing could be normal if you used ½" pipe, but I'd say that if you actually bent the clamps (the pieces that fit on the pipe) using ½" pipe, or bowed ¾" pipe, you overdid it on the pressure. A good rule of thumb is to use just enough pressure to start forcing some glue squeeze-out from the joint. No squeeze-out under lots of pressure means you may not have applied enough glue to the joint.

—Ray Cox, Lawton, Okla.

● Your joint should fit together snugly, and then it won't require lots of clamping pressure. If the joint has to be forced together under heavy pressure you may encounter problems later on. This also makes it much more difficult to make everything square.

—John Harden, Rancho Cucamonga, Calif.

### Gluing brass to wood can be sticky business

*I am doing a carving, and included in it are three pieces of brass that I want to attach to a curly maple background. Does anyone have any tips on types of glue? Or perhaps another method?*

—Albert McBride, Fort Myers, Fla.

● Haven't glued any brass to wood, but have secured abalone inlay to cherry burl with 5-minute epoxy, and it held well. With metal, I rough the back with some medium-grit emery before applying a small drop of the epoxy mix.

—Al Archie, Bessemer, Mich.

● You may want to try hot-melt glue or silicone sealer (aquarium type). You can't go wrong with the fast-cure epoxy. Hot-melt glue is fast and convenient. It's also more forgiving; you could pull it off if needed. It may not hold up over time as well as epoxy.

—Sam (full name and address unknown)




Continued on page 20



**In search of great mitersaw cuts**

I have the Makita LS1013 sliding compound mitersaw. Today, I was attempting to miter some picture frame molding that was 2½" wide and made of black cherry. The fit is only tight in the center—the two edges do not meet. I clamped the piece in place before cutting. What could I be doing wrong?

—Joe Gorleski, Bel Air, Md.



Miter gaps have been exaggerated for clarity

● I have the same saw and also was having problems. But, instead of convex cuts, my problem was a concave cut. At a woodworking show I talked to the Makita representative who said the problem was my blade. I replaced it with a Skarpaz 60-tooth, ¼"-kerf blade from White Engineering (619/475-6166), and bingo, the problem disappeared. I had tried stabilizers, new clamps, different wood, everything except a different blade.

—Douglas Parker, San Diego, Calif.

● Picture frame moldings can be the most demanding of all miter cuts, but I routinely cut them with a 12" Makita mitersaw with an extremely sharp 100-tooth picture-frame blade (the model U1210-6 Ultramitre blade from Industry Saw Blades, Burbank, California, 800/433-3140).

I believe a mitersaw to be slightly more stable for this kind of work, but your slider should be able to handle the task. On rare occasions, I'll correct a bad miter cut with my Delta Sanding Center's extra fine sanding disc. I use it with a miter gauge set at 45° and lightly touch the mitered corner to the disc.

—Bruce McElbaney, Livonia, Mich.

● I had a similar problem and found that I was not using a straight pull down on the handle, and was going too slow on the cut. Once I started making my motions consistent and straight, the problem cleared up.

—Don Sindedecker, Ketchikan, Alaska

● I have a 10" mitersaw that did not cut right, too. My cuts were wavy and sometimes only met the other piece in the center. I found that I needed to use a stabilizer (a round metal plate several inches in diameter) next to the blade. It will not change the position of the blade if it is used on the outside.

—Tom Pedlow, Perry, N.Y.

● I use a Forrest Chopmaster 80-tooth blade in my old Ryobi 10" mitersaw, and get perfect miter cuts with no burning. No stabilizer required. It makes a perfect glue edge with absolutely no sanding required and no gaps if I cut to proper lengths.

—Mike Kelly, Austin, Texas

**Followup from Joe Gorleski:**

● The final solution was to replace the original blade with a new one that had fewer teeth. I believe the old blade was burnishing the wood enough to compact the fibers and make the cut inaccurate.

**Curing coat trees with weak legs**

I'm making several children's coat trees. Each leg is biscuit and glued to the tree, which is 3" square and 4' tall. Legs are of 1" pine, ¾" actual. I prefinished several of those and they fell off, due to glue failure. Should I switch to wood dowels?

—Smitty, address unknown

● I had a similar problem with about a 4' item made of cherry. I had attached each leg with two dowels. They kept coming apart, so I glued them with two-part epoxy. They have held ever since.

—Mark Metko, Larsen, Wis.

● If you have a router table, I would suggest that you abandon dowels and biscuits and go with a sliding dovetail joint. In my opinion, this is a very easy joint to make, and the legs will not fall off. They will break off first. If you don't have a router table, I would screw the legs to the post and countersink and plug [the holes].

—Bryce Templeton, Austin, Texas



Illustrations: Jim Stevenson

## Are You Stumped?

If you've got a question that you think would interest other readers, we would like to hear from you. Write to: Ask WOOD®, 1716 Locust St., GA310, Des Moines, IA 50309-3023. For an immediate answer to your question, try posting it on one of our 10 internet discussion groups at: [www.woodmagazine.com](http://www.woodmagazine.com)

## Follow-up question on Ark project technique

*For the Noah's Ark project in issue #109, you suggest using a "not quite sharp #2 pencil" to scribe the lines in the deck. I had a hard time burning these lines in afterward to make them look as neat as I'd have liked. I don't know if I should have scribed the lines deeper and followed the groove, or tried a different woodburning tip than the "universal" style I used.*

*Frank Hawkins, Riverview, Mich.*

Frank, you can't quite tell from the photos of the ark we built, but those woodburned lines in the deck are and definitely look handcrafted, not precise in the way a machine might make them. Still, the rough-hewn look gives the ark an authentic "Old World" feel we like.

As far as the woodburning tool goes, if by "universal" you mean a round-pointed tip, that style does make following the pencil lines a little harder. We used a wedge-shaped "knife" tip, which tracked well even in the relatively shallow pencil grooves.



## Why are my sanding discs burning my work?

*I've enclosed a 12", 220-grit sanding disc with a buildup of some sort around the outer edge. What is the material? What is causing the buildup, and more important, what can I do to prevent it? It leaves burn marks on workpieces. (I was sanding kiln-dried cherry with this disc.) Thanks for your help.*

*Eugene Bigelow, Niwot, Colo.*

The disc alone is only circumstantial evidence, Gene, but together with your description it offers some solid clues to unravel this mystery.

The problem, called "glazing," occurs when the abrasive on the disc becomes saturated with foreign material, usually resins contained in the wood you're sanding. Cherry is prone to burning, and it often has small inclusions of resin (called pitch pockets) that can gum up abrasives. When the abrasive becomes "loaded" like this, it merely rubs the wood surface instead of cutting particles away. The friction and heat produced cause the burn marks.

The location of the buildup offers another clue that the problem stems

from a vicious circle (no pun intended) of heat and friction. On popular combination belt/disc machines, the typical 2,100-2,400 rpm spindle speed translates to a disc rim speed of 75-85 miles per hour, much faster than the speed at the center portion of the disc. This discrepancy means the outer edge will heat up and glaze before the rest of the disc does.

You can't fight the physics of a spinning circle, but you can work around them. First, try to avoid using the very outside edge of the disc. Second, switch to coarser abrasives that won't load up as quickly (120-grit is as fine as we go in our shop). Third, clean the disc regularly with a crepe rubber block (available from Klingspor's Sanding Catalogue, 800/228-0000, or other woodworking retailers).

Finally, consider slowing the machine speed by changing the drive and/or arbor pulleys. But fair warning: Disc-only sanders typically run at 1,725-1,800 rpm, while the faster speeds on combination machines are a concession to the belt sander's requirements. You may not be able to reduce the speed even if you want to, as it might affect the tool's performance. As a precaution, speak to a technical representative from the manufacturer and explain what you want to do. ♣





We salute Top Shop Tip winner Curtis George, shown with his latest work-in-progress: a walnut flag case.

Curtis George still uses his first real power tool: a second-hand Black & Decker jigsaw that he got when he was 10 years old. But his love of all things wood began a couple of years earlier when he helped his mom refinish the wooden furniture around their house.

Now that he's grown up, Curtis still enjoys refinishing. But when he's feeling creative, he likes to take a turn at the lathe and crank out kids' toys, such as wooden tops. Toys aren't the only "top" things coming out of Curtis's shop, though: Check out his Top Shop Tip at *right*.

We'd love to hear how you've solved time, money, or space problems in your shop. If we print your idea in an upcoming issue, we'll line your pocket with \$75, and you could win our Top Shop Tip tool prize worth at least \$250. Mail your best tips, along with photos or sketches and your daytime telephone number to:

**Tips From Your Shop (and Ours)**  
**WOOD® Magazine**  
 1716 Locust St., GA-310  
 Des Moines, IA 50309-3023

Or e-mail them from our website at [www.woodmagazine.com](http://www.woodmagazine.com).

Sorry, but we can't return your submissions. And, because we try to publish original tips, please send your ideas only to *WOOD* magazine. Thanks!

*Dave Campbell*  
 GENERAL-INTEREST EDITOR

## Auxiliary drill-press table works neat as a pin router

When I needed a pin router for channelling out a tray, I decided to make one rather than buy it. I fashioned a router-table support base of 2x4 and 4x4 stock, as shown in the drawing below, and mounted it to my drill-press column.

After machining the tabletop and mounting my router, I inserted a short length of 1/4" steel rod into the drill-press chuck. I then placed the tabletop on the supports, lowered the drill-press quill, centered the router collet on the rod, and attached the tabletop to the support base. The distance to the column is the critical dimension here because I


can rotate the jig to get my side-to-side alignment.

To rout patterns with the jig, I again chuck the rod into the drill press, align it with the router collet, and tighten the support in place on the column. Now, with my router bit in place and the pattern attached to the back of my face-down workpiece, I lower the rod into place and simply follow the pattern with it.

—Curtis George, Royal Oak, Mich.



Top Shop Tip winner Curtis George will keep workshop dust under control with his new Grizzly G1029 dust collector. Kudos, Curtis!



Continued on page 26

## TIPS FROM YOUR SHOP (AND OURS)

Continued from page 24


### Spray's too sticky, so use packaging tape first

As a scrollsawyer, I've never been happy with the most common methods used to secure patterns to a workpiece. I always seem to use too little or too much spray adhesive, and double-faced tape is a bear to remove.

So, instead of adhering the pattern directly to the wood, I now put down a layer of clear packaging tape, as shown at right. Then I spray adhesive liberally on the back of the paper pattern and stick it to the tape. After cutting out the pattern, I remove the tape and pattern together with no residue left on the wood.

Go easy, though, on narrow pieces, especially workpieces less than 1/4" thick—the tape grips well enough to break fragile parts. For such pieces, I find it works best to pull the tape straight back on itself, rather than lifting it straight up. As an added benefit, the tape seems to lubricate the blade, resulting in less burning.

—Dale Olschowka, Hollister, Calif.



Continued on page 28



## Let's Clear the Air...

### Introducing The New Model 750 Simply The Best!

- Variable Speed Control (200 CFM to 750 CFM Filtered Air)
- Two Speed On/Off Pull Chain
- Ultra Quiet
- 95% ASHRAE Tested Main Filter
- Lifetime Warranty
- 30 Day Money Back Guaranty

The National Institute for Occupational Safety and Health (NIOSH) recommends limiting wood dust exposures. The JDS Air-Tech 2000 will dramatically improve the quality of the air you breathe. Our new model 750 variable speed allows you to dial in your desired air flow, from a whisper quiet 200 cfm to an ultra performance 750 cfm. This will clean the air in a 30'x30'x8' shop ten times per hour. For larger areas our models 8-12 and 10-16 are available. The JDS systems will remove 99% of particles as small as five microns and 80% of particles as small as one micron. For the removal of odors, fumes and smoke, our optional charcoal filter is available. To place an order or for the dealer nearest you call us toll-free.

**\$259.00**  
Model 750

\*Better Homes and Gardens®  
WOOD® Magazine (Nov. 95)



**JDS AIR-TECH 2000™**

Another quality product from  
Manufactured in the U.S.A.

**JDS  
COMPANY**

[www.thejdscompany.com](http://www.thejdscompany.com)

1-800-382-2637

# WOODMALL™

Your Online Woodworking Shopping Service from WOOD® Magazine



## THE INTERNET'S LARGEST SOURCE FOR WOODWORKING TOOLS AND SUPPLIES!

- 24-Hour Shopping
- Over 25,000 Tools & Accessories
- Special Sales & Offers
- Tool Comparison Charts
- Free Seminars

Enter Our  
Monthly  
Sweepstakes!

[www.woodmall.com](http://www.woodmall.com)

## REVOLUTIONARY PRECISION TECHNOLOGY BACKED WITH A 6 YEAR WARRANTY\*!

16" with Free Stand\*\*



20" with Free Stand



26" with Free Stand



RBI has always been the leader with its 6 Year Commercial Rated Warranty\*, Power House: 1/5 HP DC Motor, Dual Position Lower Blade Holder, Free Stand with every saw, Heavy Duty Construction, Exclusive: Clock Tensioning, and Automatic - Upper arm lift. RBI not only makes a great Scroll Saw... we ship peace of mind with every machine sold. \*ON ALL SAW'S SOLD AFTER 8/1/99



Call 1-800-487-2623 for your **FREE** Fact Kit Today!

rbindustries, inc.

America's Woodworking Machinery Manufacturer  
1801 Vine Street • Harrisonville, MO 64701  
[www.rbiwoodtools.com](http://www.rbiwoodtools.com)



\*\*Dual position holder not included on 216!

K102


### TIPS FROM YOUR SHOP (AND OURS)

Continued from page 26

#### Timer remembers to turn off "hot" tools

I was fortunate to have not caused a fire when I forgot and left a hot-melt glue gun plugged in. To safeguard against future forgetfulness, I built a timer to automatically turn off "hot" tools. I bought the 15-minute timer at the local hardware store and wired it to an outlet box, as shown below. Now when I use a hot-melt glue gun or soldering iron, I plug it into the outlet and turn on the timer. If I need more time, I simply reset the timer.

—Alan Bradstreet, Pownal, Maine



Continued from page 30

Continued from page 28


## Tiny eyes giving you trouble? Poke 'em on with a toothpick

I sometimes need to attach tiny jiggle eyes to the children's toys I make. Unfortunately, those little devils are hard to handle with grown-up fingers. And it's easy to apply too much cyanoacrylate (CA or instant) adhesive, which can stain the workpiece and cloud the clear plastic of the eye. When stuck in this situation, round toothpicks come to my rescue.

Using sandpaper, I flatten both ends of a toothpick—one end just slightly to remove the point, and the other to the full diameter of the toothpick.

First, I dip the small end in a drop of CA and apply the glue to the toy, as shown *at far right*. I then dip the broad end of the toothpick in water and touch it to the top of the jiggle eye. The surface tension created by the water allows me to carry the eye to its mounting location, where it releases without moving out of position.

—Michael P. Locke,  
Huntington Beach, Calif.



Front Floor Mat Set  
**\$44.95**  
Tan or Grey, add \$5.00 plus \$8 shipping  
2nd set ships FREE\*



Cargo Liners Starting From  
**\$69.95**  
Tan or Grey, add \$10.00 plus \$9 shipping  
FREE cargo liner shipping when you purchase floor mats\*



WeatherFlector™ Front Set  
**\$44.95**  
plus \$8 shipping  
2nd set ships FREE\*

WeatherFlector™ Front & Rear Set  
**\$79.95**  
plus \$8 shipping  
Rear set ships FREE\*

### WeatherTech® Floor Mats

Interior protection for all types of vehicles. WeatherTech® Floor Mats offer carpet protection that is both eye-catching and effective. Only WeatherTech® gives you all season protection you can rely on. Our WeatherTech® Floor Mats are made of up to 16 lbs. of pliable virgin rubber with deeply sculpted channels and an outer rim that traps water, road salt, mud and sand from under your heels. Even in sub-zero weather, the thick natural rubber won't curl, crack, or harden. Because of the deep ridge design, dirt comes off your shoes and stays trapped in the mat, which means you also get added protection for your shoes as well as your carpet. Our WeatherTech® Floor Mats are designed to hold up to 1½ quarts of water without spilling. A protective, non-stick finish makes cleanup quick and easy.

WeatherTech® Floor Mats meet FMVSS302 and are TÜV approved. Available in Black, Tan or Grey. Available to fit most domestic and imported Cars, Pickup Trucks, Minivans and SUVs.

We also carry products from these four companies:



\*We pay regular shipping within the 48 contiguous states, when shipped to the same address on additional sets of floor mats or a cargo liner when purchased in combination with a set of front floor mats or additional sets of WeatherFlectors™ when purchased in combination with a set of front WeatherFlectors™. WE GUARANTEE YOUR SATISFACTION. If you are not satisfied with your order, return your unused product within 30 days for a complete refund, less shipping & packaging.



### WeatherTech® Cargo Liners

Custom fit cargo liners for your vehicle. WeatherTech® Cargo Liners protect the rear cargo area carpeting from all types of wear and tear. Our cargo liners are designed with up to a 3" lip which helps to contain spills from leaky groceries or wet snow boots. They are perfect for hauling gardening supplies, fishing gear, construction materials, golf clubs, or the family pet. Cleanup is quick and easy. Just wipe up with a damp cloth, sponge or vacuum. We manufacture the finest liner available, in black, tan or grey. WeatherTech® Cargo Liners are tough and durable and can withstand even sub-zero or hot summer temperatures. Guaranteed not to crack or break as long as you own your vehicle. WeatherTech® Cargo Liners meet FMVSS302 and are TÜV approved.

Available in your choice of: Black, Tan or Grey.

#### SPORT UTILITY LINER APPLICATIONS:

Bleas • Bravaas • Bronco • Cherokee • Coyote • CR-V • Daihatsu • Discovery • Durango • Envy • Escalade • Excursion  
Expedition • Explorer • Grand Cherokee • Grand Vitara • Jimmy • Land Rover • LX450 • LX470 • ML320  
ML400 • Montero • Mitsubishi Sport • Mitsubishi • Navajo • Navigator • Pathfinder • Passport • QX4  
Range Rover 4.0 SE/4.6 HSE • Rav4 • Raptor • RX300 • S10 • S10 • SLX • Sportage • Su Urban • Tahoe • Tracker  
Trooper • Vitara • Wrangler • Yukon • Xterra • Xterra • Xterra

#### VAN / MINIVAN LINER APPLICATIONS:

Aston (Ext.) • Astro (Ext.) • Caravan • Club Wagon • Escalade • Explorer • Honda • MPV • Odyssey • Pirelli  
Quest • Saturn (Ext.) • Silverado • Sierra • T 302 • Trans Sport • Venture • Voyage • Voyager • Windstar

#### AUTOMOBILE LINER APPLICATIONS:

A4 • A6 • Accord • Acura • Avenir • Beetle • BMW 3, 5, 7 Series • Camry • Civic • CL • Conquest • Continental  
Corvette • Crown Victoria • DeVille • ES300 • Escalade • Escort • Geo/Geo • GS300 • GS400 • Integra  
Intrepid • Jetta/Vista III • Legacy • Legacy • Legacy • Outback Vgn. • LS400 • Maxima • Mercedes C, E, S Class  
Passat • S70 • Saab • Seville • SC • SC1 • SC2 • SL • SL1 • SL2 • SW • SW2 • Taurus • Town Car • V70 • V90 • Vision  
7407ET/90/90 • 850 • 940

(TAN AND GREY CARGO LINERS AVAILABLE FOR SELECT APPLICATIONS)

### WeatherTech® WeatherFlector™

Ventilation made easy! Our WeatherFlector™ is precision crafted in Germany exclusively for Mac Neil Automotive Products by ClimAir. An OEM approved supplier to nearly 20 of the world's finest vehicle manufacturers assures you the highest in quality engineering, safety and function. In fact, they are the only manufacturer in the world of wind and rain deflectors to meet the ultra-tough requirements of the German product testing firm TÜV. The optically transparent cast acrylic is nearly twice as thick as the nearest competitor and installs quickly and easily inside your window channel using a precision-machined micro-thin mounting-flange. Rain or shine, while parked or in-motion, you get the best of both worlds with WeatherFlector™! The WeatherFlector™ is clearly your finest choice! Available for virtually all SUV's, Pickup Trucks, Minivans and Automobiles.

**ORDER TODAY:**  
**1 (800) 441-6287**

Representatives are available:  
Monday through Friday - 7AM-11PM  
Saturday - 8AM -11PM & Sunday - 8AM -10PM (Central Time)

Canadian Customers Call:  
**1 (800) 378-6287**


Major credit cards accepted.  
We normally ship within 48 hours. Express shipping available

**OPEN 24 HRS., 7 DAYS A WEEK**  
**MATS.COM**

## Sweatband keeps corded tools from going cordless

Dealing with a dangling power cord creates a whole handful of hazards—you can accidentally cut through it, it can get caught and pull your attention away from your work, and it's just plain annoying. To avoid the danger, I slip an elastic wrist band (like you might use when playing tennis) up to just below my elbow, and run the power cord through it, as shown *below*. The band keeps the cord well away from the cutting tool.


—Barbara Dorin-Bach, Kailua-Kona, Hawaii



## Stop shelf slippage with slots

Adjustable shelves in a bookcase or entertainment center tend to fit loosely so they can be moved easily. But that built-in sloppiness can be a nuisance when the shelves shift. To minimize this problem, rout shallow slots about the same size as your supporting pin or clip in the bottom of each shelf.

—Chuck Hedlund, WOOD® magazine shop manager



Continued on page 32

## WHY ARE WE PRACTICALLY "GIVING AWAY"



# "412 Woodworking Patterns for Only 2¢ Each?"

IF YOU LIKE TO CUT PATTERNS OUT OF WOOD, THIS IS THE SET FOR YOU! YOU'LL FIND A TREASURE HOUSE OF IDEAS INSIDE. 412 BEAUTIFUL WOODWORKING PATTERNS AND DESIGNS.

(By Frank K. Wood)

FC&A, a Peachtree City, Georgia, publisher, announced today that it is practically "giving away" an all-new set of "412 Woodworking Patterns."

- Wooden furniture for patio and porch.
- Stylish reindeer will give your yard a festive holiday touch.
- "Garden golfer" whirls all day long, while works of art bless your hearth and home.
- Angels for the kitchen, cute critters galore, neighborly welcome for a door.
- Large outdoor patterns add seasonal fun, create delightful kitchen gadgets and household helpers for everyone.
- One-of-a-kind birdhouse designs, a victorian-style holder for beanie bag

"finds."

- Shimmering snowflakes, santas and sleighs, a Christmas countdown number the days.
- Twirling whirligigs fill the sky — woodpecker, owl, and a pig that can fly!
- A 3-D village, sleepytime rabbit and a frog that hangs out over your door.
- Noah's ark toy, a garland for teacher, clever animal notepad keepers.
- An adorable armoire and baby cradle, dressing screen, and a treetop table.
- Classy corner shelves, handy peg racks, decorative vine and animals that shine.
- And much, much more!



Build all these wooden favorites. Illustrated plans include intricately detailed patterns and complete instructions. To order a set, just return this notice with your name and address and a check for \$7.99 plus \$3.00 shipping and handling, and we will send you "412 Woodworking Patterns." Or, for only \$9.99 plus \$3.00 shipping and handling, you can get both the basic set and an extra 100 patterns.

Plus, as a purchaser of our set of "412 Woodworking Patterns," if pleased, about every two months you will also be eligible for a first look and free trial preview of all companion pattern sets printed in the years ahead.

Send your check along with your name and address to: FC&A, Dept. BWZ-2, 103 Clover Green, Peachtree City, GA 30269.

You get a no-time-limit guarantee of satisfaction or your money back.

You must cut out and return this notice with your order. Copies will not be accepted!

**IMPORTANT — FREE GIFT OFFER  
EXPIRES FEBRUARY 29, 2000**

All orders mailed by February 29, 2000, will receive a free gift, "50 Special, Seasonal, Woodworking Patterns," guaranteed. Order right away!

©FC&A 2000

Continued from page 31



## Raise your clamps to be sure

When gluing up panels, I like to remove the glue squeezeout before it sets. But pipe clamps laid flat on my assembly bench left me no room to clean the underside of the joint. So I found a way to take my panel-making to a higher level.

I made a pair of clamp-holding rails, as shown *at right*, that raise the panels nearly a foot above the bench. Each upright can be moved individually to accommodate different-size panels by simply removing the wing nut and carriage bolt.

Besides giving me more space for cleanup, the rails let me inspect both the top and bottom of each joint without flipping the assembly. And, if I find the need to add panel-flattening cauls across the joints, it's easy to attach them with a C-clamp or handscrew.

—Ronald Huizenga,  
Morrison, Ill.



Continued on page 34

**New!**  
**All★Pro™**  
**Professional Series**  
**Band Saw Blades**

Heavy duty, commercial grade band saw blades.

For use in industrial, woodworking, and furniture manufacturing applications by professional woodworkers and craftsmen.

The most efficient, long lasting blades with induction hardened teeth for cutting wood, plastic, and non-ferrous metal.

Visit Your Olson Dealer and Ask for the New All Pro Blades.

**OLSON®**  
 THE OLSON SAW CO.  
 16 Stony Hill Road, Bethel, CT 06801  
 Manufacturers of Fine Quality Saw Blades Since 1918

# Sanding

**A \$230 SAVINGS**

## dust free

Add 32" wide sanding capacity to your shop and we'll throw in a dust collector at a great price.

The PERFORMAX 16-32® PLUS drum sander will surface, dimension, and finish sand. The JET 650 cfm dust collector with a 5 micron bag will pick up even the smallest particles.

16-32 PLUS shown with optional INFEED & OUTFEED TABLES, METAL STAND and CASTERS.

**PERFORMAX**  
 PRODUCTS CORPORATION. A JET EQUIPMENT & TOOLS AFFILIATE  
 Call 800-334-4910 for the dealer nearest you or visit our website at [www.PerformaxProducts.com](http://www.PerformaxProducts.com)

**OFFER EXTENDED BY POPULAR DEMAND UNTIL FEBRUARY 29, 2000**



**TIPS FROM YOUR SHOP (AND OURS)**




Continued from page 32

## Made-to-match tenons for tapered legs

When mortising a stretcher into the tapered part of a table leg, matching the angle on both shoulders of the tenon doesn't have to be a mind-boggling operation. Start by cutting the mortise in the untapered leg, then trim the waste from the leg using a tapering jig on your tablesaw.

Next, take one of the offcut tapers and place it against the fence of your cutoff sled (or your miter gauge set to 90°), as shown in the Cut 1 Drawing, *above right*. Hold the stretcher against the tapered scrap, and cut one shoulder of the tenon with your dado set. Now, flip the stretcher top-to-bottom and the tapered scrap end-for-end (as shown in the Cut 2 Drawing), keeping the point of the taper at the edge of the sled. Cut the opposite shoulder without changing the tablesaw fence. Finally, make the top and bottom shoulder cuts by hand or with a bandsaw.

—David Sobel, Tampa, Fla.





**SHOP FOX**

# HEAVY-DUTY MOBILE BASES & ROLLER STANDS

**ASK FOR THESE QUALITY PRODUCTS BY NAME!**

**D2056 TOOL TABLE**  
Support cross braces on top provide incredible strength and capacity. Flared legs and adjustable rubber feet ensure stability while reducing machine vibration. Butcher block finish table top measures 13" x 23" and is 30 1/2" tall. 700 lb capacity.



**D2275 TOOL STAND**  
This sturdy universal tool stand measures 24" tall, 27 1/2" x 31 1/2" at the base and 17 1/4" x 22" at the top. Includes non-slip rubber feet. 1,000 lb capacity!



**D2273 SINGLE ROLLER STAND**  
• Adjusts in height from 26 1/2" to 45".  
• All-steel construction  
• 1 5/8" wide ball bearing roller



**D2272 TILTING ROLLER STAND**  
• Adjusts in height from 25 1/4" to 43 1/4".  
• Rollers Tilt from 0° to 45°  
• All-steel construction  
• 1 5/8" wide ball bearing rollers



**D2057 HEAVY-DUTY MOBILE BASE**  
• Adjusts from 19" x 20 1/2" to 29 1/2" x 29 1/2"  
• 600 lb capacity



**D2274 5 ROLLER STAND**  
• Adjusts in height from 26 1/2" to 45".  
• All-steel construction  
• 1 5/8" wide ball bearing rollers



**D2271 ROLLER TABLE**  
Features all-steel welded construction and measures 19" wide x 65" long. Comes with 9 ball bearing rollers. Adjustable in height from 26 1/2" to 44 1/2".



**D2058 SUPER HEAVY-DUTY MOBILE BASE**  
• Adjusts from 18" x 24 1/2" to 28 1/2" x 33 1/2"  
• 1200 lb capacity



CALL US OR VISIT OUR WEBSITE FOR THE LOCATION OF A DEALER NEAR YOU.


**WOODSTOCK INTERNATIONAL** INC.  
SELECT WOODWORKING TOOLS AND ACCESSORIES

Phone: 1-800-840-8420 FAX: 1-800-647-8801  
[www.woodstockinternational.com](http://www.woodstockinternational.com)

## How do you top a Top Shop Tip?

I loved the keyhole cutting jig in *WOOD*® magazine #112 because I make a lot of frames and always use keyhole slots. But I found a way to make it even better: I left a 1/4" flange on the inside of both rails (as shown below) for my router to ride on. I have to set my keyhole bit a little deeper, but the rabbets keep my router from dipping side-to-side.

—*Lutber Williamson, Columbia, Md.*



### A FEW MORE TIPS FROM OUR WOODWORKING PROS

- When tiny drill bits snap mid-task, they can take you almost to the breaking point. See Photo E on page 56 for an easy way to prevent bit breakage.
- Boring holes at compound angles challenges even the most experienced woodworker. On page 60, see the drill-press angle jig we made to help with the adult rocker.
- Learn how we employed a router and scrollsaw to make long, straight decorative cutouts. Photos A and B on page 48 show the process we used when building the nesting tables.

## For All Your Woodcarving & Sign Carving Needs

Terrco provides a full line of machine carving and sign carving equipment. Beginning models are the T-110 single spindle bench carver and our CM614 single spindle sign carver.

### Terrco, Inc.

222 1st Ave. NW  
Watertown, SD 57201  
USA  
(605) 882-3888  
Fax (605) 882-0778


Intermediate models include the K-Star, a two-spindle heavy duty bench model, and the Northstar, a heavy duty floor model available in one to eight spindles.

Our advanced model is our Master Carver series, which is an extremely heavy duty floor model with from eight to forty spindles.


Website: [www.terrco.com](http://www.terrco.com)  
E-mail: [info@terrco.com](mailto:info@terrco.com)



Model CM614 Sign Carver



Model T-110 Dupli-Carver



Multi-Spindle Carving Machine

Circle No. 2175

The missing  
Link Between  
man AND  
CRAFTSMAN.



Gorilla Glue® makes serious woodworkers more successful. It's incredibly strong, 100% waterproof and excellent for hardwoods, softwoods and hard-to-glue exotics. You'll get nearly invisible glue lines and stable joints. Plus, Gorilla Glue won't gum up your tools like yellow glue does. Discover a higher form of creation. Call 800-966-3458 for a dealer, or find out more at [www.gorillaglu.com](http://www.gorillaglu.com).



THE TOUGHEST GLUE  
ON PLANET EARTH™

# Forests for the Future

Granted, trees grow without any help. But to bring you lumber and veneer, foresters find ways to grow them bigger, better, and forever. Here's how they do it.

Once upon a time, most wood came from *old-growth* forests that had trees hundreds of years old. Now, due to past logging and conservation measures designed to protect old-growth forests, most wood comes from *second-* and *third-growth* forest land; that is, from trees that grew after logging activity. Some of this forest land belongs to the public as state and national forests. (Logging is *never* permitted in national parks and monuments or designated wilderness areas.) The rest is in private ownership, managed as commercial *timberland* to provide lumber and other forest products.

Today, a well-managed forest not only produces desirable trees for everything from woodworking stock to newsprint, it also maintains wildlife resources, protects natural watersheds, and provides beauty. Public forests also must meet recreational needs.

## Two ways to make a forest grow.

Due to rugged terrain, poor soil, or an unfriendly climate, some forests never produce trees large enough for commercial use. But where trees can grow to good size, foresters have two options for growing them, *even-age* or *uneven-age* (sometimes called *sustainable*) management.


### An even-age forest has trees that don't vary in age by more than 20 years.

Some species of trees—aspens, black cherry, birch, California redwood, Douglas fir, red pine, and southern pine, for example—require the sunlight provided in this type of forest. It's created by cutting all the original trees to make way for the natural regeneration of seedlings (sometimes supplemented by planting).

### An uneven-age forest contains trees of all ages.

There are tree species, such as oak, ash, white cedar, and sugar maple, that grow better in the shade of larger trees. To get a desirable mix of existing trees, the forest has to be cleaned of all dead, damaged, or unwanted ones.

*Continued*



## Foresters meet the needs of the tree species growing naturally in their timberlands—or of the ones they want to grow—with different practices.



### For even-age-forests:



**Clear-cuts** require removing all trees larger than 1-2" in diameter. Remaining trees provide wildlife support and some stream protection. Trees that grow well under the newly created sunlight are *pioneers*. Eventually, their greenery induces the vigorous growth of shade-loving trees such as ash, basswood, beech, and birch. States and the federal government frequently limit the size of clear-cuts for environmental reasons (to prevent serious erosion, for instance) or aesthetics.


**Seedtree** is a practice that—instead of clear-cutting—leaves a dozen or so good seed-producing trees per acre. When young trees eventually sprout and become established, the older seed trees come down. This works best with the same species listed under clear-cut, plus red oak and sugar maple.



**Shelterwood**, a practice done in two or three thinning-type logging operations over several years, restricts competition from other vegetation for new tree seedlings by providing some shade. The last logging of mature trees delivers the sunlight needed for young trees to grow into an even-aged stand. The forest never looks harvested. It works with shade-loving trees such as ash, basswood, and maple, but also with Douglas fir, Sitka spruce, lodgepole pine, and Eastern white pine.

### For uneven-age forests:

**Group Selection** means that ¼- to 2-acre forest parcels must be cleared of specified groups of tree species and sizes every few years. Openings create some sunlight for species that need it. This practice leaves a forest looking fairly undisturbed but requires intensive management to raise California redwood, sugar pine, white ash, and walnut.



**Single-tree** requires the spotty harvesting of individual trees to slightly open up the forest to sunlight, which allows seedlings to grow. The cutting also removes undesirables, letting valuable trees add diameter and height. These thinnings occur about every 10 years to encourage the growth of California redwood, sugar pine, white ash, walnut, and many other hardwoods.

### How to size up a tree

Some trees easily grow over 100' tall. But a timber company only cares about *merchantable* height. That's the measurement from the base of the trunk to the first visible defect, such as a crack, the major fork if there isn't a defect, or where the trunk diameter diminishes to 10" in the absence of a fork or defect. The merchantable height combined with the tree's diameter at breast height (4½' above the ground; called *d.b.h.*) tells about how much wood a tree will yield. Forest pros accomplish this with the help of a scaling stick and conversion tables based on log-volume tables. You can come fairly close calculating board feet in a tree with the method shown at right.

- 1 From 50 paces, visualize yourself standing against a tree's trunk. Then to get merchantable height, imagine how many times you can multiply your height in feet up to the first defect, fork, or narrowing of the trunk to 10" diameter.
- 2 With a steel tape, measure the trunk circumference (around the tree) at breast height.
- 3 In the chart, find the diameter that most closely matches the trunk circumference you measured. Read across to find the closest merchantable height, then down to the corresponding yield in board feet.

Circumference at breast height (inches)	Diameter at breast height (inches)	Merchantable height (feet)					
		8	16	24	32	40	54
		Yield in board feet					
57	18	72	122	168	207	248	292
63	20	90	156	212	262	317	366
69	22	111	194	262	328	392	450
75	24	137	236	319	400	470	550
82	26	165	281	381	480	565	650
88	28	195	331	450	560	670	760
94	30	227	383	520	650	770	890
101	32	260	440	600	740	890	1,020
107	34	294	500	680	840	1,010	1,160
113	36	330	565	770	960	1,140	1,310



Illustrations: Brian Jensen


# Crafted in Carolina

South Carolinian  
Philip Greene  
strives for the  
perfectly crafted  
canoe—and he's  
nearly there

Wood makes music to Philip Greene. It chimes, "With your hands, craft me into things people will want to touch. Use my beauty to its best advantage. Make me a pleasure to gaze upon, to own, to use." And he listens.

From a red and white barn-like workshop in rural Round O, South Carolina, the 35-year-old craftsman caringly produces objects of Honduras mahogany, figured maple, western red cedar, redwood, Sitka spruce, and walnut. Although most people

*Continued*



# Crafted in Carolina



view the things Phil makes as masterfully crafted strip-built canoes and wondrous paddles for the most serious of canoeists, some look on them as art. And like fine oil paintings or sculpture in marble, the creations carry proportionate price tags. Try \$20,000 for a 20' canoe. Or as much as \$600 for a paddle. And even at those prices, Phil finds himself a year behind in fulfilling orders for his masterpieces built under the name Wood Song Canoes.

## He found a rich niche among wooden boats

Internationally acclaimed woodworker Sam Maloof bought a 1/3-scale canoe model of Phil's in 1997—at 65 percent of full-size price. Then he later ordered a 12' all-mahogany canoe to hang in his home.

John Moores, owner of the San Diego Padres baseball club, has a model displayed in his home, too. Hollywood movie director and producer James L. Brooks also bought one. So did an unnamed man of wealth from Charleston, South Carolina—then another and another, for a total of five! “He told me quite frankly that he was taking them home, adding thousands to their cost, and reselling them to his friends at a barbeque,” Phil explains.

“I really feel uncomfortable dealing with wealthy people because I'm not in their class,” he confides with sincere modesty. “But I do make something that fits their class. Believe me, I didn't start out that way, saying that I was going to sell to the rich folks. But it's not really boating people who buy most of my canoes. Once I realized that, and quit trying to sell to people who couldn't afford it, I did better.”

Phil designed and built canoes in his mind during long months of sea duty while in the U.S. Navy. “As a submarine sonar technician, I could sit and hear nothing but whales for weeks at a time in the North Sea,” he says. “So in 1997, after 13½ years in the Navy, I finally decided to get out and start building those dreams.”

The very first canoe, however, came in 1988 while Phil was still in the service and living near Charleston where he was stationed. Remembering his boyhood years in New York's Adirondack Mountains, he wanted a canoe for recreational use on Lake Moultrie. What he wanted, though, cost too much for an enlisted man with a family.

"I told Paula, my wife, that we could build a wooden canoe for about \$250," he recalls. "She said we should do it. So, together, we made a 19' strip canoe of redwood trimmed with ash and walnut and covered with fiberglass and epoxy. By the time it was finished, it cost nearly \$2,000 with all the tools. Paula said I should recoup that, so I built another, planning to sell it to my Dad. But by the time it was finished, I had to go to sea. Rather than leave it outside, I put it in a consignment shop. I later heard via ship's radio that it sold for \$2,000."

Phil went on to build more canoes when he wasn't at sea, each improved. By 1993, he'd won Best of Show and People's Choice awards at the Georgetown, South Carolina, Wooden Boat Exhibit. He repeated in 1995 and 1998. In 1994 and 1995, one of his canoes took the most prestigious award at *WoodenBoat* magazine's Wooden Boat Show, in New England. The exposure brought sales, too, even at the then low prices of \$6,000 to \$8,000.

"I was probably averaging about \$1 an hour," Phil chuckles. "So I almost doubled the price." A small 1996 ad placed in *The Robb Report*, a magazine for the rich devoted to travel, luxury autos, and other pricey merchandise surprisingly brought orders. "Now, it's pretty much business by word of mouth, a few shows, and an occasional ad," he says.

### His duty has become full attention to detail

How do Phil's functional objects de art differ from other wooden canoes?



Above: At the shop's double router table, Phil, left, and brother Tim shape bead-and-cove strips for a canoe hull.



Left: Tim clamps a glued western red cedar strip to a canoe-in-progress. It takes about 80 strips to form a hull, each numbered and placed for appearance.

"I believe in the old Navy term 'attention to detail,'" he replies. "I can show you places like the scuppered [ventilated] gunwales that have no defects. You can look with a magnifying glass and you won't find anything. On the other hand, anybody can do a boat that looks good from 10' away. But when you get 3' away, flaws start showing up."

At Wood Song Canoes, detail begins with the wood. Bird's-eye and fiddle-back sugar maple come from northern Michigan. Select walnut Phil buys from a furniture maker. Clear-heart western red cedar, redwood, and Sitka spruce he gets from an Oregon supplier. Honduras mahogany, in plain, ribbon stripe, and crotch figure is shipped from North Carolina. "All in all, when you talk strips for a 20' boat, that's only 40 board feet of wood," he says. "And it takes a lot less for the gunwales, decks, seats, and other trim. So I can be picky."

Phil and his brother, Tim, rip the wood for the hulls into strips—boat

length  $\times \frac{3}{4} \times \frac{1}{4}$ " for softwoods and boat length  $\times \frac{3}{4} \times \frac{3}{16}$ " for hardwoods. The strips are numbered in pairs as they come off the board, all 80 of them. This allows Phil to "bookmatch" the hulls. That is, a strip that is No. 14 on the left (port) side has its twin in the corresponding spot on the right (starboard) side. It's pleasing to the eye.

Figured trim receives the same attention, according to Phil. "If I'm using bird's-eye maple, for instance, I place it where the most figure will be seen by the person in the boat looking at it. The carrying yoke, for example, is best seen by the stern [rear] paddler, so I face the figure to that position."

Add to that attention five coats of epoxy over the fiberglass, inside and out. Each, put on when the one before gets tacky, requires a six-hour wait, depending on air temperature. Then there's finish—seven or eight sprayed coats of Defthane exterior polyurethane on everything.

That's Phil's attention to detail, and it goes into every one of the eight or

*Continued*

# Crafted in Carolina

so canoes Phil and his helper can turn out annually. That's also why a boat takes from 350 to 550 hours to complete, depending on size and extras.

## Model by model, it's strip after strip

Wood Song Canoes offers 16 models, each with variations that add up to 40 different hull designs ranging in length from 10' to 20'. You'll find solo canoes built for maneuverability, tandem canoes for speed, and everything in between. None of them incorporate a keel ("Modern canoe designs don't need one," notes Phil.) He doesn't build a canoe for whitewater.

"Our canoes are for special occasions when rocks and rapids aren't on the agenda," Phil comments. "They're for the time when enjoying the canoe is as meaningful as the actual trip."

Whatever the purpose or the chosen wood, every canoe requires thin strips. But unlike the strip-canoes of earlier years, which required staples

**The adjustable bow seat of curly maple and mahogany features hand-caning in a daisy chain pattern. Several coats of exterior polyurethane protect the wood and the cane.**

to hold them in place on the forms while the glue dried, Phil and Tim employ bead-and-cove joinery. "Stapleless construction adds about 40 man hours to the building time, but it eliminates the normal 6,000-10,000 holes that can be seen on the hull," Phil explains.

For bead-and-cove joining, each of the wooden strips has to be routed for a bead and a cove. This takes both men at a router table fitted with two routers. One has the beading bit, the other the cove bit. After Phil cuts one shape on one edge of a strip, he passes it to Tim to cut the other.

Phil, though, has discovered a trick to make stronger, more flexible joints with the bead-and-cove technique. "I cut the  $\frac{3}{16}$ "-thick strips with  $\frac{1}{4}$ " bead-and-cove router bits. This gives me a shallower cove that's stronger because it doesn't have tall walls that can chip off. The smaller bit doesn't make a full radius. To get this on  $\frac{1}{4}$ " strips, I use a  $\frac{3}{16}$ " bead-and-cove bit."

With the hull forms in place on the strongback, a temporary backbone for the canoe, the strips can go on. "For the strips, laminations, and everything that has what I call a factory joint, I use Tite-Bond II," says Phil. "For something that I've hand-sanded, like the decks that have to be hand fit, I use epoxy. It fills the gaps."

When the strips have been added to the hull forms and the glue has dried, the outside gets sanded down to 400-grit. Next comes the outer layer of fiberglass.

## There's many a trick to fiberglass and epoxy

"We start the fiberglassing at the warmest point of the



A canoe's carrying yoke begins as a lamination of mahogany and bird's-eye maple. It's then cut out at a bandsaw and shaped with a grinder.

day. And there's a reason," says Phil. "As the boat cools down, the air pockets that are inside the wood pores start to contract and draw in the epoxy with which we've saturated the fiberglass cloth. Most people do it the other way around—starting in the morning—and as the boat heats up the pores force the epoxy out." After the surface becomes tacky come the five extra coats of epoxy.

Strip-canoes builders have always had one big problem: sanding inside the hull. The outside's easy; all contours are convex. Inside, they're concave. "No sanding device fits it," Phil says. "But I've come up with a good trick."

"After fairing in [sanding] the now-hardened glass on the outside of the hull, we wiggle the very flexible hull off the form and strongback and place it right-side up in two carpet-covered cradles," he continues. "These hold the canoe at waist level and are set so that the heavy ends don't sag and draw in the hull at the gunwale line."

Now the inside of the hull is ready for sanding with a 5" random-orbit sander and two different pads. One is a standard pad and the other is one that Phil altered and calls his floppy disk. "To make a floppy disk, I take a standard-thickness 5" pad and insert its threaded bolt into my drill press," Phil explains. "With the drill press on high speed, it acts like a lathe as I file away some of the hard backing of the





## Paddles that may never see water

Although Wood Song Canoes' flat-water paddles are built ergonomically so it takes little effort to move a canoe along, they're tough as well as good looking. Laminated from woods of contrasting colors, edged in ash, and reinforced with fiberglass, they'll take a beating. But like many of Phil's canoes, most paddles never see water.

"People buy them for wall decoration in restaurants, sport shops, clothing stores, and homes," says Phil. "We designed and built them for hard use, so this 'display only' aspect was exasperating at first. But then we realized that it was a form of flattery, so now we customize them and build hangers and display racks for these customers."

As well as wonderfully beautiful, Phil's paddles can feature bent shafts, modified pear-shape grips, and S-blades. For lightness, but less beauty, Wood Song makes them of redwood or western red cedar. Hardwood paddles offer more eye appeal, but they're heavier. The base price for either in adult size is \$225, with added charges for figured wood, fancy patterns, or special blades.

pad. I generally stop when the pad becomes 2¾" to 2" in diameter. At that point it can handle sanding all but the smallest radius.

"For the very tight curves in the ends of the canoe's bottom, I sand with a rubber 1½"- to 2"-diameter drum and sanding sleeve. In the extreme ends, which will later be covered by bulkheads, I use cloth-backed 40-60 grit paper."


The inside gets sanded first with 40 grit for soft woods or 60 grit for hardwoods. Phil and Tim don't bother scraping off the glue, as the coarse grit readily handles the non-gumming Tite-bond II. After the first sanding, which removes squeeze-out, the pair switches to other grits and ends up with 280 grit for softwood hulls or 400 grit for hardwoods.

The figured, matched wood, the details, the coats of epoxy and polyurethane, all add up to the beauty that people just love to touch. Pointing to the gleaming 19' tandem boat before him, Phil says, "This canoe has been fondled by perhaps 250,000 people at different shows. And I can tell by how they run their hands over it that our Wood Song Canoes have hit the right chord." ♣

### Want to get canoe savvy?


Phil has written a real gem of a booklet on choosing a canoe and paddles, canoe design, and basic canoe and paddle construction. You can get it for \$8 (U.S.) by writing Wood Song Canoes, 425 Jessie Lane, Round O, SC 29474. Phone 843/835-8137.

Written by Peter J. Stephano  
Photographs: Steve Uzzell



From left, walnut/curlly maple Black Beauty paddle, \$270; walnut/curlly maple Salt and Pepper paddle, \$270; redwood, western red cedar, and spruce Spectrum paddle, \$270; curly maple, walnut, and mahogany Sunrise paddle, \$390.

A laminated red cedar paddle with maple accents leans against a canoe with a sculpted, crotch mahogany deck.



# Nesting Knockouts

A matched set of mission-style tables



You can treat the trio as three separate tables, as shown *above*, or nest them, as shown at *right*.

You can't beat nesting tables for versatility and beauty. We've made these three even more appealing by designing them to go together with minimum fuss and maximum workshop enjoyment.

*Note:* Although the tables are different sizes, the methods for making the parts for each one are identical. So we suggest you machine parts for all three tables at the same time. That way, you'll only have to make each setup once.

## You'll need a dozen legs

**1** Laminate stock for the legs (A), and cut them to the sizes shown for each table in the Bill of Materials. To do this, laminate two pieces of  $\frac{3}{4}$ "-thick  $\times 1\frac{3}{4}$ "-wide white oak about 1" longer than the finished length of each leg. Joint one edge of each lamination, and rip the piece to  $1\frac{1}{16}$ " wide. Joint the sawn edge to finished width, and trim the leg to length.

**2** Mark each leg's location, such as *right rear*, on its top. Orient the lamination lines as shown in the Exploded View drawings.

**3** Lay out the mortises on the legs, referring to the Exploded View drawings and the Mortise detail of the Right Leg Assembly drawing. Stand the legs for each table in assembly order to verify the mortise layouts.

**4** Form the leg mortises. To do this, refer to steps 2-4 in the Forming a Mortise illustration. For accuracy, drill the holes with a drill press, setting a fence to center the bit on the leg.

**5** Rout or sand  $\frac{1}{8}$ " chamfers at the bottom of each leg where shown.

## Now get rollin' on the rails

**1** Cut the rails (B) to size for each table. At the same time, cut two or three scrapwood test rails (small-table size would be fine).

**2** Cut  $\frac{3}{8} \times 1\frac{1}{4}$ " tenons  $1\frac{1}{16}$ " long on the rail ends, where shown in the Tenon detail of the Right Leg Assembly (large table) drawing. Later you'll miter-cut

the tenons to give them the shape shown in the drawing.

To cut the tenons, install a  $\frac{3}{4}$ " dado blade on your tablesaw. Position the tablesaw's rip fence  $\frac{3}{16}$ " from the dado blade, as shown in the Cutting the Rail Tenons drawing. Attach an auxiliary fence to the saw's miter gauge, extending it to the rip fence, as shown in the drawing.

Set the cutting depth to  $\frac{3}{16}$ ", and cut both faces at one end of a test rail, holding the end against the rip fence. Make another pass with the end


*Continued*

Bill of Materials						
Part	Finished Size			Matl.	Qty.	
	T	W	L			
large table						
A* leg	1½"	1½"	27¼"	LO	4	
B rail	¾"	2"	17¾"	O	7	
C wide slat	¼"	3"	18¼"	O	2	
D narrow slat	¼"	1¼"	18¼"	O	8	
E filler	¼"	⅝"	1¼"	O	24	
F top	¾"	20"	20"	EO	1	
medium table						
A* leg	1½"	1½"	24"	LO	4	
B rail	¾"	2"	11⅞"	O	7	
C wide slat	¼"	3"	15"	O	2	
D narrow slat	¼"	1¼"	15"	O	4	
E filler	¼"	⅝"	1⅞"	O	16	
F top	¾"	14½"	14½"	EO	1	
small table						
A* leg	1½"	1½"	20¾"	LO	4	
B rail	¾"	2"	6¾"	O	7	
C wide slat	¼"	3"	11¾"	O	2	
D narrow slat	not used in this table					
E filler	¼"	⅝"	1⅞"	O	8	
F top	¾"	9"	9"	EO	1	





\*Make oversize initially, then cut to finished size in accordance with how-to instructions.

**Materials Key:** O—white oak; EO—edge-glued white oak; LO—laminated white oak.

**Supplies:** Tabletop fasteners, #8x¾" flathead wood screws.



SEE THE WOOD PATTERNS® INSERT FOR FULL-SIZE PATTERN



# Nesting Knockouts

pulled back far enough to cut the end of the tenon. Insert a corner of the tenon into a mortise to check its fit. Adjust the cutting depth as necessary. When correct, cut both faces at both ends of all 21 rails.

Next, set the cutting depth at  $\frac{1}{4}$ ". Stand the test rail on one edge, and cut the tenon. Ensure that this distance from the rail edge to the tenon will place the rail's top edge flush with the leg top. Adjust if needed. Then cut one edge of each rail end.

Finally, set the cutting depth at  $\frac{1}{2}$ ". Saw the other edge of the test rail's tenon. Test-fit and adjust as before, then cut the remaining rail edges. After making the last cuts, leave the tablesaw cutting depth set where it is for the next step.

**3** Change to a  $\frac{1}{4}$ " dado blade, and saw a centered groove  $\frac{1}{2}$ " deep, where shown on four of the seven rails for each table. The slats (C, D) and spacers (E) will slide into these, so verify the width of the groove against the thickness of the stock for those parts.

**4** Miter-cut the tenon ends to  $45^\circ$ . Those at the front of the bottom side rails don't require mitered ends. But cutting all of them makes the side rails interchangeable, heading off a complication come assembly time.


## Saw some slats and spacers

**1** Cut the wide slats (C), narrow slats (D), and spacers (E) to size from  $\frac{1}{4}$ "-thick stock. Note that the small table doesn't call for any narrow slats.


**2** Make 12 photocopies of the Decorative Cutout Full-Size Pattern in the *WOOD PATTERNS*® insert. Adhere two copies to each part C, placing the top of each pattern at one end of the part. Spray adhesive (follow the label instructions for temporary bonding) or rubber cement will hold them in place.

**3** Drill  $\frac{3}{8}$ " start holes where shown.


**4** Rout the straight center portion of the cut-out design. To do this, install a  $\frac{1}{4}$ " straight bit in your table-mounted router. Position a fence to center the bit on the wide slat. Clamp another fence along the other edge of the part, as shown in *Photo A, above right*. Then, with the cutting depth set to about  $\frac{3}{8}$ ", place the hole at the



Parallel fences help you rout an arrow-straight slot between two holes for the cut-out design in the wide slat.



Scrollsaw the ends of the decorative cutout. A #4 blade (.035 x .015", with 18 teeth per inch) is a good choice.



Bore recesses for the tabletop connectors with a  $\frac{1}{16}$ " spade bit. The bit's point simultaneously drills a screw pilot hole.

left end of the part over the bit, start the router, and cut the decorative slot between the two holes.


**5** Scrollsaw the ends of the decorative cutout, as shown in *Photo B*. Sand the routed and sawn edges, as needed. Remove the patterns.

**6** Finish-sand the legs, rails, slats, and spacers. (We sanded to 220 grit.)

## Assemble a bunch of bases

**1** Dry-assemble (without gluing) the legs, rails, and slats for the right leg assembly, referring to the Right Leg Assembly (large table) drawing. You

## FORMING A MORTISE




**STEP 1**  
Mark mortise location on leg.

**STEP 2**  
Drill  $\frac{3}{8}$ " holes 1" deep at both ends of mortise.

**STEP 3**  
Drill overlapping  $\frac{5}{16}$ " holes 1" deep between holes drilled in Step 2.



**STEP 4**  
Finish mortise with a chisel, cutting sides and ends square.

## CUTTING THE RAIL TENONS




can leave out the spacers (E) for this test-fitting. Check for joint fit and squareness, and ensure that the top of the rail lies flush with the leg tops. Unclamp the parts, and disassemble.

**2** Glue together the rails and slats for the assembly. To do so, start by placing the center slat exactly in the middle of one rail. Put a dab of glue in the groove on each side of the slat, and slip a spacer into the groove against each edge of the slat. Center the other rail on the other end of the slat, and glue in the spacers. Slide in the first narrow slat, and fix it in place with



KEY	
LT=	Large Table
MT=	Medium Table
ST=	Small Table



\*Note: Part (D) is not used on the ST.

spacers. Continue until all slats and spacers are in place.

**3** After the glue dries, glue the front and back legs to the assembled rails and slats.

**4** Put together the left leg assembly in the same way. Build the left and right leg assemblies for the other tables.

The leg assemblies for the other tables differ from the drawing only in the number of narrow slats (D). The medium table has two narrow slats per assembly; the small table, none.

**5** Connect the leg assemblies for each table with the remaining rails, refer-

ring to the Exploded View drawing. To ensure wobble-free tables, assemble them on a known flat surface, such as your table saw's table.

#### This tops everything so far

**1** For each table, edge-glue stock to make a blank slightly larger than the top, and cut the top (F) to size.

**2** Install figure-eight type tabletop connectors on each frame assembly, where indicated on the Exploded View drawings. Locate the center of the 1/16" hole for each connector 1/4" from the inside edge on top of the

rail. Drill the holes with a portable drill, as shown in *Photo C*.

**3** Lay the top facedown on the workbench, and center the inverted base assembly on it. Mark centers for the attaching screws. Drill pilot holes, taking care not to go through the top. Attach the top with screws.

**4** Finish-sand the top. Finish the set as desired. (We stained the tables shown with Minwax provincial #211, then applied satin-finish polyurethane.)

Project Design: Jim Boelling; James R. Downing  
Photographs: Hetherington Photography  
Illustrations: Kim Downing; Lorna Johnson

# Portable Plant



This cold frame folds flat for handy storage

**I**n our neck of the woods, garden cold frames are essential to help protect seedlings from early season storms and chill. Many gardeners also use them to extend the growing season into late fall. Traditionally, they've been makeshift affairs, tacked together from salvaged wooden storm windows, old boards, and bricks or rocks. This one, though just as simple to put together, offers some big advantages: It's sturdier, better-looking, and it folds for easy storage.

*Note: You can cut all of the parts from a half-sheet (4x4') of 3/4" B-C exterior plywood. Select a sheet with as few knots as possible on the C-grade side. It should lie flat, too.*

### Saw seven plywood pieces

**1** Referring to the Cutting Diagram, rip a 7 $\frac{3}{4}$ "-wide strip for the front panel (A) from one edge of a 4x4' piece of plywood. Crosscut to the length specified for part A in the Bill of Materials.

**2** Cut part B to size. Rip and crosscut the remaining piece of plywood to 28x39 $\frac{1}{4}$ " (the outside dimensions for part C); then lay out on it the inside cutting line for part C.

**3** Draw cutting lines for parts D and E in the middle of the laid-out lid (C), where shown on the diagram. (We laid out the parts using a metal yardstick and a fine-point black marker.)

# Protection

**4** Drill a  $\frac{1}{4}$ " blade start hole adjacent to the cutting line for the lid opening. Lay the plywood across a pair of sawhorses or other suitable supports, and cut out the lid opening with a handheld jigsaw, as shown in the photo below.

**5** Cut parts D and E to shape.

**6** Tilt your tablesaw's blade to  $21^\circ$ , and bevel-cut the top of the front panel (A) and back panel (B), where shown on the Exploded View and Side Section View drawings.


**7** Bevel-cut the back of the lid (C) where shown. The long side will be the outside surface of the lid.

**8** Rout a  $\frac{3}{8}$ " rabbet around the lid opening on the inside where shown. Chisel the rabbet's corners square.


**9** Fill any voids that appear in the sawn and routed plywood edges. (We used Durham's Rock Hard water putty as a filler.) Sand the parts smooth.

*Continued*


A handheld jigsaw makes quick work of cutting out parts C, D, and E. Cut close to the line; then sand to it.



## EXPLODED VIEW



## CUTTING DIAGRAM



$\frac{3}{4}$  x 48 x 48" Exterior plywood

## Bill of Materials

Part	Finished Size			Mater.	Qty.
	T	W	L		
A front panel	$\frac{3}{4}$ "	$7\frac{3}{4}$ "	$38\frac{1}{2}$ "	Ply	1
B back panel	$\frac{3}{4}$ "	$17\frac{13}{16}$ "	$38\frac{1}{2}$ "	Ply	1
C lid	$\frac{3}{4}$ "	$39\frac{1}{4}$ "	28"	Ply	1
D side panel	$\frac{3}{4}$ "	12"	$16\frac{7}{8}$ "	Ply	2
E side panel	$\frac{3}{4}$ "	12"	$12\frac{5}{16}$ "	Ply	2

**Material Key:** Ply—grade B-C exterior plywood.

**Supplies:** 3" light strap hinges (3), National N127-605; 3" non-removable pin hinges (10), National N146-373; 3" loose-pin hinges (2), National N227-207; aluminum screen-frame kit; nylon turn buttons (8), Elgar 00081; 2-mil clear plastic; nylon window screen (optional); paint.



# Portable Plant Protection

## Hinges hold everything together

**1** Lay the parts of one side (D, E) in order on your workbench, the outside facing up. Join them with two 3" hinges, located where shown in the Exploded View drawing. Likewise, assemble the other side.

To install the hinges, lay each one in position. Mark the screw centers for one leaf, and drill pilot holes. Install a stop on the bit to prevent drilling through the side. Drive in the screws; then attach the other leaf.

**2** Install a loose-pin hinge on the inside face of each D-E assembly where shown.

**3** Connect the front (A) and back (B) panels to the side assemblies with hinges, referring to the Exploded View drawing.

**4** Install the lid (C) with three strap hinges, mounted as shown in the Exploded View and Side Section View drawings. Hacksaw the end off one leaf of the center hinge so it won't hang over the opening. (We also drilled and countersank an additional screw hole near the cut-off end.)

The hinge leaves that attach to the lid must bend down to match the lid's slope. An easy way to do this is to affix the hinges to the back (B), place the lid (C) in position, lift its front edge to make it level, and screw the hinge leaves to it. Closing the lid then bends the hinges to the correct angle.

## Paint the frame for outdoor duty

**1** Sand all parts to 220-grit. Sand a slight round-over along all edges to prevent splintering.

**2** Apply a coat of oil-based exterior primer. Take care to coat the plywood edges. You can paint over the hardware, paint around it, or remove it and paint under it, as you prefer.

**3** Brush on two finish coats of house paint or exterior enamel.

## Put plastic in the window

For a traditional cold frame, glaze the lid opening with  $\frac{1}{8}$ "-thick clear acrylic. Cut the plastic to size, place it in the rabbeted opening, and secure it

with glazier's points. Caulk around the plastic with glazing compound.

But, one editor suggested, if the opening had screen mesh in it, the frame could protect strawberries from birds later in the season. So for the cold frame shown, we made interchangeable lid inserts, utilizing do-it-yourself aluminum window screen kits from a home center. (Elgar Products made the kits we used.) Here's how we did it.

**1** Following the kit manufacturer's instructions, assemble two frames that fit inside the rabbeted opening.

**2** Install nylon window screening in one frame, following the manufacturer's instructions for pressing in the rubber spline and trimming the screen to size. Using the same procedure, install clear plastic sheeting (we used 2-mil plastic) in the other frame.

**3** Secure the window inserts in the lid rabbet with nylon turn buttons, like those shown in the photo *above right*. We installed eight turn buttons, placing them as shown on the Exploded View drawing.


**4** From the leftover plywood, cut two sticks about 1" wide and 13" long. Use these to prop the lid open on warm, sunny days so the plants won't cook in your cold frame.



Nylon turn buttons hold the interchangeable inserts in the lid. You can also glaze the lid directly with a piece of clear acrylic sheet.

**5** To fold the cold frame for off-season storage, pull the pins from the loose-pin hinges on the sides. Flip the lid over against the back. Fold the sides inward to collapse the frame. Stick the hinge pins back in one leaf of each hinge for safekeeping.

Project Design: Bruce Chambers; Charles I. Hedlund  
Illustrations: Roxanne LeMoine; Lorna Johnson  
Photographs: Hetherington Photography





# Rocker of the Ages



Make this heirloom for generations to enjoy

Designing and building this beautiful walnut rocker was challenging, to say the least. We began with a charming child's version I discovered in an antique shop in Savannah, Georgia. Scaling it up seemed simple enough.

But it didn't take long to realize we had a classic study in template and jig making. Add a scooped seat and we soon had our hands full.

Fortunately, after numerous stops and starts, I'm happy to report that we've solved all of the challenges. This means much easier building for you, guaranteed! So go ahead, build yourself an heirloom.

*Larry Clayton*  
Editor

*Note: To build this chair, write for the complete, full-size, project patterns at the following address: Traditional Rocker, 1716 Locust Street, GA 310 Des Moines, IA 50309-3023. For a walnut source, see our Buying Guide.*

## **A great chair starts with a comfortable seat**

**1** Crosscut enough 6/4 (1 3/8") stock to make a 22"-wide by 21"-long seat blank (A). (We cut and jointed four pieces to 5 1/2" finished width.)

**2** Plane each piece of stock to 1 1/4"; then arrange these pieces on a flat surface over waxed paper to achieve the best color and grain match. Mark the pieces to maintain this order during the glue-up.

*Continued*

# Rocker

**3** Glue up the blank, leaving the clamps on overnight. Next, crosscut both ends to square the blank, establishing a finished length of 20 $\frac{3}{4}$ ".

**4** Apply the full-size patterns for the seat top and bottom from the mail-order pattern pack. (See *Photo A*.) Be sure to run the grain from front to back. Align the patterns' front edges with the front edges of the seat blank. Ensure that the top and bottom patterns align perfectly. (We penciled a centerline across the front edge of the seat blank and aligned the patterns' centerlines with this line.)

## Bore precision holes in the seat with our handy jig

*Note: Success in drilling the seat and other chair parts requires a close and careful reading of the patterns.*

**1** Complete the seat work by boring precision angled holes in the seat top and bottom. To do this, first build the drill-press angle jig on *page 60*.

**2** Chuck a  $\frac{3}{4}$ " brad-point bit into your drill press, and check to see that the table sits perpendicular to the bit. Place the jig on the table, locating it hinge-end out with the centerline beneath the bit. To do this, lay the column-alignment gauge along a centerline marked on the jig and against the drill-press column as shown on *page 56* in *Photo B*. Bolt or clamp the table in place.

**3** Next, as shown *Photo C*, adjust the angle of the table for 77° for the  $\frac{3}{4}$ " rear leg holes drilled into the seat bottom. Tighten the jig's knobs to lock the angle in place.

**4** Tack the alignment gauge temporarily in place along the dashed alignment line for the 77°,  $\frac{3}{4}$ " hole. Place the seat blank on the jig with the hole location centered under the drill bit. Ensure that the column alignment gauge contacts the column as shown in *Photo D*. Drill the hole to the prescribed depth. (We used masking tape wrapped around the drill bit for a depth gauge.) Repeat the drilling process for the remaining 77°,  $\frac{3}{4}$ " hole.


Adjust the table to 81°, and drill the remaining  $\frac{3}{4}$ " holes on the bottom. Flip the seat blank over, and drill the


*Continued*




Center and align the top and bottom patterns along the front edge of the seat blank. Tape them in place at the centerline edges; then spray-adhere them to the seat as shown, smoothing out any wrinkles.

## CUTTING DIAGRAM






ROUND-OVER DETAIL



SCREW-HOLE DETAIL



EXPLODED VIEW

Part	Finished Size			Mati.	Qty.
	T	W	L		
*A seat blank	1 1/4"	22"	19 7/8"	W	1
B front legs	see pattern		12 7/8"	W	2
C rear legs	see pattern		12 7/8"	W	2
D front stretcher	see pattern		15 1/4"	W	1
E rear stretcher	3/4" dia.		13"	W	1
F side stretchers	3/4" dia.		14 1/4"	W	2
G armrest supports	see pattern		11 3/8"	W	2
H back spindles	see pattern		23 1/4"	W	2
I back splats	see pattern		21"	W	4
*J rockers	1 1/4"	4"	30 15/16"	W	2
*K seat back	7/8"	4 1/8"	22"	LW	1
*L armrests	1"	3 1/2"	14 5/16"	W	2

\*Cut parts with an \* oversize. Trim to finished size according to the how-to instructions.

**Materials Key:** W—walnut; LW—laminated walnut.

**Supplies:** White woodworker's glue, #10x2" flat-head wood screws (2), 3/4" walnut dowel, clear finish.

**Buying Guide**

**Rocker wood kit.** Walnut, 6/4 boards, 6' long (3), 4' long (1), \$160 ppd.; 8/4 turning squares, 3' long (10), 3/4" dowels (2), \$115 ppd. Complete order of boards, squares, and dowels, \$250 ppd. Woodworker's Source, 5402 South 40th Street, Phoenix, AZ 85040, or call 800/423-2450.

**Rocking chair spindle kit.** Walnut, item RP. Kit includes legs (4), front stretcher (1), side and rear stretchers (3), armrest supports (2), back spindles (2), and back splat (4). \$203.95 ppd. Schlabaugh and Sons Woodworking, 720 14th Street, Kalona, IA 52247, or call 800/346-9663 to place an order.

**Queen Anne Router Bit.** Item no. 610-500 (1/2" shank), \$34.90, plus \$5.90 shipping. Jesada Tools, 310 Mears Boulevard, Oldsmar, FL 34677, or call 800/531-5559.

# Rocker

$\frac{3}{4}$ " holes on the seat top at the specified angles and depths on the pattern. Switch to a  $\frac{1}{2}$ " brad-point bit, and similarly drill the  $\frac{1}{2}$ " deep holes on the seat top.

**5** After drilling the holes, build the seat routing jig, and scoop the seat as described on page 10. Redraw the outline in the area scooped out.

**6** Bandsaw the seat to shape, cutting just outside the line and sanding to the line. (We used a disc sander for this operation.)

**7** Complete the seat by routing a  $\frac{1}{16}$ " round-over along the top and bottom edges. You may need to hand-sand the round-over where the flat and scooped surfaces meet.

## Now, surround the seat with sturdy spindles

*Note: If you don't own a lathe or would like to save on construction time, order the precision-turned rocking chair spindles from our Buying Guide. Then skip to Step 3 below.*

**1** Referring to the Bill of Materials, cut the turning blanks for the front and rear legs (B, C), front stretcher (D) armrest supports (G), back spindles (H), and back splats (I) to length from  $\frac{8}{4}$  ( $1\frac{1}{2}$ ") stock.

**2** Draw diagonals on both ends of each piece to locate the centers. Starting with the legs, turn the spindles to shape, using the full-size patterns in the pattern pack to guide you. (We used a parting tool,  $\frac{1}{2}$ " spindle gouge, and a 1" skew.) Complete the spindles by parting or sawing off the waste where shown.


**3** From  $\frac{3}{4}$ " walnut dowel, cut the rear stretcher (E) and the side stretchers (F) to length. Set these aside until you dry-assemble the base.

**4** Next, to determine the hole locations in each leg, first cut the leg-drilling guide from scrap to  $\frac{1}{4} \times 1\frac{1}{2} \times 20\frac{1}{2}$ ". Apply the guide pattern to the piece, and drill the four  $\frac{3}{4}$ " holes where indicated.

**5** Place the seat upside down on a worktable, and dry-fit the leg spindles into the holes. (We sanded bevels on the tenons to make the spindles easier to insert.) Place the appropriate holes in the guide over the front and back legs on one side, and, using a rule,



Use the column alignment gauge to locate the drill-angle jig prior to clamping it in place.



To adjust the table, raise it, aligning the top surface with the needed degree line on the scale. Tighten the knobs.

Align the gauge with the drill alignment guideline for the hole, tacking it in place. Hold the gauge's upper end against the column, center the bit over the hole location, and bore.





**E** Place the guide over the bottom ends of the legs and make alignment marks for the drilling operation.



**G** Align the appropriate mark on the leg's bottom end with the jig's vertical line, and clamp the opposite end in place.

mark a  $\frac{1}{4}$ " line onto the ends of each leg, continuing the pattern line as shown in *Photo E*. Repeat for the opposite front and back legs. Then relocate the guide over the front legs only and, again, over the back legs, marking the leg ends where indicated. **6** Now, run strips of masking tape up the inside surfaces of the legs. Rest the guide on the chair bottom, and mark the hole locations, as shown in *Photo F* and where referenced for front stretcher (D), rear stretcher (E), and side stretchers (F). (To avoid confusion later on, we marked the legs and corresponding leg holes 1, 2, 3, and 4. As a quick reference, we also marked the angle of each drill hole beside each mark.)

**7** Next, make the simple leg-drilling jig in the pattern pack. Strike a vertical centerline on the jig's solid end.

**8** Secure the drill-press angle jig, hinge end out, to your drill-press table and adjust it to  $75^\circ$ . Then place the jig's fence and the leg-drilling jig on the drill-press angle jig, securing the fence to the track and centering the


leg-drilling jig on the angle jig's centerline. Measure between the two and cut a spacer to that width.

**9** Insert a marked spindle leg into the leg-drilling jig, aligning the appropriate mark on the leg's bottom end with the vertical mark on the outside face of the jig at one end, as shown in *Photo G*. Clamp the top end of the spindle in the opposite end of the jig with a small C-clamp. Ensure that the angle next to your hole location mark beneath the bit matches the angle set in the drill-press angle jig.


**10** Now, centering a  $\frac{3}{4}$ " bit over the hole mark with the top end of the leg nearest to the drill column, clamp this jig with spacer to the angle-jig's fence as shown in *Photo H*. Then drill the hole in the leg. Use this same procedure to drill all of the remaining leg holes. (We drilled all of the  $75^\circ$  holes first; then those at  $79^\circ$ ,  $84^\circ$ , and  $87^\circ$ , adjusting the angle jig accordingly and locking it in place.)

**11** Dry-fit the legs and stretchers together and to the seat bottom. Leave these in place for now.

*Continued*



**F** Hold the leg-drilling guide alongside the legs, and mark the hole locations and angles where noted on the printed guide pattern.



**H** With the spindle in place below the bit, clamp the leg-drilling jig to the fence of the drill-press angle jig. Bore the hole.

# Rocker

## It's time to shape a lasting pair of rockers

- 1 Rip and crosscut two pieces of 6/4 stock to  $4\frac{3}{8} \times 31\frac{1}{2}$ " for the rockers (J).
- 2 Apply the rocker Top View patterns to the top edge of each blank. Apply the Side View pattern to one side of one blank and aligned with the hole locations along the top.
- 3 Clamp the angle jig to your drill press rotating the jig so that the hinged end is to the right side. Because the drill-press table arm is in the way, remove the inside triangular support of the jig for this operation. Raise the jig to  $76^\circ$  and lock the one scaled side in place. Clamp a block of wood beneath the opposite open side of the jig table to provide adequate support and maintain the table's angle from edge to edge. Locate a rocker blank on the jig with the  $\frac{3}{4}$ " bit centered over the hole location at the rocker's front end.
- 4 Holding the blank firmly, drill a hole  $1\frac{1}{2}$ " deep. Drill a front-end hole in the other rocker blank.
- 5 Adjust the angle jig to  $85^\circ$ , adjust the block of wood as needed, turn the rocker blanks  $180^\circ$  on the jig, and drill the  $2\frac{1}{2}$ " holes at the rear ends of the rocker blanks.
- 6 With the ends flush and the holes aligned, join the two pieces together with double-faced tape. Now, bandsaw the rockers to shape following the pattern. Separate the rockers and label one "left" and one "right."
- 7 Next, chuck a slightly concave pilot-bit in your table-mounted router.



**I** Using white woodworker's glue, glue and clamp the  $\frac{1}{8}$ " pieces to the form and let the glue-up sit overnight.


(We used Jesada's Queen Anne Bit, no. 610-500; see our Buying Guide.) Raise the bit to its full  $\frac{3}{4}$ " cutter lengths and rout the inside bottom edge of each rocker. See the Rocker Routing Bottom Edges detail *below*.

Lower the bit so only  $\frac{1}{2}$ " of the cutter is above the table, and rout the outside bottom edges.

8 Chuck a  $\frac{1}{16}$ " round-over piloted bit in your router and rout along the top inside and outside edges of the rockers. Stop just short of running the pilot over the drilled holes. Hand-sand the edges in these areas to conform with the  $\frac{1}{16}$ " round-overs. Dry-fit the rockers to the legs. (We used a wood rasp to modify the lower tenons for an easier fit. We rasped the outside face of the rear tenons and the inside face of the front tenons.) Disassemble the chair parts.

## Okay, let's form a fancy seat back

- 1 From two lengths of 6/4 stock, resaw seven pieces to  $\frac{3}{16} \times 4\frac{1}{4} \times 23$ ". Now, plane the pieces to  $\frac{1}{8}$ " thick.
- 2 Cut three  $2 \times 4$ s to 22" and glue them together face to face. Apply the seat back form pattern to the lamination's  $3\frac{1}{2}$ " face and bandsaw the form to shape. Sand to the outline.
- 3 Place waxed paper over the contact surface of the form. Now, apply white woodworker's glue to the mating surfaces of the  $\frac{1}{8}$ " pieces, and bend and clamp the pieces to the form as shown in *Photo I*. (We taped clamping blocks to the outside lamination with double-faced tape to protect the wood. We used white glue for the longer open time.) Let the lamination cure overnight.
- 4 Scrape off excess glue on the lamination; then joint one edge. Now, with one edge true, adjust your tablesaw and rip the lamination to final width. Keep the portion in contact with the blade's cutting edge on the table as you saw through this curved seat back blank.
- 5 Adhere the patterns to the bottom edge and front face of the lamination, aligning the centerlines.
- 6 Chuck a  $\frac{1}{2}$ " bit in your drill press. Place the angle jig on your drill-press table, hinge to the right, and remove the inside triangular side. Now, referring to the angles on the Seat Back Bottom View pattern, adjust the angle jig, clamping a block of wood under the open side of the jig to maintain



the angle. Align the gauge with the hole centerlines and drill press column, as shown in *Photo J*. Drill the holes for the rear back spindles (H) and splats (I). (Note that we stabilized the seat back blank on edge with a pair of clamped wood blocks.)

**7** Bandsaw the seat back to shape, cutting just outside the line, then sanding to the line.

### Add curved armrests for maximum comfort

**1** Plane, rip, and crosscut two pieces of stock to 1×4×14¾" for armrests (L).

**2** Adhere the left and right armrest patterns to the stock. (Note that these patterns apply to the bottom surfaces of the armrest blanks.)

**3** Return to a ¾" bit, and place the angle jig on your drill press with the hinged end to the front. Adjust it to 80°. Follow the orientation on the patterns, and align the hole centerline of one armrest with the column using the gauge. Drill the hole and repeat the process for the other armrest.

**4** Bandsaw and sand the armrests to shape. Label one armrest "left" and one "right."

**5** Chuck a ½" round-over bit in your table-mounted router, and round over the top edges of each armrest.

**6** Using an oscillating spindle sander or drum sander, sand one end of each arm to fit the rear back spindles (H), where indicated on the pattern. Note that these recesses are angled to fit the tapered spindles.


### Now for the best part— assembling the rocker

**1** Remove all patterns and labels and finish-sand the chair parts. (We used a foam block and 180-grit sandpaper.)

**2** Starting with the seat, dry-fit the chair parts. (We relied on a mallet to lightly tap parts together.)

**3** With white woodworker's glue, assemble the rockers and legs to the seat. Let the assembly dry overnight. With the exception of the armrest supports (G), glue in remaining spindles, along with the seat back.

**4** Next, dry-fit the armrest supports (G) and the armrests (L) together and to the seat. Measure down from the bottom of the armrest to the seat at



Place the drill press angle jig sideways on the drill press, align the gauge using a straightedge, and bore the hole to depth in the seat back.



Rest the armrests on a right-angle spacer, and drill the countersink/counterbore holes with a portable drill.

the support location. Make a simple right-angle spacer block to this length. (We screwed two pieces of ¾" scrap plywood together.)

Now, rest the notched end of one armrest on the spacer and against the back spindle (H). Holding the armrest firmly in place, determine the screw hole location on the spindle's back surface. Mark it with an awl. Using a portable drill, bore the hole, as shown in *Photo K*. (We used a no. 10 countersink/counterbore bit for this.) Repeat for the other armrest. Test-drive the

screws; then disassemble and glue and screw these parts to the rocking chair. Plug the holes.

**5** Finish the chair. (We went with three coats of natural oil finish, letting each coat dry completely and sanding with steel wool between coats. Finally, we rubbed out the finish with three coats of paste wax, applying it with cheese cloth and buffing it with clean cotton rags.)

Written by Jim Harrold  
Photographs: Hetherington Photography  
Illustrations: Kim Downing; Lorna Johnson

# A Drill-Press Jig with all the angles



Even if you're fortunate enough to have an accurate drill press with a tilting table, the one-way (side-to-side) tilt action might not accommodate all the angles or workpieces you deal with. Worse still, the fixed tables on some older drill presses give you precision for 90° angles and that's it.

This adjustable angle-drilling jig gives your drill press a lot more versatility. It helps you position and drill workpieces consistently—the essential job of any drill press—and even can tackle such difficult tasks as the

compound angles required for our rocking chair project on *page 53*.

Two Baltic birch panels—one base and one platform—make up most of the jig. The base clamps or bolts to the drill press table, and the platform pivots to angles between 0° and 45°.

You'll find the angle scale in the *WOOD PATTERNS*® insert. Simply cut it out and use spray adhesive to glue it to a piece of 1/8" plywood or hardboard. Set another 1/8" panel (for the righthand angle support) underneath the first and cut them out together, oriented back to back. Drill starter


holes at the ends of the curved slot, then cut the center portion out with a scrollsaw or jigsaw.

Mounting the table correctly requires the use of a simple indexing template, shown at a reduced scale in the *WOOD PATTERNS*® insert. Cut a notch at one corner (equal to half the column diameter) so you can line up the template edge with the centerline on the jig. For more details on how to set up and use the jig, see *page 54*.\*

Written by Bill LaHay  
Photograph: Hetherington Photography  
Illustrations: Roxanne LeMoine; Lorna Johnson




## HERE'S HOW TO INSTALL THE MINI CHANNEL




### STEP 1

Drill an  $1\frac{1}{64}$ " hole through the channel and plywood, centered on the channel.



### STEP 2

Bore a  $\frac{5}{8}$ " hole  $\frac{1}{32}$ " deep, centered over the  $1\frac{1}{64}$ " hole.



### STEP 3

Insert the T-nut and countersink for a #6 flathead machine screw. (Note that the T-nut gets chamfered as well.)

## Bill of Materials

Part	Finished Size			Matl.	Qty.
	T	W	L		
A base	$\frac{3}{4}$ "	14"	14"	BP	1
B platform	$\frac{3}{4}$ "	14"	14"	BP	1
C angle supports	$\frac{1}{8}$ "	$9\frac{3}{4}$ "	$11\frac{7}{8}$ "	HB	2
D fence	$\frac{3}{4}$ "	2"	14"	BP	1

**Materials Key:** BP—Baltic birch plywood, HB—hardboard.


**Supplies:**  $\frac{3}{8}$ " x  $\frac{3}{16}$ " mini channel (2 pcs. @ 14" long), #6-32 T-nuts and mating #6-32 x  $\frac{1}{4}$ " flat-head machine screws (10 ea.),  $\frac{3}{8}$ " x  $1\frac{1}{2}$ " square-head bolts (2),  $\frac{3}{8}$ " x 3" carriage bolts (2),  $\frac{3}{8}$ " 3-wing plastic knobs (6),  $\frac{3}{8}$ " flat washers (8),  $\frac{3}{8}$ " x 2" threaded rod (2), #8 x 1" flathead wood screws (8),  $1\frac{1}{16}$ " x 14" continuous hinge with mounting screws.

### Buying Guide

**Hardware kit.** Includes all hardware described above, \$24.95 ppd. Ask for kit #DP-AJ.

**Lumber kit.** Includes Baltic birch plywood and  $\frac{1}{8}$ " hardboard, \$12.95 ppd. Kit #LP-1.


Contact Schlaubaugh and Sons Woodworking, 720 14th Street, Kalona, IA 52247, 800/346-9663.



$\frac{1}{8}$ " hardboard (pattern applied with spray adhesive) Protect surface with clear packing tape.

$\frac{3}{8}$ " all-thread 2" long (Thread into hole using a pair of  $\frac{3}{8}$ " nuts.)

SEE THE WOOD PATTERNS® INSERT FOR FULL-SIZE PATTERN




MULTIPURPOSE

# 10" Saw Blades

Crosscutting or ripping, they do it all

Browse through any woodworking catalog or home center and you'll find a bevy of sawblades designed for specific tasks or materials. But, do you really *need* to change blades every time you turn around, or will a single multipurpose blade fill the bill for most table-saw tasks? To find out, we examined nearly 40 different models of multipurpose blades, and here's what we learned.

For this article, tool tester Bob "Bladerunner" McFarlin examined more teeth than a dozen dentists do in a day.



## Fast Facts

- For critically acclaimed cutting, start with a well-tuned saw. Even the best blade will perform poorly in a badly maintained tool.
- In our test, blades with only alternating top bevel (ATB) teeth outperformed those with a combination of ATB and raker teeth.
- Thin-kerf blades put less strain on tablesaw motors, especially lower-powered saws. But some full-kerf blades are thin enough to cut almost as efficiently as a thin-kerf.



To evaluate how easily each blade cut, we used a Comatic power feeder (Sunhill Machinery, 800/929-4321) to rip thick pine boards at a constant rate, and measured the saw strain with a multimeter.

## We started by taking the blades for a test spin

For our test, we acquired two samples of each model (74 blades in all). To objectively measure the blades before putting wood to them, *WOOD*® magazine tool tester Bob McFarlin constructed the precision testing stand shown in the photo at left. The hub of the rig is ground to exactly  $\frac{5}{8}$ " diameter to test each blade's arbor hole for fit, and a dial-indicator gauge adorns each end of the stand.

The vertical gauge Bob is using in the photo measures the blade's plate and teeth for runout (any deviation from perfectly flat). Runout greater than .005" can increase the amount of chipping and tearout, and wastes wood by widening the kerf. We measured for runout on the plate just

below the gullet and on the sides of each tooth.

The horizontal dial indicator measured the height of each tooth in relation to the center of the blade. If all teeth are equidistant from center, or *concentric*, each one works equally hard when cutting stock. If not, the higher teeth have to remove the stock left by the lower teeth, prematurely dulling the blade and leading to chipping and tearout.

While examining each of the 3,278 teeth under 30X magnification, we noted any rounded points or chipped carbide. The ratings for this test are shown in the Quality of Factory Grind column in the chart at the *end of the article*.

After a thorough tune-up of our tablesaw, it was time for some real-world testing. We ripped and crosscut  $\frac{3}{4}$ " oak, 1½" pine,  $\frac{3}{4}$ " oak-veneer plywood, and  $\frac{3}{4}$ " melamine-coated particleboard with each model of blade. After every cut, we looked for and noted any evidence of chipping, tearout, and scratching along the fresh-cut edges.

Finally, to objectively compare ease of feed, which indicates how much strain the blade places on the saw's motor, we used a power feeder (shown *above*) to rip 1½"-thick pine boards. An inline digital multimeter recorded the change in current draw. We also measured each blade's noise level during this test.

## General purpose vs. combination: What's in a name?

Take a gander at a dedicated ripping blade and you'll find about 20 flat-ground teeth around its perimeter. On the other hand, a blade engineered purely for cross-cutting sports 60-80 teeth with bevels angled in alternating directions—a pattern called *alternate top bevel* (ATB).

Blade makers have long sold blades that incorporate elements of both styles as *combination* blades. Such blades group four ATB teeth, preceded by one slightly lower, flat-ground tooth, called a *raker*. (See *foreground* blade in photo at *right*.) You'll usually find 10 sets of teeth in

this pattern for a total of 50 teeth—which, not coincidentally, is halfway between a ripping blade's 20 and a crosscut blade's 80.

But in recent years, the *general-purpose* blade has gained popularity. These blades do away with raker teeth and distribute the remaining 40 ATB teeth evenly around the blade, as shown on the *background* blade. Only a few such blades were on the market ten years ago; these days, virtually every major manufacturer sells a general-purpose blade. And with good reason: The smoothest-sawing blades in our test were 40-tooth ATBs.

*Continued*



Deep gullets, each followed by a raker tooth and four ATB teeth, distinguish a combination blade (foreground) from a general purpose blade (background), with its evenly spaced ATB teeth and consistently deep gullets.

# 10" Saw Blades

## Blade anatomy: Understanding the tooth and consequences

To get a fix on why some blades cut cleaner than others, you need to understand how tooth shape and plate characteristics affect blade performance. Use the Blade Geometry drawing *below* as a reference while you read.

**Hook angle.** If you draw a line from the center of the blade to the tip of a tooth, the angle formed between that line and the tooth face is called the *hook angle*. This measurement impacts the angle at which the tooth penetrates the wood. We found the cleanest cuts resulted when the tooth entered the stock at a 45° angle.

By raising or lowering the blade in the saw, any of the models in our test can achieve that angle. But we found that an 18-20° hook provides that optimum entry angle with the blade at the safest cutting height—with the gullet about 1/8" above the stock. As you can see in the drawing *below right*, you'd have to put the gullets of a 10°-hook blade 1 1/4" above the workpiece (which we don't recommend) to get the same entry angle.

**Bevel angle.** Blade makers grind the top of each carbide tooth to a specific angle, called the *bevel angle*. Except for the Craftsman Professional C300 model, which we'll discuss in a moment, all of the blades in our test have bevel angles ranging from 0° (raker tooth) to 25°. Raker teeth make rip cuts more efficiently because each tooth tends to pre-split the wood along the grain like a splitting wedge in a log. However, this same action splinters the wood in cross-grain cuts.

A beveled tooth behaves more like a chisel. Its sharp point scores the material before the beveled edge shears through the wood fibers. (Craftsman's



Craftsman's "Razortooth" (on the Professional C300 blade) sports a curved face so each tooth does twice the work of one ATB tooth.

unique Razortooth design, in the photo *above*, features hollow-faced teeth, where the tooth face is concave. This leaves each tooth with two scoring edges, so the blade acts almost like an 80-tooth blade crosscutting, but struggles in rip cuts.)



Generally speaking, the steeper the bevel angle, the cleaner the crosscut. But there is a trade-off: Like a chisel, the finer cutting edge of a steeply ground tooth dulls quickly and gets damaged more easily than a shallower-beveled tooth.

**Plate.** All of those sharp teeth are useless as cutting tools until they are brazed to the blade's body, or *plate*, which is either laser-cut or stamped from a sheet of steel. All other things being equal, we prefer a laser-cut

plate because it can be cut from harder steel, making for a more stable saw blade.

Plate thickness also contributes to blade stability, with thicker plates holding their rigidity better under stress than thin plates. However, thin blades have other advantages. See our comparison of thin- and full-kerf blades on the *next page*.

Some blade makers, such as CMT, Freud, and Oldham, apply a non-stick coating, such as Teflon, to the plate. This can reduce burning by blades with very little side clearance (the difference in thickness between the side of the tooth and the plate). Although coated blades also resist rust, for this style of blade we found no difference in cutting performance.



## Here's the skinny on thin-kerf blades

If the centerpiece of your shop is a contractor-style tablesaw with a 1½-hp.-or-less motor, it makes good sense to use a thin-kerf blade for most shop chores. Because a thin kerf blade removes less stock with each cut, it requires less power to operate and saves more of your expensive stock from winding up in the dust collector.

In fact, in our ease-of-feed test, we power-fed boards into each blade on two different saws—a

220-volt, 3-hp. cabinet saw, and a 110-volt, 1½-hp. contractor's saw. On the less-powerful saw, only thin-kerf blades—those with a .111" or less kerf—could handle our stiff 38-feet-per-minute (fpm) test. Full-kerf blades stalled the small saw at that rate, but did better when we slowed the feed rate to 15 fpm.

Because the thin plates are less rigid than their full-kerf counterparts, they're more prone to deflec-

tion by knots or tight grain in the workpiece. That's why we recommend installing a blade stabilizer (also called a stiffener or dampener) to stiffen a thin plate. These devices also can improve the performance of full-kerf blades.

Remember, though, stabilizers essentially thicken the plate at the center, so if they're larger than 3½", they also reduce the blade's cutting capacity. (A 6" stabilizer lowers the capacity to about 1½".)

## A few more performance issues to sink your teeth into

**Quality of the cut edge.** If you demand a scratch-free edge from your tablesaw blade, you certainly can get it from some of the blades in our test, such as the CMT General, Forrest Woodworker II, Freud F410, Jesada CGP-2000, Ridge Carbide, and Tenryu. And of these, only the Forrest blades actually burnished the cut edges.

But the same narrow side-clearances that burnish also can burn your workpiece. So if you choose one of the blades rated excellent in this category on the chart, you'll need to keep your stock moving through the blade and periodically remove pitch buildup from behind the teeth. On the other hand, blades rated as good in this category require a little light hand-sanding to remove the tooth scratches, but aren't as likely to smoke your stock.

**Quality of factory grind.** Getting the tooth angles right isn't all a manu-



You'll get more sharpenings out of the background blade because the teeth have more carbide to grind.


facturer needs to do to turn out a well-performing blade. A carelessly sharpened blade can exhibit rounded tips or a jagged cutting edge, and either characteristic lowers the quality of the cut. Bear in mind, however,

that a skilled sharpener usually can resharpen even a badly dinged edge to peak performance.

While we're on the subject of sharpening, if you're the kind of woodworker who has your blades sharpened frequently, consider buying a blade with a thicker carbide tooth, as shown *above*. You'll get more sharpenings out of your blade.

**Noise level.** The National Institute for Occupational Safety and Health (NIOSH) says that hearing damage can occur when you're exposed to a noise level of 85 decibels (dB) for 8 hours at a time. They also say that every 3dB increase cuts your safe exposure time in half. Although few of us spend a full workday around a running tablesaw, by that standard, the quietest-cutting blade in our test

*Continued*



This photo shows the gamut of bottom-side tearout and chipping we found in our test. The material shown is ¾" oak-veneer plywood.

# 10" Saw Blades

## CUTTING CLASS: 37 10" MULTIPURPOSE SAWBLADES

BRAND	MODEL	NUMBER	TEETH					PLATE	PERFORMANCE RATINGS (3)										NOISE LEVEL (10)	WARRANTY (11)						
			GRIND PATTERN (1)	BEVEL ANGLE (DEGREES) (2)	HOOK ANGLE (DEGREES)	KERF WIDTH (INCHES)	THICKNESS (INCHES)		LASER-CUT (L) OR STAMPED (S)	RUNOUT (4)	CONCENTRICITY	QUALITY OF FACTORY GRIND	SMOOTHNESS OF EDGE (5)	CROSSCUT TEAROUT (6)							EASE OF FEED (9)	NG LOAD	CUTTING			
														OAK	PINE	PLY (7)	MCP (8)	TOP OF CUT						BOTTOM OF CUT	TOP OF CUT	BOTTOM OF CUT
														TOP OF CUT	BOTTOM OF CUT	TOP OF CUT	BOTTOM OF CUT									
AMANA	610404	40	ATB/R	12	10	.130	.094	L	G	E	G	G	E	G	F	F	F	F	P	G	94	101	S			
	610504	50	ATB/R	12	10	.132	.094	L	F	E	G	G	G	G	E	G	G	F	F	P	G	95	104	S		
CMT	The General 213	40	ATB	20	18	.124	.100	L	G	G	G	E	E	E	E	G	E	F	F	G	93	100	Life			
	The General 214 (thin-kerf)	40	ATB	20	18	.107	.081	L	G	G	G	E	E	E	E	G	E	F	F	E	95	99	Life			
CRAFTSMAN	Silver Series	40	ATB	12	13	.116	.085	S	G	F	F	F	F	G	G	F	F	F	P	G	95	98	Life			
	Professional C300 (26789)	40	H	*	15	.120	.087	L	E	G	G	G	E	E	E	E	G	F	G	P	96	100	Life			
	Professional Woodworking C400 (26782)	50	ATB/R	15	10	.127	.087	L	G	F	G	G	G	G	E	G	G	F	F	E	96	99	Life			
DELTA INDUSTRIAL	35-613	40	ATB	15	12	.123	.089	L	G	G	F	G	G	G	E	F	G	F	F	G	95	97	Life			
	35-617	50	ATB/R	15	15	.124	.086	L	G	G	F	G	G	F	G	F	G	F	F	G	96	97	Life			
DEWALT	DW7623 (60 series)	40	ATB	15	20	.119	.082	L	G	G	G	G	E	E	E	G	E	P	E	F	94	96	1 yr.			
	DW7615 (60 series)	50	ATB/R	10	15	.121	.082	L	E	E	G	G	G	G	E	G	G	F	F	G	95	96	1 yr.			
DML	Golden Eagle 74010	40	ATB	20	15	.128	.087	L	G	E	G	G	G	G	E	G	F	G	E	F	93	97	Life			
	Golden Eagle 74020	50	ATB/R	20	15	.131	.085	L	G	F	G	G	G	G	E	G	G	F	F	G	95	97	Life			
FORREST	Woodworker II	40	ATB	15	20	.125	.095	L	E	E	E	E	E	E	E	E	E	E	E	G	95	97	Life			
	Woodworker II (thin-kerf)	40	ATB	15	20	.107	.077	L	E	E	E	E	E	E	E	E	E	E	E	E	95	97	Life			
FREUD	F410	40	ATB	18	18	.126	.092	L	E	E	G	E	E	G	E	E	E	E	E	E	G	95	96	Life		
	LU72M010	40	ATB	10	13	.123	.086	L	E	G	G	G	E	G	E	G	G	F	F	G	94	96	Life			
	TK306/TKR306 (thin-kerf)	40	ATB	15	15	.094	.071	L	E	E	E	G	E	G	E	G	G	E	E	E	94	95	Life			
	LU84M011	50	ATB/R	20	10	.118	.086	L	E	E	E	E	E	F	E	G	G	G	E	P	95	97	Life			
	TK906/TKR906 (thin-kerf)	50	ATB/R	10	15	.092	.071	L	E	E	E	G	E	G	E	G	G	E	E	E	96	97	Life			
IRWIN	Premium S6750	40	ATB	15	20	.115	.079	L	G	G	E	G	E	G	E	E	G	E	F	E	93	95	Life			
JESADA	CGP-2000	44	ATB	20	18	.130	.099	L	G	G	G	E	E	E	E	E	E	E	E	E	94	98	Life			
	Maxi-Combo	50	ATB/R	15	12	.126	.084	L	G	G	G	G	E	G	E	E	G	F	E	G	96	98	Life			
	Maxi-Combo Light	50	ATB/R	15	12	.097	.065	L	F	G	G	G	E	G	E	G	G	F	F	E	95	98	Life			
MAGNA	M87155	40	ATB	12	13	.107	.070	S	G	G	F	F	G	G	G	F	F	F	P	E	95	99	Life			
MAKITA	792200-3	50	ATB	5	10	.109	.086	L	E	E	G	G	E	E	E	G	G	G	E	G	93	96	Life			
OLDHAM/US SAW	Woodworker's Choice C1040	40	ATB	15	12	.108	.074	L	G	G	F	F	E	F	E	F	G	P	E	P	95	98	Life			
	Wizard Elite 100-7740T	40	ATB	15	12	.122	.095	L	F	G	F	F	E	F	E	F	G	P	E	P	94	96	Life			
	Wizard Elite 100-7150T	50	ATB/R	15	12	.125	.088	L	F	E	G	G	E	G	G	G	G	E	F	E	96	98	Life			
RIDGE CARBIDE	TS-2000	40	ATB	15	20	.126	.092	L	E	E	G	G	E	E	E	E	E	E	E	F	G	95	101	90 days		
SYSTI-MATIC	10BB40	40	ATB	20	15	.130	.084	L	E	G	G	G	E	E	E	G	G	E	F	G	96	103	Life			
	10BB50	50	ATB/R	20	15	.130	.083	L	G	G	G	G	E	G	E	G	G	F	E	P	95	104	Life			
	10TF55	55	ATB/R	25	15	.110	.079	L	G	G	G	G	E	E	E	E	G	E	F	E	96	101	Life			
TENRYU	Gold Medal	40	ATB	15	20	.111	.078	L	E	E	E	G	E	E	E	E	E	E	E	F	E	95	94	Life		
	Rapid-Cut Planer Combo	50	ATB/R	15	15	.126	.087	L	E	E	E	G	E	E	E	E	E	E	E	G	G	97	95	Life		

**NOTES:**

- (ATB) Alternate-top bevel  
(ATB/R) Alternate top bevel & raker  
(H) Hollow-face
- Bevel angles shown are for beveled teeth. Raker teeth have 0° bevels unless noted in comments.  
\*No bevel due to hollow-face design.
- E** Excellent  
**G** Good  
**F** Fair  
**P** Poor
- Measured 1/8" below gullet and on sides of teeth.  
**E** +/- .001-.002  
**G** +/- .003-.005  
**F** +/- .006-.008
- E** Teeth left no scratches.  
**G** Scratches required hand-sanding to remove.  
**F** Scratches required jointer or belt sander to remove.
- All cuts made in 3/4" thick materials with gullets 1/8" above stock.  
**E** Fine chipping; edge suitable for edge joining or edge-banding.  
**G** Minor chipping; edge suitable for most applications.  
**F** Moderate chipping; requires sanding of edge or filler for some applications.  
**P** Severe chipping; requires filler.
- Test results based on cuts made in high-quality oak-veneer plywood. Lesser-quality materials may increase chipping.
- (MCP) Melamine-coated particleboard
- Measured while ripping 1 1/2" pine at 15 feet-per-minute (fpm) on 1 1/2-hp. saw, and at 38 fpm on 3-hp. saw.
- In decibels, measured at 24" from blade.
- (Life) Warranted against factory defects for the life of the blade.  
(S) Warranted until first sharpening.
- (G) Germany (J) Japan  
(IS) Israel (UK) United Kingdom  
(IT) Italy (US) United States
- Prices current at time of article's production.  
(\*) \$95 for second blade when purchased with the first.



Freud F410



Freud TK306



Ridge Carbide TS-2000



CMT "The General" 214



Jesada CGP-2000



Tenryu Gold Medal



Forrest Woodworker II

COUNTRY OF MANUFACTURE (12)  
SELLING PRICE (13)

COMMENTS

IS	\$ 67	Generous carbide teeth for multiple sharpenings; thick plate for reduced deflection.
IS	59	Generous carbide teeth for multiple sharpenings; thick plate for reduced deflection.
IT	70	Leaves a very smooth ripped edge. Teflon-coated blade.
IT	70	Thin-kerf version of the General 213. Easy feeding for low-powered saws.
US	30	The least expensive blade in the test, but we'd spend just a little more for a Freud blade.
US	47	Excellent results crosscutting solid materials, but ripping thick materials requires slow feed rate.
US	63	Generous carbide teeth for multiple sharpenings. Widely available at retail outlets.
G	59	Generous carbide teeth for multiple sharpenings. Price includes one free sharpening with shipping to Delta.
G	59	Generous carbide teeth for multiple sharpenings. Price includes one free sharpening with shipping to Delta.
UK	65	Well-constructed blade with thick carbide teeth. Widely available in retail outlets.
UK	69	Well-constructed blade with thick carbide teeth. Widely available in retail outlets.
US	65	Good results in solid materials; high-powered saw required for ripping.
US	70	Medium-priced blade that delivers good results.
US	107*	Outstanding sharpening and construction; left the smoothest cut edge in the test.
US	107*	Thin-kerf version of Woodworker II. Easy feeding for low-powered saws.
IT	57	Affordable blade with thick carbide teeth produce excellent results in most cuts.
IT	46	Good-performing blade, but we'd spend \$11 more for the F410 Quiet Blade.
IT	34/39	Inexpensive thin-kerf blade gives good results. Easy feeding for low-powered saws. TKR is Teflon-coated version.
IT	53	Leaves very smooth cut edges; excellent results for a 50-tooth blade.
IT	38/44	Inexpensive thin-kerf blade gives above average results. Easy feeding for low-powered saws. TKR is Teflon-coated.
J	70	Very easy feeding for low-powered saws.
IT	70	Unusual 44-tooth pattern that gives excellent results in most cuts.
IT	67	Raker teeth have 2° beveled edge to reduce tearout.
IT	65	Thin-kerf version of Maxi-Combo. Among the easiest feeding for low-powered saws.
US	42	Very easy feeding for low-powered saws.
J	120	Pricy, but holds sharpness due to outstanding factory-grind and shallow hook and bevel angles.
US	59	Thinner kerf than other "full-kerf" blades makes for easy feeding, even on low-powered saws.
US	39	Thick carbide teeth and Teflon-coated plate. Price includes two free sharpenings.
US	49	Easy-feeding full-kerf blade. Thick teeth and Teflon-coated plate. Price includes two sharpenings.
US	99	Well-constructed blade with generous carbide teeth. One of the top performers in our test.
US	50	Affordable blade gives excellent results in many cuts.
US	50	Affordable blade gives good results in most cuts.
US	75	Unusual 55-tooth pattern gives good results. Thin kerf for easy feeding on low-powered saws.
J	95	A top performer offering a very smooth cut edge and glass-smooth feeding.
J	50	The smoothest-cutting of all the ATB/R blades in our test.

For more information, contact:

Amana  
800/445-0077  
www.amanaatool.com

DeWalt  
800/433-9258  
www.dewalt.com

Jesada  
800/531-5559  
www.jesada.com

Oldham  
800/828-9070  
www.oldham-usa.com

CMT  
888/268-2487  
www.cmtusa.com

DML  
800/242-7003  
www.primarktoolgroup.com

Magna  
800/624-9044  
www.vancouveramerican.com

Ridge Carbide  
800/443-6392  
www.ridgecarbideatool.com

Craftsman  
800/377-7414  
www.sears.com/craftsman

Forrest  
800/733-7111  
www.stores.yahoo.com/forrestman

Makita  
800/452-5482  
www.makitatools.com

Systi-Matic  
800/426-1035  
www.systimatic.com

Delta  
800/223-7233  
www.deltawoodworking.com

Freud  
800/472-7307  
www.freudinc.com

Marathon  
800/866-5740  
www.americanatool.com

Tenryu  
800/951-7257  
www.tenryu.com

For specifications on other types of tools, click on Tool Comparisons at <http://www.woodmagazine.com>.

(94dB from the Tenryu Gold Medal) can be used for an hour without hearing protection. By comparison, the loudest blades from Amana and Systi-Matic, at 104dB, shouldn't be endured for more than 7 minutes unprotected.

### Alright guys, cut to the chase and pick a winner

When all is said and done, we're happy to say there really wasn't a bad blade in the bunch. But 40-tooth ATBs ruled the roost in this test. If you demand a scratch-free, burnished edge on your cuts, the Forrest Woodworker II will do the job—for a price. Ridge Carbide's TS-2000 comes close to that edge quality, but has more side clearance on the teeth and so is less likely to burn your material than the Forrest.

However, we were tickled pink with the cutting performance of three less-spendy blades: Jesada's CGP-2000 (the 44-tooth ATB), CMT's thin-kerf version of "The General", and Freud's new F410 blade. Each model performed about on-par with those more expensive blades, for \$30-40 less.

For low-powered saws, you can't go wrong with the thin-kerf model of the Woodworker II, or either blade from Tenryu: the Gold Medal or the Rapid-Cut Planer (the best of the 50-tooth combination blades). All of these blades breezed through the ease-of-feed test on our contractor-style saw, and come from the factory with an outstanding tooth-grind. Here again, the price and performance of Freud's thin-kerf ATB, the TK306, also makes it an excellent choice in this category.

Written by Dave Campbell  
Technical consultant: Bob McFarlin  
Photographs: Baldwin Photography  
Illustrations: Lorna Johnson

# From Blocks To Bandsawn Boxes

*Along with pro boxmaker Jerry Patrosso, we show you the basics; after that, the sky's the limit.*



Craftsman Jerry Patrosso makes all three of these finished bandsawn boxes from a single block of redwood burl. You can, too, with the tips Jerry shares here.

## First, a few box-making essentials


Although bandsawn boxes may appear complex, they're incredibly simple to make. All you need is a sturdy bandsaw and a few ideas to get you started. With that in mind, in the first part of this article we'll present the steps for making four simple bandsawn boxes. Each succeeding one increases slightly in complexity and teaches a different aspect of this craft. If you're new to bandsawn boxes, you may want to make all four from scraps of glued-up 2x4s. Once you feel comfortable, move on to fancier woods.

Your practice cuts also will tell you if your bandsaw is up to the task of cutting thick wood. First, equip the saw with a sharp, ¼"-wide, 6 teeth-per-inch, hook-tooth blade, and adjust

the saw for a cut that's exactly 90° to the table. (You'll also need a similar ⅛" blade for some tight cuts.)

Get a feel for the cutting power of your saw by testing it in soft and hard woods up to 5" thick. Most benchtop bandsaws, and some stationary models, can't muster the power to cut hard or thick woods. You may find that you'll need to invest in a saw with at least a ¾-horsepower motor to cut stock more than a couple of inches thick. A quality set of blade guides will keep the blade from bowing sideways.

In the second part of this article, we will take you into the shop of box maker extraordinaire Jerry Patrosso.



He'll show you how to craft the set of three boxes shown above.

Like Jerry, we prefer to cut bandsawn boxes from fanciful burls or spalted woods. Blocks of these materials can be expensive, but as you'll see, little stock goes to waste when you make a bandsawn box. If you favor a contemporary look, try laminating a block made of several species. You could, for example, laminate a walnut stripe within a maple block.

*Continued*



# LET'S GET THINGS ROLLING WITH FOUR BASIC BANDSAWN BOXES

You can make any of these boxes by simply following the step-by-step illustrations. We did not include any dimensions because you can make them big or small depending on your needs and available stock. We do provide a full-size pattern of the heart-


shaped box (#4) in the *WOOD PATTERNS*® insert. Make your entry cuts with the grain of the project pieces so they conceal better when you glue and clamp them to close up the blade kerfs. We think you'll have a lot of fun with these—we did!

*Note: Use sharp blades, and round their backs by touching a file or stone against the back corners as the saw runs. This will help the blade negotiate tight turns. Be sure to hold the file or stone firmly on the table, and go lightly when touching it to the*

*blade. And always clean the bandsaw of dust to prevent any sparks from igniting a fire. Even after rounding a 1/8" blade, you may find that to negotiate some especially tight turns you will need to use a 1/8"-wide blade (round it, too).*



## 1 Basic Open Box



**STEP 1**  
Saw off bottom.


**STEP 2**  
Saw out center, and glue entry cut closed.

**STEP 3**  
Position bottom in its original orientation, and glue it back on.

**STEP 4**  
Shape and sand smooth the outside of box.



## 2 Basic Box With Sliding Lid



**STEP 1**  
Saw off bottom, then saw off lid with interlocking cuts.


**STEP 2**  
Saw out center, and glue entry cut closed.

**STEP 3**  
Position bottom in its original orientation, and glue it back on.

**STEP 4**  
With lid taped in place, smooth outside of box.



## 3 Basic Box With Lift-Out Tray



**STEP 1**  
Saw off bottom of box. Saw out center, and glue entry cut closed. Glue bottom of box back on.

**STEP 2**  
Saw out center of "waste" to be used as tray bottom.

**STEP 3**  
Saw out two sections to create tray. Glue entry cuts closed.



**STEP 4**  
Saw out center section to create tray support. Glue entry cut closed.

**STEP 5**  
Glue center section formed in Step 2 to bottom of tray.

**STEP 6**  
Glue section formed in step 4 to bottom of box to form a support for the tray to sit on.

# Bandsawn Boxes

## 4 Basic Box With Locking Lid Pin



Jerry Patrasso with a boxelder burl that he discovered in a public park and saved from a certain fate as firewood.


## How to squeeze three bandsawn boxes with hinged lids from a single block of wood

After profiling Jerry Patrasso in the December 1993 issue of *WOOD* magazine, we knew he had the art of bandsawing great-looking boxes down to a fine science. After all, by his own estimation he has made about 10,000 bandsawn boxes.


It took us a while, but we finally returned to Boulder, Colorado, where Jerry lives, so that we could share his techniques with you. Here's how he makes the set of boxes shown on the *first page* of this article. Each of these boxes goes together as shown in the Exploded View drawing at *right*.

**1** Jerry starts with a block of wood that's about  $3\frac{3}{4} \times 5\frac{1}{4} \times 6$ ". The block should be square and flat in all three dimensions. First, he bandsaws two  $\frac{1}{4}$ "-thick pieces off one of the  $5\frac{1}{4} \times 6$ " sides of the block for "side stock" to be used later. Smooth the just-sawn face of the block. (Jerry uses a stationary disc sander with 80-grit paper.) Recheck the block for square.

**2** On a  $3 \times 5\frac{1}{4}$ " piece of stiff paper (like card stock) mark three concentric templates, as shown in the Box Blank Templates drawing on the *last page* of this article. You will later




An awl or other sharp object serves as a pivot point for marking the lid clearance on the template.



Mark the template outline on the end of the block. Also mark the lid lip and hinge clearance.



Hold the block firmly on the table with one hand and use a pushstick to guide the portion of the block near the blade.



A sanding spindle with an aggressive abrasive, such as 50-grit, quickly smooths out the bandsaw blade marks.



Use a #53 bit to drill the hinge-pivot holes into both ends of the box blank. Stabilize the bit with stop collars.

use the templates to mark the bandsaw cuts onto one end of the block.

Note that Jerry allows about  $\frac{3}{32}$ " of space between each template for a bandsaw kerf and sanding. Cut the three templates to shape with a pair of scissors, but do not cut along the lid lip cuts or the cuts below the hinge pins. Mark the locations for the lid lips, lid clearance, and hinge pins on the card-stock templates.

Note on the templates that we've determined how much stock you need to remove to allow the hinged lid to swing freely. Should you make a

set of larger boxes, you can determine this clearance by using a pencil and awl as shown in *Photo A*. Just cut the template lid off, then pin the lid down with the awl at the hinge pin location. Pivot the lid, and follow it with a pencil to mark the needed clearance.

**3** Place the largest template on the block, and trace its outline as shown in *Photo B*. Transfer the lid lip, lid clearance, and hinge pin locations onto the block of wood. Place the template on the opposite end of the block to mark the other hinge pin location.

**4** To make the large blank, enter the cut through the lid lip, saw out the inner blank, and back out of the cut through the lid lip (see *Photo C*). Hold the block down firmly as you saw it to ensure 90° cuts.

*Continued*

# Bandsawn Boxes



Lightly touch one end of the lid to a disc sander to reduce its width by about  $\frac{1}{64}$ " uniformly along the end.



Brass or bronze brazing rod makes for sturdy hinge pins. Nip the pins so they stick out  $\frac{1}{8}$ " from the lid.



Use the hinge pin already placed in the lid to mark its matching location on the side pieces.

Set the inner block aside so you can use it later for creating the medium and small boxes. In the following steps we'll continue building the large box. Simply repeat all steps beginning with #3 to complete the medium and small boxes using the inner block. Remember to square the inner block on your disc sander before marking it for the medium blank. (If your bandsaw cuts are square you should have to do just light sanding.) Do the same before cutting out the small blank.

**5** Smooth the inside of the box with a  $\frac{3}{4}$ " sanding spindle outfitted with 50-grit abrasive, as shown in *Photo D*. Jerry uses his drill press, but an oscillating spindle sander works well, too.

**6** With a #53 bit, drill a  $\frac{1}{4}$ "-deep hole at both hinge pin locations in the lid, as shown in *Photo E*. Jerry uses four stop collars (two visible in the photo) to stabilize the bit and prevent it from bending or breaking. The collars also come in handy if your drill-press chuck won't go down to the small diameter of a #53 bit. Just be sure to mount the collars to the bit so the bit stays centered in the chuck.

**7** Jerry uses a #53 bit because it's just slightly smaller than a  $\frac{1}{16}$ " bit. That way, the  $\frac{1}{16}$ " hinge pin has enough friction to hold the lip up and prevent it from slamming down due to looseness.

Separate the lid from the blank by cutting away the lid-clearance material. Err on the side of removing slightly too much material to avoid a lid that won't swing freely later.

**8** Straighten the bottom lip as marked on the *Box Blank Templates* drawing. Jerry does this on his stationary disc sander.

**9** Smooth the inside surfaces of the lid and bottom with 120- and 220-grit abrasives. Then, narrow the width of the lid by about  $\frac{1}{64}$ ". Jerry again turns to his trusty disc sander for this task, as shown in *Photo F*.

**10** Determine which sides of your side stock surfaces will face the inside of the boxes. Then, sand out the bandsaw marks on those sides with an 80-grit belt in your stationary sander. Smooth these surfaces further with a hardwood sanding block and 120- and 220-grit abrasives. Be careful to keep the sanded surfaces flat.

**11** Insert a length of  $\frac{1}{16}$ " bronze or brass brazing rod into a hinge pin hole and nip it off so  $\frac{1}{8}$ " of the rod protrudes, as shown in *Photo G*. Repeat for the other hinge pin.

**12** Cut two pieces of side stock to  $3\frac{1}{8} \times 5\frac{1}{8}$ ". Place one piece flat on a bench, inside surface up, and position the lid, as shown in *Photo H*. Mark the position of the hinge pin on the side stock by pressing the pin into


the side. Be sure to position the lid so there is excess side stock along its edges. (You'll sand this away later.) Repeat *Steps 11* and *12* for the other piece of side stock.

With the #53 bit, drill holes just a hair more than  $\frac{1}{8}$ " deep at the marked indents on the sides.

**13** Align the pin holes on the sides with the pins in the lid, and dry-clamp the side pieces to the box lid and bottom. Position the pieces with excess side stock all around the edges of the lid and bottom. Check to make sure the lid will open. If it doesn't, remove more stock from the hinge clearance area.

Once you're satisfied with the fit of these parts, disassemble them and apply yellow glue to the ends of the box bottom, as shown in *Photo I*. Repeat for the other side and reclamp the assembly. Check the gaps at the hinge and lid lip; you usually can equalize small gaps by shifting the clamps slightly.

**14** Allow the glue to dry, and remove squeeze-out with a sharp chisel. With a disc sander and 80-grit abrasive, sand the bottom, back, and front surfaces of the box, in that order, to bring the sides flush with those surfaces. Use a light touch and don't overheat the wood—that could cause it to warp. Next, equalize



the gaps on both ends of the lid with a light sanding, as shown in *Photo J*. Then, sand the top of the box. Go back to the disc sander and round over the four long edges of the box.

**15** Remove all sanding marks on the outside of the box with a 150-grit belt in a stationary sander. Then, hand-sand the outside with 220-grit abrasive, and sand the entire box with 400-grit paper.

Make a centered mark on the bottom lip. Mark  $\frac{1}{2}$ " on both sides of the center, and use a drum sander to cut a shallow finger recess, as shown in *Photo K*.

Blow, vacuum, or brush all dust from the box, and apply the finish of your choice. Jerry wipes on his own polyurethane/tung oil mix, but you can achieve similar results by applying an oil/varnish blend, such as Antique

Oil Finish from Minwax or Olympic. After the finish dries, Jerry uses a bench grinder and buffing wheels to buff the outside with tripoli compound, and polish the surfaces with carnuba wax. 🐿

Written by Bill Krier with Jerry Patrasso and Jim Downing  
 Illustrations: Kim Downing; Lorna Johnson  
 Photographs: Tim Murphy/Foto Imagery; Marty Baldwin



Prevent squeezeout on the inside of the box by wiping the glue bead away from the inside edges of the lid and bottom.



Use a gentle touch with a disc sander to equalize the gaps between the box lid and sides.



Use a spindle sander to make a 1"-long finger recess along the bottom front edge of the box.



# A Keepsake

## Elegant results from

**Watches, rings, and other precious things deserve a home that matches their good looks. You can provide one in this handsome hardwood keepsake box. It's compact, but a pair of trays and a drawer provide plenty of room to organize jewelry and other valuables. Best of all, the simple techniques and epoxied joints make it easy to build.**

### Glue up a building block

*Note: Unlike the burls often used as raw materials for bandsawn boxes, the block for this project has to be glued up from milled stock—a board at least 1½×6×26". You'll also need to resaw and plane a board into ¼"-thick and ⅜"-thick material for the drawer end caps and box side panels (Exploded View). For this project we recommend a stable hardwood, such as walnut, cherry, or mahogany. Tropical woods are another option. (See our Buying Guide on opposite page.)*

**1** Glue up four pieces of 1½"-thick stock for the center block. The finished block should measure 5¾" high by 5⅞" wide by 5⅞" long. With a bandsaw and a stationary disc sander, you can trim an oversize block to the

required dimensions and true up all the faces. Or mill each of the four layers exactly to size, and use clamping cauls to keep all the edges and faces properly aligned while the glue dries.

**2** After you clean off any glue squeeze-out and sand the block smooth, use spray adhesive to affix a copy of the Core Side View pattern from the *WOOD PATTERNS*® insert onto one end of the block.

### Cutting the basic box parts

*Note: For best results, install a new ⅛" blade on your bandsaw and tune the table so it's dead square to the blade. Any error will produce a box that doesn't fit together cleanly.*

**1** Following the pattern's outlines and easing through the corners, bandsaw the lid (B), the tray body (C), and the

drawer body (D) from the box core (A). Then cut the three "pockets" in the box core's fixed tray.

**2** Sand all of the cuts smooth with 100-grit and then 150-grit sandpaper. (For the inside curves, it helps to wrap the sandpaper around a dowel.)

Next, set your tablesaw's rip fence to 4⅞" and cut the drawer and tray bodies to that length. You'll need this clearance to add the end caps.

**3** Using your bandsaw and a ¼" or wider blade, resaw ⅜" stock for the side panels (E) and ¼" stock for the drawer and tray end caps (F, G). Plane or sand the stock smooth and cut it to the sizes shown in the Bill of Materials.

**4** Test-fit the parts by clamping the side panels to the box core (without glue); then insert the drawer and lift-out tray parts (including end caps) to see if they fit with the correct clearance. Recut the center portion of either assembly if it proves too long.

**5** Once everything fits properly, you're ready to glue up the box. (We used epoxy to bond the parts together because it dries clear, and its bead is thick enough to form a small fillet where the end caps and side panels meet their respective center parts. When finish is applied, the exposed adhesive becomes nearly invisible.)

Place one side panel (E) on waxed paper (outside face down). Use a cotton swab or other small applicator to spread a uniform layer of epoxy on one end of the box core (A), then carefully place it on the side panel. No clamps are required, but allow the epoxy to set up before handling the assembly or gluing on the other side panel. Repeat this procedure for the tray and the drawer.

After the epoxy in all the joints has cured (which will vary according to the resin type and the ambient temperature), sand off any residue from the outside surfaces.



# Box Worth Keeping

a simple bandsaw technique

## Fit the lid and the hinge pins

**1** Cut or sand about  $\frac{1}{32}$ " from the length of the lid to provide clearance for it to open and close without binding. When you've got a good fit, use a cardboard spacer (the back of a note pad works great) as a shim between the back edge of the lid and the upper edge of the box core, then tape the lid in place with masking tape.

**2** Make layout marks at the rear corners of the box, where the hinge pins will go (Hinge Pin Detail). With the lid taped in place, drill a  $\frac{1}{8}$ " hole  $\frac{3}{4}$ " deep through each side panel, into the ends of the lid, as shown in *Illustration A*.

**3** Cut two  $1\frac{1}{2}$ "-long pins from a length of  $\frac{1}{8}$ "-diameter round brass rod; lightly chamfer the leading end on each. Now tap them into the holes you drilled. Make sure the lid opens and closes properly. If you need to adjust it or trim more length, pull the hinge pins and remove the lid. After you get a good fit, reinstall the pins and trim them off with a hacksaw; then sand them flush with the side panels.

## One last detail—then finish




**1** To keep the outside lines of the box clean, we opted for a drawer pull cutout rather than a knob. First, install a  $\frac{3}{4}$ " straight bit in your router table; then clamp stopblocks to the fence to control the drawer's travel from side to side, as shown in *Illustration B*.

Make a test cut on a scrap block the same size as the drawer front, and limit the cut depth to about  $\frac{1}{8}$ ". When the setup is right, make a first pass in the drawer. Raise the bit again in  $\frac{1}{8}$ " increments for another two passes or until the cutout is routed clear through the drawer front.

**2** Apply several coats of a penetrating oil finish. (We used Minwax Antique Oil.) Line the drawer opening with felt if you want; then you can find some small treasures to take up residence in your new creation. 🌿

Written by Bill LaHay  
Photography: John Hetherington  
Illustrations: Roxanne LeMoine;  
Lorna Johnson

<http://www.woodmagazine.com>



## Bill of Materials

Part	Finished Size			Mati.	Qty.
	T	W	L		
A box core*	5 $\frac{1}{8}$ "	5 $\frac{1}{8}$ "	4 $\frac{3}{4}$ "	**	1
B lid*	1 $\frac{7}{8}$ "	5 $\frac{1}{8}$ "	4 $\frac{3}{4}$ "	**	1
C tray body*	1 $\frac{7}{8}$ "	4 $\frac{3}{8}$ "	4 $\frac{1}{8}$ "	**	1
D drawer body*	1 $\frac{9}{16}$ "	4 $\frac{7}{8}$ "	4 $\frac{3}{16}$ "	**	1
E side panels	$\frac{3}{8}$ "	5 $\frac{1}{8}$ "	5 $\frac{3}{4}$ "	**	2
F tray end caps	$\frac{1}{4}$ "	1 $\frac{7}{8}$ "	4 $\frac{1}{2}$ "	**	2
G drawer end caps	$\frac{1}{4}$ "	1 $\frac{9}{16}$ "	4 $\frac{7}{8}$ "	**	2

\* Note: These parts feature irregular shapes due to the nature of the project design and technique. The dimensions shown reflect the overall space they occupy, but not the specific contours. See the *WOOD PATTERNS*® insert for details.  
\*\*Materials Key: See introductory note, page 74.

**Buying Guide:** For tropical species for this project you can order blanks (surfaced two sides and sized at  $1\frac{1}{2}$ "x6"x26") in African padauk, black limba, bubinga, lacewood, sapele (quarter-sawn), or shedua for \$35 each or three for \$95, including shipping in the continental United States. Contact Woodworkers Source, 5402 South 40th St., Phoenix, AZ 85040, 800/423-2450.

Carved wooden figures  
once were...

# The Signs of The Times

At the turn of the century, there may have been as many as 100,000 hand-carved shop figures advertising America's businesses and products. Today, they're rare. Here's their story and a look at some classic survivors.

## A. BLACKAMOOR WITH KEG

Artist unknown.  
Probably England;  
c. mid-18th century.  
20½" high.



In the days before every American citizen was guaranteed an education, many people could neither read nor write. So to sell goods and services back then, merchants and professionals put carved displays and symbolic signs outside their shops and workplaces to denote what they offered. The most famous of these was the "shop figure," as collectors call them. And the most recognizable of shop figures to us is the cigar-store Indian, although the carved figures frequently represented other personages.

The Indian became such a well-known symbol primarily because of Sir Walter Raleigh's efforts, although he wasn't aware of it at the time. It seems that the English nobleman introduced tobacco grown and smoked by the Indians of the Virginia Colony to England in the 1600s. Known as "Indian weed," it became so popular that storekeepers started to specialize in selling it. But cleverly promoting tobacco posed a problem—until someone thought to associate the puffable leaf with an Indian figure. In a short time, the cigar-store Indian became a marketing hallmark.

The cigar-store Indian first showed up in America during the Colonial



## B. MALTZBERGER INDIAN

Artist unknown.  
Probably New York City;  
c. 1845. 44" high.



Period, but by the mid-1800s they proliferated. Every tobacco store had a carved Indian image—or something related—to help sell its goods. The carved figures were used for other purposes, too. They marketed liquors; pharmaceuticals; clothing; tea; and services, such as banking and insurance.

According to experts at the Museum of American Folk Art in New York City, carved shop figures reached their peak in the U.S. between 1840 and 1890. As one reporter wrote back then, “Few objects—policemen and lampposts excepted—are more familiar to the general public than the cigar-store wooden Indian.” By 1900, though, the production of such figures literally had ceased because they had been replaced by metal signs and other forms of advertising.

### Shaping the image business

As with the making of classic American furniture, shop figure carving had its origin in Europe. Art historian Ralph Sessions, who curated a shop-figure exhibit at the Museum of American Folk Art in 1998, believes the earliest known tobacco figure showed up in an English shop in 1617. It was countertop size, and depicted an African-appearing person in a feathered kilt holding rolled tobacco leaves under his arm. Figures such as that remained popular in England for 200 years, but were joined by other human types, all mostly executed in quarter- or half-size.

In Europe, and later in America, carvers of shop figures were trained in traditional techniques that were applied to maritime carvings. Indeed, most American shop-figure carvers were well skilled at ship’s figureheads. So from their shops in Eastern port cities—and to some extent along the Great Lakes—they



**C. VOLUNTEER FIREFIGHTER**  
Columbian Engine Co. 14.  
Incised “S.A. Robb, 195 Canal St.  
New York City; 1876-1888.” 29” high.

turned out tens of thousands of promotional carvings. The carvers themselves coined the catch phrase “the image business” to characterize the wide range of figures they were asked to create.

It wasn’t until the late 18th century, however, that life-size figures began to appear. Historical accounts cite Philadelphia sculptor and ship carver William Rush as the man who changed the course of shop figures to this larger scale after he spotted full-size figureheads on two French ships in port for repair. The larger-scale carvings were called “show” figures, and by the 1850s they were produced in remarkable variety. While the cigar-store Indian was the most prominent, show figures represented sports personalities, politicians, entertainers,



**D. GIRL OF THE PERIOD**  
Artist unknown.  
New York City;  
c. 1870. 68” high.

## A heritage of carved signage

### A. Blackamoor with keg

This inventive African figure represents the oldest form of English tobacco figures. In England, the black man image was associated with exotic, far away lands. Virginia, the source of tobacco, was thought to be such a place, which explains the association. At the time, little was known of what American Indians looked like. In the collection of the Museum of American Folk Art.

### B. Maltzberger Indian

After opening his tobacco shop in Reading, Pennsylvania, in 1847, John Maltzberger purchased this figure. It stood in front of the Maltzberger Cigar Store until 1928. Its pose is representative of the style carvers used for ship figureheads. The figure is in the collection of the Historical Society of Berks County, Reading, Pennsylvania.

### C. Volunteer Firefighter

Firemen’s courageous actions were widely acclaimed. This is thought to be a heroic commemorative figure carved after the engine company had long been disbanded, as indicated by the 1860-style uniform, and replaced by professionals. Owned by the New York City Fire Museum.

### D. Girl of the Period

This figure caricaturizes the fashion-conscious young women of the time in urban America. It was found in Calais, Maine, and belongs to the New York State Historical Association, Cooperstown, New York.

### E. Turk (see next page)

Figures of this type could be used in a variety of circumstances, depending on the proprietor’s needs. This figure, found in Camden, Delaware, may have been used by a tobaccoist, although it doesn’t have identifiable accessories to associate it with tobacco. Turkish figures were associated with tobacco from Turkey, especially in Great Britain. In the collection of the Museum of American Folk Art.

### F. Father Time (see next page)

Father Time is a stylized figure that might have been used in a shop as a type of doorbell. His left arm once could move so that the sickle hit the suspended bell. In the collection of the Museum of American Folk Art.

*Continued*

# The Signs of the Times



**TURK**  
Artist unknown.  
Probably New York City or Philadelphia;  
c. 1875. 77" high.

fictional characters, and such heroes as George Washington and Buffalo Bill Cody.

Ship carvers, bound by family and apprenticeships, were close knit. But they moved a lot, leaving partnerships and closing shops to seek business opportunity. Yet, they often followed styles developed by master carvers, who frequently reflected changes in the other decorative arts as well as printing and publishing.

That's why today it's easier to surmise when a figure was carved than who created it.

## Carving comes to an end


A large carving shop that produced shop figures or ship carvings might have two master carvers, some apprentices, and one or two traveling journeymen carvers, depending on the number of orders to be filled. Some carvers worked alone.

Eastern white pine was generally the material of choice for carvers of shop figures. In port cities, it could be bought in 3'- to 7'-long ship-mast sections at spar yards. Inland to the Midwest, it also was readily available from logging companies and other wood sources.

A shop figure, especially a highly popular model, would begin with a pattern. Other times, just the carver's eye would determine where the contour lines were drawn on the wood. Rough shaping was done with axes and adzes. Mallets and chisels created the details. The final figure was generally painted brightly and gilded.

Although other forms of advertising had replaced and outperformed the carved shop figure by the beginning of the 20th century, the traditional ship carvers who created them had by then become craftsmen of the past anyway. Their trade had been sunk years earlier by the development of the metal-hulled ship. ♣

This article was drawn from historical material provided by the Museum of American Folk Art, Two Lincoln Square, New York, NY 10023-6214 ([www.folkartmuseum.org](http://www.folkartmuseum.org)).



**FATHER TIME.**  
Artist unknown.  
Mohawk Valley, New York;  
c. 1910. Wood, metal, hair. 52" high.

Written by Peter J. Stephano  
Photographs: Courtesy of the Museum of American Folk Art, New York City




## One-handed table-routing with a two-wheel fence

Feather boards on a router table are great for keeping your work snug against the fence and tabletop, especially when all of the pieces are fairly narrow and the same width. But wide or varying-width workpieces can be a major headache: Either you can't use the feather board at all, or you have to readjust it for every piece.

To ease your stock-holding woes, the folks at Rousseau came up with the Deluxe Router Fence, which mounts easily even to shop-built router tables. Instead of flexible feathers, this dandy accessory uses a pair of rubber wheels toed 5° toward the fence. These rubber wheels force a workpiece solidly against the fence, while their stiffly spring-loaded arms keep the stock dead flat on the table. You only need to provide the feeding action.

Besides the wheels, the Deluxe Router Fence also incorporates a granny-shoe shaped hold-down (with a clear acrylic bit guard). You position



it directly over the router bit to reduce bit chatter. It also offers downward pressure—but no lateral pressure—when working on pieces too narrow to use the wheels. Therein lies my one minor criticism of the Deluxe Router Fence. The wheels make effective contact only on stock that's wider than 2".

—Tested by Dave Henderson

### PRODUCT SCORECARD

#### Rousseau RM3301DL Deluxe Router Fence

Performance	★ ★ ★ ★ ☆
Price	\$139
Value	★ ★ ★ ★ ☆

For a Rousseau dealer near you, call 800/635-3416.

## Locking tape doubles as a quick-change artist

It's Christmas Eve. You're rushing to finish up building that last gift, and as your retracting tape snaps back into



its case, you hear the sickening sound of the broken blade spinning inside. Now what? Well, if you have a Craftsman E-Z Change locking tape, you simply reach into the drawer for a replacement blade, and five minutes later, you're back in business.

Truly, this is the only tape I've seen that changes out that quickly. The bottom of the case slides open so that you can remove the old blade without tearing the case apart. Then the new blade hooks onto a tail of blade attached to the hub. In fact, if you're just replacing a worn blade, you don't need to open the case at all: Just pull the blade all the way out, slip a nail into the tail, hook the new blade on as shown at left, and remove the nail.

The tricky part about replacing any broken blade is in resetting the spring tension, and it's here that the E-Z

Change really shines. Using the tool's external ratcheting mechanism I easily wound the spring to its proper tension. Actually, I purposely overtightened the spring, but, by pushing in the winding tab, readjusted the tension until it was perfect.

Besides the 25' tape I tested, the E-Z Change comes in 12', 20', and 30' lengths. A replacement blade runs about \$4, and it's worth it to have one on hand for emergencies. And with Craftsman's lifetime warranty, you can simply take the broken blade back to Sears at your convenience for a free replacement.

—Tested by Bob McFarlin

### PRODUCT SCORECARD

#### Craftsman E-Z Change Locking Tape

Performance	★ ★ ★ ★ ★
Price	25', \$14; 30', \$16
Value	★ ★ ★ ★ ☆

For more information, call 800/377-7414, or visit the Craftsman tools website at [www.sears.com/craftsman](http://www.sears.com/craftsman).

Continued on page 82



Continued from page 80

## Roll out the barrel-shaped Ply Prep bit before banding

Because of its dimensional stability, many woodworkers prefer hard-wood-veneer plywood for cabinet

work. But the ugly, layered edges of plywood detract from the beauty of the project unless they're capped with a strip of solid-stock edging. It is for this process that the Ply Prep router bit was created.


The theory behind the Ply Prep bit (it looks like a slightly chubby straight bit) is that plywood's inner plys expand when you apply glue, pushing the edging away. Chuck the bit into your router, center the bit's mark on your plywood, and—using a straightedge guide—rout the edges. The bit cuts a shallow cove in the edges of the workpiece, slightly relieving those inner plys, giving them room to expand, and preventing a bulge.

After milling the edges of some plywood shelves with the Ply Prep bit, I noticed that my solid-stock edging joints came together tighter than before, with virtually no clamping pressure. In fact, I found I could hold the stock in place with just a few

pieces of masking tape along the edge. And, with no clamping, there was no glue squeeze-out. As a bonus, the bit left me with chip-free edges on my plywood.

The Ply Prep router bit removes some of the plywood's face and back when it does its thing, so you need to cut your pieces slightly oversized. For the same reason, I found it difficult to use in a router table, unless you can slightly offset the outfeed fence of your router table (like the table of a jointer).

—Tested by Bob McFarlin



### PRODUCT SCORECARD

#### Ply Prep router bit

Performance	★ ★ ★ ★ ☆
Price	1/4" or 1/2" shank, \$28 ppd.
Value	★ ★ ★ ★ ☆

Call Collins Tool Company at 888/838-8988.

### Buy Our Best Seller

10" x 40T only \$107  
or \$95 on 2nd blade

#### EXTRA BONUS! 9 AT \$5 EACH!

Buy a blade or dado and get \$43 worth of sharpening discount coupons from Forrest, good on any make blade or dado set you own. The first 100 customers will receive a FREE Picnic Table Plan and Router poster!

### THE ONE BLADE THAT LEAVES A SMOOTH-AS-SANDED SURFACE



Outperformed 36 other premium blades, both foreign and domestic, WOOD magazine test, Sept. 1998, pg. 45.

### DURALINE HI A/T

7 1/4" to 16" diameter available  
Cuts melamine PERFECTLY. 220 mm & 300 mm available. Our best PLYWOOD blade. 8", 7 1/4" & others available

	Sale Price	10% Off 1st Blade	20% Off 2nd Blade
10" x 80 T (1/8" or 3/32" K)	\$159	\$143	\$127
12" x 80 T (5/8" or 1" hole, 7/8" K)	187	163	145
14" x 80 T (1" hole)	197	177	158
14" x 100 T (1" hole)	225	203	181
16" x 100 T (1" hole)	245	219	194

### BUY ONE & SAVE - BUY MORE & SAVE MORE

Buy any sawblade or dado in this ad and save 10% off the sale prices. Buy additional sawblade(s) or dado(s) and save even more—15% to 20%! Sale good through January 31, 2000.

#### WOODWORKER II

5 3/8" to 14" diameter available

All-purpose—tablesaws and portable circular saws.

Special 10% Discount! Take 20% off second blade of your choice.

EDITOR'S CHOICE AND TOP RATING OVER 18 COMPETING SAW BLADES.

The 10" x 40T earned the Editor's Choice Award for the best performance regardless of the price. See American Woodworker magazine, April 1998, pp. 68-69.

	Sale Price	10% Off 1st Blade	20% Off 2nd Blade
14" x 40 T x 1"	\$149	\$134	\$119
14" x 30 T x 1"	139	125	111
12" x 40 T x 1"	129	116	103
12" x 30 T x 1"	119	107	95
10" x 40 T x 1/8" or 1/32"	119	107	95
10" x 30 T x 1/8" or 1/32"	99	89	79
9" x 40 T	109	98	87
9" x 30 T	99	89	79
*8 1/4" x 40 T x 3/32"	99	89	79
8" x 40 T x 3/32"	99	89	79
8" x 30 T x 3/32"	89	80	71
7 1/2" x 30 T x 3/32"	69	62	55
**6" x 40 T x 3/32"	69	80	71
***5 1/8" x 40 T x 10mm	69	80	71

NEW for \*Sears & Makita Table Saws \*\*Saw Boss \*\*\*Dewalt Cordless

**BLADE STIFFENER**  
Make all your blades cut better and quieter with a blade stiffener!

- 4" ...\$21
- 5" ...\$24
- 6" ...\$25

#### CHOPMASTER BLADE

6 1/2" to 15" diameter available  
Specially designed for sliding compound miter, miter-chop, and radial saws.

	Sale Price	10% Off 1st Blade	20% Off 2nd Blade
6 1/2" x 40 T Delta, Sidekick, & Others	99	\$89	\$79
8 1/4" x 60 T Sears, Delta, Ryobi	109	98	87
8 1/2" x 60 T Hitachi, Dewalt, Ryobi, FreudTR125	119	107	95
9" x 80 T Delta & Others	129	116	103
10" x 80 T Delta, Bosch, Mitachi, Makita, Ryobi, AEG, & All	139	125	111
12" x 80 T Dewalt, Hitachi, Makita, Sears, & All	149	134	119
14" x 100 T Makita, Ryobi	189	170	151
15" x 100 T	199	179	159

#### WOODWORKER I

7 1/4" to 14" diameter available  
Designed for radial arm or tablesaws—fine crosscut.

	Sale Price	10% Off 1st Blade	15% Off 2nd Blade
8", 8 1/4", 7 1/4" x 60 T	109	\$98	\$87
10" x 60 T (5/8" hole)	129	116	103
12" x 60 T (5/8" or 1")	139	125	111

CANADA SALES: CMR RON COLLIER  
3644 SCHUMANN RD., BAY CITY, MI 48706  
Phone 800-229-4814, FAX 517-684-0402

### FREE SHIPPING

on orders over \$200 'til Jan 31, 2000  
All Major Credit Cards Accepted  
FL, NJ, NY Residents - Please add Sales Tax  
YOUR SATISFACTION GUARANTEED!

### EXCLUSIVE OFFER



Select one of these items FREE when placing an order for any saw blade or dado purchase from this ad in Wood magazine. Choose from the eight book titles shown, imprinted cap. or 16 oz. can of spray blade cleaner. **Hurry!** This special offer is limited while supplies last on orders placed by January 31, 2000.

### FORREST DADO-KING

Unmatched Precision on Every Dado Cut! The Forrest Dado-King gives you flat-bottomed grooves and no splintering—even when crosscutting oak plys and melamine! This award-winning set comes with six 4-tooth chippers (including 3/32" chipper), two 24-tooth outside blades plus shims. Cuts 1/8" to 29/32" grooves.

	Sale Price	10% Off 1st Dado	15% Off 2nd Dado
6" Set	289	\$242	\$229
8" Set	299	260	245
10" Set	349	314	297
12" Set	449	404	382

**FREE CARRYING CASE**  
10" Blade Runner Case with 6, 8, or 10 Dado Sets \$21 Value.  
**"EASY-FEED" STANDARD DADO**  
For solid hard and soft woods only! (No plys, no melamine!) 8" D. with positive hook 24 tooth blades & 2 tooth chippers and shims. Cuts 1/8" to 1 1/2" wide.  
**LIST SALE 15% OFF**  
\$249 \$218 \$196 \$185

**2-4 Days Sharpening on ALL MAKES OF CARBIDE BLADES**  
Western Canada Call European Sharpening 403-287-0850

# FORREST FORREST MANUFACTURING COMPANY, INC.

ORDER BY MAIL: 457 River Road, Clifton, NJ 07014 • BY PHONE: 800/733-7111 (IN NJ: 973/473-5236) • BY FAX: 973/471-3333  
SEE OUR INTERNET STORE AT woodmall.com OR stores.yahoo.com/forrestman

## Make interchangeable dovetails? You can with this jig

When I first laid eyes on the Universal Jointer dovetail jig, I was impressed with the way it provided full-support for a router base. Now that I've had my hands on it as well, I'm also amazed at the repeatable accuracy with which it makes joints, including box joints, rabbets, tenons, and sliding (but not half-blind) dovetails.

Most through-dovetailing jigs require two routers (one to cut pins, and the other to cut tails) because you mount both workpieces in the jig at the same time. With the Universal Jointer, you can cut all the pins on a kitchen full of drawers, change bits, then cut all the tails. And when you're done, any two pieces will fit together perfectly.

### PRODUCT SCORECARD

#### Universal Jointer

Performance ★ ★ ★ ★ ☆

Price \$239

Value ★ ★ ★ ★ ☆

For a dealer near you, call Universal Fixtures at 724/733-8644.

How can the Universal Jointer make dovetail joints so interchangeable? First, instead of a series of moveable forks, this jig uses a pair of precision-cut, phenolic-coated, marine-plywood templates to pilot your router through the cuts. Because the openings on the templates never change, every pin and every tail comes out identical.

Secondly, the Universal Jointer sports a stepped aluminum pin and a series of registration holes that positively locate each workpiece. When used with the eccentric spacing block, I could move the jig in precise 1/8" increments. Using the templates and locating pin, I bet you could cut dovetail pins all day, disassemble the jig, come back a year from now, and cut perfectly mating tails.

To make spacing almost foolproof, much of the extensive instruction manual is devoted to charts showing which combination of templates, bits, registration holes, and pins result in different joint patterns. Unfortunately,



it doesn't devote much space to centering the pattern on different widths of stock, so I ended up centering by trial-and-error. One other minor criticism: The Universal Jointer requires 14° dovetail bits, which make for strong joints, but I had trouble finding and buying some of the sizes specified in the charts (such as 5/8", 7/8", and 1").

Finally, unlike other jigs, the jig clamps to your workpiece, and the workpiece to your bench. So, you can join stock longer than your bench's height, even if you need a ladder to do it. The Universal Jig can handle workpieces up to 18" wide.

—Tested by Dave Henderson

Continued on page 85

## 4-WAY MONEY-MAKER!



Turn a \$2 rough board into \$25 worth of finished trim right in your own shop! Make over 350 standard moldings, tongue & groove, picture frame stock, any custom design. QUICKLY CONVERTS from Planer/Molder to Drum Sander or power-feed Multi-Blade Rip Saw! Made in U.S.A. Choose from 12", 18" and 25" Models.

### Variable Feed Makes The Difference!

Just a twist of the dial adjusts the Woodmaster from 70 to over 1,000 cuts per inch. Produces a glass-smooth finish on tricky grain patterns no other planer can handle. Plenty of American-made "muscle" to handle low-cost, "straight-from-the-sawmill" lumber. 5-Year Warranty, Easy Terms.


FREE FACT KIT

**1-800-821-6651 ext. PW43**

Woodmaster Tools, Inc.  
1431 N. Topping Ave. Dept. PW43, Kansas City, MO 64120  
www.WoodmasterTools.com

## "All my tools should be this good!"

The Accu-Miter® is a professional miter gauge that makes perfect angles easily. Shot-pin action assures dead-on accuracy for common angles — plus a precise protractor scale for everything in between!



We do not recommend operating without the saw blade guard, as is shown here.  
US Patent #5,038,486

Optional accessories:  
manual clamp—  
pneumatic clamp—  
3/8" x 3/4" miter bar—

# JDS COMPANY

Call or write for our free brochure.

Precision Woodworking Equipment

800 Dutch Square Blvd., Suite 200, Columbia, SC 29210  
1-800-382-2637 / SC 803-798-1600  
www.thejdscompany.com

\$149



Continued from page 82

## "Photocopy" a pattern onto your workpiece

When I need to copy a full-size pattern onto a workpiece, I place a photocopy face down on the piece and warm it with a clothes iron. The heat reactivates the toner and transfers the pattern to the wood. However, the iron's large surface doesn't let me be selective about which lines I transfer, and it's easy to scorch my pattern. The Transfer Tool nicely addresses both problems.

With its 3/4"-diameter tip, I got into tiny areas and copied small line drawings and photos without burning my fingertips. And, because the Transfer Tool is designed specifically for this purpose, the temperature setting is as low as it can be for effective transfer without burning the pattern. In fact, I found the going a little slow for my taste and would probably go back to my old iron for larger patterns.

One caveat: The process leaves you with a mirror image of the original pattern, which can be a problem, especially if there are letters in it. To get around this, take the extra step of making the first photocopy on transparency film (available at office supply stores), then photocopying the transparency from the back.

—Tested by Dave Henderson

### PRODUCT SCORECARD

#### Wall Lenk Transfer Tool L16TT

Performance	★ ★ ★ ★ ☆
Price	\$21
Value	★ ★ ★ ★ ★

To locate a dealer near you, call toll-free 888/527-4186.



Continued on page 86

YEAR 2000

# It's About Time

## CLOCK BUILDING CONTEST

### Contest Rules

1. No purchase necessary to enter or win.
2. To enter, construct a working clock. All entries must fit into a box no larger than 2'X2'X2'. The primary material of the clock case must be wood, but you may incorporate other materials.
3. Entries must be received by April 3, 2000. All entries must be postpaid; collect entries will be refused. Attach a 3-1/2"X5" card with your name and address to each entry. You may submit up to 3 entries. Winners limited to one prize. Send all entries to: "It's About Time" Clock Contest, 1716 Locust Street (GA 310), Des Moines, IA 50309-3023.
4. Entries become property of WOOD Magazine and will not be returned. All entries will be offered at auction under the supervision of Meredith Corporation; and all proceeds from the auction will be donated to the U.S. Marine Corps Reserve Toys for Tots program.
5. The entry must be your own original design and not made from previously published patterns. A different approach to an existing clock case could qualify.
6. The sponsors are not responsible for illegible, lost, late, misdirected, damaged, delayed or stolen entries. All decisions of the judges are final. Entry constitutes permission to use winner's

name, hometown, and photograph for promotional purposes, unless prohibited by law. Employees and immediate family members of Meredith Corporation and Titebond® Glues & Adhesives and their affiliates and subsidiaries are ineligible. Open to U.S. and Canadian residents, except Quebec. Subject to all U.S. federal, state and local laws and regulations. Void where prohibited.

7. Winners will be selected and notified by mail on or about May 15, 2000. A panel of representatives from the U.S. Marine Corps Reserve, Meredith Corporation and woodworking experts will judge all entries on or about May 1, 2000 on design excellence, creativity and craftsmanship.

8. Grand Prize - \$5,000; First Prize - \$4,000; Second Prize - \$3,000; Third Prize - \$2,000; Fourth Prize - \$1,000; 25 honorable mentions

9. Winners are responsible for applicable taxes. Winners will be required to complete an Affidavit of Eligibility, Ownership and Liability Release within 14 days of notification, or an alternate winner may be selected.

10. Winners will be published in the December 2000 issue of WOOD. For a list of winners, send a separate self-addressed stamped envelope after June 1, 2000 to: "It's About Time" Clock Contest, 1716 Locust Street (GA 310), Des Moines, IA 50309-3023.

SPONSORED BY

Better Homes and Gardens®

# WOOD



**Titebond®**  
Glues & Adhesives

## SUBSCRIBERS: PLEASE NOTE!

Many of our customers are mail-order buyers. These consumers are interested in receiving offers for other products and services from our company (Meredith Corporation) and for products and services offered by other reputable companies.

In order to promote our other products, we retain your name and address in a prospective customer file. We also provide that name and address to other reputable companies who offer products we consider to be of value and interest to our customers.

However, we also respect the rights of those customers who prefer not to receive additional mail-order offers.

Should you prefer to have your name restricted, please fill out the coupon (below), clip it out, and mail it to the address shown. Please be sure to indicate whether you wish to restrict all offers or just those from other companies.

- I will accept offers from Meredith Corporation only.
- I prefer not to receive any offers.

Include a current magazine address label with this coupon, and mail your request to:

Magazine Customer Service  
P.O. Box 10263  
Des Moines, IA 50336-0263

## NEW VIDEO TORMEK® INSTRUCTION



**\$9.95**  
plus \$3.50 p.p.  
**TOTAL**  
**\$13.45**

Demonstrates the TORMEK method of grinding, sharpening and honing edge tools.

Ideal for potential new owners who wish to preview the TORMEK SYSTEM and for existing owners to see the latest techniques.

TORMEK U.S.A.  
Post Office Box 1522  
Blue Springs  
MO 64013

Tel. 1-800-5-TORMEK

Circle No. 101



Continued from page 85

## Accuracy of unique miter gauge trips our trigonometry

Although I was never a whiz at trigonometry (I always thought "cosine" was something you did to get a loan), I do know that mathematics can be a woodworker's best friend. The folks at Osborne Manufacturing figured a way to use higher math to take the tablesaw miter gauge to a new level of accuracy, and came up with the Osborne EB2 Miter Guide.

The first thing I noticed is the lack of a semi-circular protractor with tiny marks to show me the angle of my miter cut. Instead, an adjustable arm stretches between the guide bar and fence, as shown *below*. Numbers and graduations etched into the arm indicate the miter angle.

So, you ask, is it more accurate than a typical miter gauge? Absolutely. With the EB2, I simply loosened a knurled knob, slid the arm so the end of the tube lined up with the mark for my angle, and tightened the knob. The mitered corners on my 4-sided frame came out perfect. The distance between each degree on the arm varies from  $\frac{1}{16}$ " to  $\frac{1}{8}$ ", so I found it easy to eyeball even fractions of degrees. Milled detents snap the arm in place at precisely  $0^\circ$ ,  $22\frac{1}{2}^\circ$ ,  $30^\circ$ ,  $45^\circ$ , and  $90^\circ$ .

The 21"-long guide bar is the longest I've seen, and works in virtually any standard  $\frac{3}{8} \times \frac{3}{4}$ " guide slot. (Some slots

are a hair undersized, and Osborne offers a slightly slimmer bar for those saws.) If your saw's slot is a little worn, expansion slots in the bar widen it for a snug fit. As a bonus, tapered setscrews let you adjust these expansion slots without removing the bar from the miter slot, saving a lot of test-fitting.

Another unique feature of the EB2 is its reversible 25 $\frac{1}{2}$ " extruded-aluminum fence. One face is covered with non-slip tape to keep your stock from creeping, while the other offers a smooth surface and measuring tape. The aluminum flip-stop works on either face.

Osborne Manufacturing president David Osborne told me that he's also working on a 26" telescoping stop that extends beyond the length of the fence. The extension stop should be available in mid-2000 and will fit all EB2 guides made after February 1, 1999.

—Tested by Dave Henderson

### PRODUCT SCORECARD

#### Osborne EB2 Miter Guide

Performance ★ ★ ★ ★ ★

Price \$160

Value ★ ★ ★ ★ ☆

Call Osborne Manufacturing Co. at 800/852-9655, or order online at [www.osbornemfg.com](http://www.osbornemfg.com).




## GROSS STABIL® PARALLEL CLAMPS VS. THE COMPETITION

	OURS	THEIRS
Clamping Depth	5-1/2"	5-1/8"
Clamping Width	1-3/4"	1-3/8"
Removeable Pads	Yes	No
15% Longer Spindle	Yes	No
Replaceable Pads	Yes	No
Metal Jaws	Yes	No
Nominal Throat Depth	4"	3.5"
Cast Iron Sliding Arm	Yes	No
Clamping Pressure	1100lbs.	1000lbs.
Tempered Steel Bar	Yes	Yes



(517) 278-6121 (800) 671-0838 Fax (517) 278-5523

Circle No. 2230



Continued on page 98

# GIVE LIFE TO YOUR ROUTER

WITH QUALITY ACCESSORIES  
MADE IN THE USA




**ROUSSEAU**  
COMPANY

**FREE CATALOG**

800-635-3416 • www.rousseauco.com

*Buy Factory Direct and Save Thousands!*

## Woodworkers Dreamshop



**SAVE THOUSANDS  
ON SELECT SIZES**

25x34 • 30x46 • 40x56 • 50x116

*Additional sizes available.  
Proudly made in the USA.*



SAVE UP TO  
**\$5,000.00**  
ON STEEL  
BUILDINGS

- 20 Year Guarantee
- Build it yourself
- Maintenance Free
- 100% Useable Space

**CALL TODAY**  
**1-800-463-6062**

**FREE PRODUCT CATALOG  
AND FACTORY PRICE LIST**

[www.us-buildings.com](http://www.us-buildings.com)

PRODUCTS THAT PERFORM



*Continued from page 86*

### Purge pesky labels and residue with Sticker Lifter

These days, you just can't escape stickers—a bar code label pasted on a hammer, a price tag stuck on a pair of shelf standards, even the hardwood you bought has its dimensions adhered to it on a label. If you can peel the label off without tearing it, you're often left with a gummy mess that can't be sanded away and draws dirt like a freshly bathed kid. Sticker Lifter may be the solution to this sticky problem.

I dripped a few drops of the citrusy-smelling solvent on the label on the piece of mahogany shown *below*, and let it soak for a few seconds. Then, using the plastic scraper that comes with the solution, I just peeled the label off. Sticker Lifter left the wood clean with no apparent residue to hinder the finish (although you should still sand prior to finishing).

Emboldened, I found myself wandering around the shop looking for other things to unstick—a UPS label here, a price tag there, even that spongy foam tape that sticks to everything. Some items needed to be soaked longer than others, but eventually, they all came clean.

—Tested by *Chuck Hedlund*



#### PRODUCT SCORECARD

##### Sticker Lifter

Performance ★ ★ ★ ★ ★

Price \$4 for 2 fl. oz.

Value ★ ★ ★ ★ ☆

For more information, call Magic American Corp. at 800/321-6330.

*Continued on page 100*



## WOOD® CLASSIFIED MART

For rates: 1-800/424-3090 Fax 312/464-0512

### BUSINESS OPPORTUNITIES

\$100.00 PER HOUR, woodworking from your garage, full or part-time. No selling! Free brochure: Home Tech 800-456-4987.

### FINANCIAL SERVICES

FREE MONEY! IT'S TRUE. Never repay. Grants guaranteed for business start-up, expansion, equipment, personal needs, education. Free information: 1-800-303-8486.

### FINISHING/RESTORATION

SPRAY-ON SUEDE. New mini flocker. Free brochure (sample included). DonJer Products, 13142 Murphy Rd., Winnebago, IL 61088.

### HELP WANTED

EASY WORK! EXCELLENT PAY! Assemble Products at Home. Call Toll Free 1-800-467-5566 EXT. 11856.

### TOOLS/EQUIPMENT

BAND SAW BLADES: Low tension Swedish Silicon Steel "TIMBER-WOLF" bands. 1/16" thru 1/4". FREE CATALOG 1-800/234-7297. Email-timberwolf2@worldnet.att.net HOME PAGE-timberwolf1.com

CUSTOM BRANDING IRONS as low as \$56.25! Great gift idea! Gift Certificates 10% off. Any design, logo, signature. VISA/MC/AMEX BrandNew 1-800-964-8251 www.brandnew.net

### VIDEOS

TRICKS OF THE TRADE VIDEO MAGAZINE. Call toll-free 1-877-WoodGuy (877-966-3489) for free sample tape. \$4.95 S&H credited on first order. Or visit www.woodguy.com

## A Complete Home Woodworking Shop

### Shopsmith's MARK V

The ONLY alternative to a shop full of expensive single tools. It's a...

600,000 Sold!



- Table Saw
- Disc Sander
- Lathe
- Drill Press
- Boring Machine

Call For FREE Kit  
**1-800-543-7586**

6530 Poe-SF · Dayton, OH 45414



Circle No. 650

## PRODUCTS THAT PERFORM



Continued from page 98

## Bandsaw guide throws resawing a gentle curve

A wandering bandsaw blade has cost many a resawing woodworker time and precious stock, but what's a guy to do? Straight fences offer solid stock support, but don't let you pivot the workpiece to account for blade drift. On the other hand, bullnose guides allow too *much* control. The FastTrak Bandsaw Resaw Guide strikes a happy medium between both.

Like a bullnose guide, this anodized aluminum accessory provides a single pivot-point for steering stock through the blade. But, its broad curved face gave me better control than a narrow bullnose. I felt almost as if I could micro-adjust the cut, with a wide swing of the workpiece yielding only a small adjustment in the blade path.

The Resaw Guide's positioning also helped me stay on top of the curve. The manufacturer recommends setting the crown of the guide slightly ahead of the teeth, which struck me as odd. However, with the guide positioned in this manner, I found I could steer the board precisely *into* the cut, rather than *out* of it.

T-slots on the back of the Resaw Guide make mounting it to your bandsaw's rip fence almost as smooth as the wood you'll cut with it. The 7"-tall guide works on virtually any stationary bandsaw, but if you routinely resaw narrow stock, the 4½"-tall version keeps your bandsaw's blade guides closer to your workpiece. 🌲

—Tested by Dave Henderson

### PRODUCT SCORECARD

#### FastTrak Bandsaw Resaw Guide

Performance ★ ★ ★ ★ ★


Price \$16, 4½" guide; \$20, 7" guide

Value ★ ★ ★ ★ ★

For more information, call toll-free, 888/327-7725, or visit the FastTrak website at [www.dwave.net/~fasttrak](http://www.dwave.net/~fasttrak).



## The Best Place To Buy Your Tools!



★ THE  
WOODWORKING  
SHOWS ★  
tools • supplies • education

THE NATION'S PREMIER WOODWORKING TOUR

☆ Watch live demonstrations before you buy

☆ Get answers from factory reps ☆ Free Seminars and Workshops

☆ See the latest tools and accessories ☆ Savings by the truckload



## VISIT THE SHOW NEAR YOU!

COLUMBUS	Jan. 21-22-23	Ohio Expo Center/Fairgrounds
MILWAUKEE	Jan. 28-29-30	Wisconsin State Fair Park
INDIANAPOLIS	Feb. 4-5-6	Indiana State Fairgrounds
ST. LOUIS	Feb. 11-12-13	Gateway Center
KANSAS CITY	Feb. 18-19-20	Overland Park Int'l Trade Center
TAMPA	Feb. 25-26-27	Florida State Fairgrounds
NO. VIRGINIA	Mar. 3-4-5	Capital Expo Center
CHARLOTTE	Mar. 10-11-12	Merchandise Mart
BUFFALO	Mar. 17-18-19	Erie County Fairgrounds

...and 24 Additional Locations!

Call for FREE brochure 1-800-826-8257

Monday - Friday, 8:30 am - 5:00 pm Pacific Time

E-mail: [info@thewoodshows.net](mailto:info@thewoodshows.net) Web Site: [www.thewoodshows.net](http://www.thewoodshows.net)

★ JET ★ JOINTECH ★ LAGUNA ★ MAKITA ★ OLDHAM ★ PERFORMAX

Circle No. 2900

# Black Willow

The tree that can't help but grow

From the Midwest and eastward, the black willow shows up everywhere. It grows as far north as New Brunswick and to Georgia in the south. On the sandy dunes of North Carolina's offshore islands, it's but a shrub. Travel westward, though, to the vast drainage of the Mississippi River, and the willow grows to commercial-lumber size.

In the Mississippi's rich bottomlands, the black willow attains great proportions—sometimes 100' tall with a trunk nearly 4' in diameter. That size suits the lumbermen just fine. They saw and dry the wood for manufacturing into boxes, crates, and even wooden shutters. In days gone by, some of the black willow harvest would have gone for artificial limbs because of its light weight, yet super shock absorbancy.

Today's country craftsmen turn to freshly cut willow shoots for woven baskets and larger branches and saplings for bark-on, wicker-like furniture. The green wood, collected in cool months, retains its skin-like bark seemingly forever after harvest.

Black willow's greatest contribution to man goes mostly unsung, however. On riverbanks, the deep-rooted, pliant tree buffers raging waters that would sweep away soil. In fact, engineers favor the black willow for planting as a levee reinforcement.

The black willow doesn't need man's help to propagate. Insects pollinate its catkins (blossoms). The wind spreads them. Twigs, snapped off by water, wind, man, or animal, find a resting place in the ground. Then, despite weeks of dormancy, they'll sprout and grow. Try it. ♣



A twig from a black willow tree growing on a river bank may end up sprouting on a downstream sandbar.

Illustration: Jim Stevenson

When you buy a machine you also buy the company selling the machine. Torben Helshoj, President of Laguna Tools understands the American Woodworker, because he is one. Torben knows firsthand the hard work that goes into every piece of furniture. Having the best tools makes a difference.

TAKE FOR EXAMPLE the Robland X31 combination machine, the #1 selling machine of its kind in the world! Powered by three separate 3HP German motors, the Robland X31 gives you a 10" table saw, 50" of cross cut capacity, a 38" rip capacity, 12" jointer, 12" x 9" thickness planer, reversible shaper and a horizontal mortiser.

Free Demonstration Video Available



Free Demonstration Video Available



OR, IF YOU WANT TO cut wood like butter, our line of Bandsaws will make it that easy. Awarded "Editors Choice Award" by American Woodworker magazine, our LT16HD is designed like a tank and performs on the toughest wood like a Ferrari on a mountain road.

## Just Like You, We Build to Last

CALL TODAY to order your FREE demonstration video or brochure and see how much YOU and Laguna Tools have in common - 800 234-1976.

### LAGUNA TOOLS

You Build With Wood, We Build With Trust.

(800) 234-1976  
 2265 Laguna Canyon Road, Laguna Beach, CA 92651  
 (949) 494-7006 • FAX (949) 497-1346

(800) 234-1976  
 100 Central Avenue, #40E, South Kearny, NJ 07032  
 (973) 491-0102 • FAX (973) 491-0591

E-Mail: [lagunatools@earthlink.net](mailto:lagunatools@earthlink.net) • Web: [www.lagunatools.com](http://www.lagunatools.com)



## Another Asian insect attack

It's not the Asian longhorned beetle that's giving New Orleans fits. But the menace that's eating up the historic French Quarter and other sites did come from Asia. It's called the Formosan subterranean termite (*Coptotermes formosanus*), and it eats homes, buildings, live trees, as well as crops and plants. Here are just a few instances of damage:

- The gymnasium floor of a New Orleans Parish high school, built in 1996, was eaten away.
- Thirty percent of the city's live oak trees—some 300 years old—have been infested. (The termites also like ash and baldcypress.)
- A cannon outside the French Quarter's St. Louis Cathedral crashed to the ground after its wooden carriage became a meal.

The terrible termites came to the U.S. in crates holding leftover military equipment and supplies from Pacific fighting in World War II. They're larger, more aggressive, and there are more of them per colony than our native termites. They're also hungrier—a typical colony might eat 1,000 pounds of wood a year. (There's a colony in each of the French Quarter's 110 square blocks.)



**Terrible termites attack New Orleans.**

They became so well established because they actually weren't detected until 1965. And all truly effective pesticides have been banned from use since 1988.

Formosan termites now infest 14 states and cost about \$1 billion annually in property damage, repairs, and control measures. The federal government has launched a new national campaign to control and eradicate them. For information, contact the Southern Regional Research Center, Agricultural Research Service, L.S.U. Agricultural Center, New Orleans, LA 70179. Call 504/286-4444 or visit [www.ars.usda.gov](http://www.ars.usda.gov).

## Some redwood now sheds water

Nature endowed redwood with decay and insect resistance. Water is its only enemy, so structures like redwood decks must be protected with two coats of a waterproofer. The Thompson's Company of Dallas, though, wants to eliminate those preliminary steps for the homeowner with a new product—pressure-treated and waterproofed redwood lumber.

Thompsonized Redwood lumber has the appearance and durability of premium construction heart redwood. Pressure treating with an organic preservative enhances the wood's rot resistance. The toned waterproofing stain applied at the plant evens the color. To treat the cut ends created in construction, the company sells a Cut End stain. While the factory coating initially saves homeowners time and effort, Thompsonized Redwood does have to be rewaterproofed annually.

The price of the treated and waterproofed redwood lumber runs about 12 percent more than construction common redwood. Thompson's also markets pressure-treated pine that's waterproofed, called Thompsonized Lumber. For more information, phone 800/367-6297, or visit the web site, [hickson.com/thompson.html](http://hickson.com/thompson.html).

## It wasn't just junk

Tom Kelly, of Fort Collins, Colorado, exhibited vision, patience, and skill in turning a wood pile found at an estate sale into a striking piece of period furniture. His efforts also brought him \$3,000 cash and a package of tools as the Grand Prize winner of Dremel's recent Furniture Refinishing Contest.

Tom's turn-of-the-century hall tree, shown in the photo *far right*, involved 85 hours of labor to arise from the pile of parts, *near right*. And because the contest rules required both a before and after photo, he spent time with photography, too. Now, with the new Dremel contour sander, Multipro rotary tool, a furniture refinishing kit, and the pocketful of cash he won, Tom can shop for more challenges.



**This turn-of-the-century hall tree, right, took Fort Collins, Colorado's Tom Kelly 85 hours to rebuild and refinish from the pile of parts he started with, above.**

Racine, Wisconsin-based Dremel offers tips on restoration projects and finishing to the general public, too. Just visit its web site with your questions at [www.dremel.com](http://www.dremel.com), or call 800/437-3635. ♣



Photographs: Courtesy of Dremel Illustration: Jim Stevenson